# SERVICE PARTS LIST

for the



TWO-LITRE

(SA Type)

BL HERITAGE LTD

## Service Parts List

for the



#### Foreword.

The Service Parts List has been compiled and illustrated to assist as far as possible the correct ordering of replacement parts, and it will be found that the reference numbers on the illustrations correspond with those in the left-hand columns of the Service Parts List.

When ordering replacements it is of the greatest assistance to our Service Department if the part required is given its correct reference number and description, and the chassis, engine and body numbers should be quoted in all correspondence as well as on the order itself, as delay and misinterpretation of orders are thus avoided.

We would also draw your attention to the fact that you will get quicker service if you place all your orders with our Distributors in your territory, who are holding very adequate stocks of M.G. Spares.

The name and address of the nearest Distributors is given in the Instruction Manual supplied with the car, and we feel sure that all your requirements will receive every consideration and attention.

May we request you, therefore, to get into touch with our Distributors for all your future orders?

We cannot stress too highly the danger of fitting non-genuine parts to M.G. cars, and we strongly advise all M.G. owners to insist and see that for all repairs and replacements only genuine M.G. parts are fitted.

M.G. parts are specially designed and manufactured to withstand the stresses imposed, and we would warn all owners that the fitting of non-genuine parts renders the guarantee null and void.

The Company only fit the highest grade and best known proprietary fitments, but we give no guarantee whatsoever in respect of tyres, lamps, electrical equipment, speedometers, clocks or any other proprietary fittings of any type supplied with the car or otherwise, as such proprietary fittings are usually covered by a guarantee issued by their respective manufacturers.

All questions involving the replacement or repair of any such proprietary fittings should therefore be taken up direct with the manufacturers concerned, and not with The M.G. Car Company Ltd. (See list overleaf.)

February, 1937. Revised September, 1939. Revised Sept., 1946

TELEGRAMS:

ABINGDON



TELEPHONE: 251 ABINGDON

#### SPECIAL NOTE REGARDING PROPRIETARY

### **FITTINGS**

All claims for replacement of alleged defective proprietary parts must be referred direct to the respective component manufacturers or their nearest Service Station and not to The M.G. Car Company Limited.


New proprietary equipment and component parts can be obtained direct from the manufacturers as listed below or from the Service Department of The M.G. Car Company Limited at current list prices.


Name of Part.				Name and Address of Manufacturer.
Dynamo	• • • • • • • • • • • • • • • • • • • •		•••	J. Lucas Ltd., Great King Street, Birmingham.
Starter			. • • •	Ditto
Starter Switch	• • • • • • • • • • • • • • • • • • • •			Ditto
Distributor			• · •	Ditto
Ignition Coil			• • •	Ditto
Junction Box		•••		Ditto
Regulator Box		`	• • •	Ditto
Ammeter		•••		Ditto
Ignition Warning Light			•••	Ditto
"Thirtilite"		• • •		Ditto
Instrument Panel and St	witches	•••		Ditto
Lamps		•••	• • • •	Ditto
Electric Bulbs				Ditto
Battery		•••		Ditto
Electric Horn				Ditto
Windscreen Wiper			•••	Ditto
Driving Mirror				Ditto
Illuminated Rear Number	er-plate	•••		Ditto
"Trafficators"		•••		Ditto
Dipper Switch				Ditto
C 11 1				Ditto
Steering Column Controls		•••		Ditto
Shock Absorbers				Luvax Ltd., Luvax Works, Warple Way, Acton,
Speedometer and Cable				British Jaeger Instruments Ltd., Chronos
Developing County and	Calda			
Reduction Box for Revo.	iution C	ounter	• • •	
O'1 D				
		•••	•••	
Oil and Petrol Level Gar			•••	Ditto
Oil and Petrol Level Gar Attachments for ditto				Ditto Ditto
Oil and Petrol Level Gar	uge	•••	•••	Ditto
Oil and Petrol Level Gar Attachments for ditto	nge			Ditto Ditto
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer	nction Box Ditto gulator Box Ditto numeter Ditto numition Warning Light Ditto strument Panel and Switches Ditto mps Ditto mps Ditto mps Ditto mps Ditto tetric Bulbs Ditto cetric Bulbs Ditto indiscreen Wiper Ditto iving Mirror Ditto pper Switch Ditto pressure Gauge Ditto pper Switch Ditto			
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks				Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2 Ditto The S.U. Carburetter Co. Ltd., East Works, Bor-
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters				Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2 Ditto  The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham.
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters				Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2 Ditto  The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham.
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters Petrol Pumps				Ditto Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2. Ditto  The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham. Ditto  Dunlop Rubber Co. Ltd., Fort Dunlop, Birming-
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters Petrol Pumps Tyres	  			Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2. Ditto The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham. Ditto Dunlop Rubber Co. Ltd., Fort Dunlop, Birmingham. Wilmot-Breeden Ltd., Eastern Works, Camden
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters Petrol Pumps Tyres	  			Ditto Ditto Ditto S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2. Ditto The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham. Ditto Dunlop Rubber Co. Ltd., Fort Dunlop, Birmingham. Wilmot-Breeden Ltd., Eastern Works, Camden Street, Birmingham.
Oil and Petrol Level Gar Attachments for ditto Radiator Thermometer Thermostat Hydraulic Jacks Carburetters Petrol Pumps Tyres Sun Visor	  			Ditto Ditto Ditto  S. Smith & Sons (Motor Accessories) Ltd., Cricklewood Works, London, N.W.2 Ditto  The S.U. Carburetter Co. Ltd., East Works, Bordesley Green Rd., Adderley Park, Birmingham. Ditto  Dunlop Rubber Co. Ltd., Fort Dunlop, Birmingham. Wilmot-Breeden Ltd., Eastern Works, Camden Street, Birmingham. Ditto

#### INDEX

				Page			Page
Accelerator		•••		40	Connecting Rods	• • •	17
Axle (Front)	•••	•••	• • • •	47	Crankshaft and Bearings		14
Axle (Rear)		• • •	•••	811	Cylinder Block	• • • •	12—13
Badge Bar	• • •			61	Cylinder Head	• • •	18
Battery	•••			55	Distributor	• • •	24
Body Details (Salo	on)	• • •		6573	Dynamo		23
Body Details (Fou	rsome)	• • •	• • •	73 - 75	Fan	•••	26
Bonnet and Faster	iers			58	Flywheel		14
Brake Gear			• - •	3540	Front Bearer Plate		13
Bumper (Front)				61	Gearbox	• • •	3033
Bumper (Rear)		• • •		61	Gearbox Remote Control	ı	33-34
Carpets (Saloon)			,	72	Lubrication Details	•••	24-25
Chassis Frame		• • • •		4	Manifolds		19
Controls	• • •			40	Oil Filter		25
Dashboard				51	Oil Pipes		25
Differential				11	Oil Pump	.,.	25
Engine Mounting				34	Pistons		17
Exhaust System				42	Starter Motor		23
Facia Equipment				51 - 52	Thermostat		2629
Floorboards (Saloo	n)			72	Timing Chain Case		14
Footwell				65	Valve Gear	,	18
Harnessed Cables	•••			56	Water Pump		26—29
Hood				74	Propeller Shaft		11
Horn				55	Radiator and Connections		42
Ignition Coil				56	Regulator Box		55
Instrument Panel				51	Running-boards		57
Jacking System				4851	Seats (Saloon)		68
Junction Box				55	Shock Absorbers		46
Lamps				5253	Spare Wheel Carrier		62
Lubricating Systen	1			47	Splasher	•••	61
Mirror				<b>5</b> 5	Springs (Front)		7-8
Number-plates				4647	Springs (Rear)		12
Petrol Pipes	•••			45	Steering Gear		41
Petrol Pump		••••	•••	45	Tools		75
Petrol Tank				45	Wheels		45
Power Unit Details		•••		12	Windscreen (Saloon)		6869
Bell Housing				13	Windscreen (Foursome)		74
Camshaft and	Bearir	ıgs		17	Windscreen Wiper		54
Carburetters				1923	Wings (Front)		57
Clutch				29	Wings (Rear)		57


	(MV)	DESCRIPTION			No. Used	
Part No.		DESCRIPTION	(اله	Saloon	Tourer	Four- some
		CHASSIS FR				
MG651	Chassis frame		1 Ch. No. SA2751		1	1
MG840	33 _ 33		. Ch. No. SA2752	1	1	1
MG651/104		for front Lockheed hos		2	2	2
MG <b>651/108</b>	Front wi	ing rear stay and body	/ bracket O/S	1	. 1	1
MG <b>651/109</b>	" "	, ,, ,, ,,	" N/S	1	1	1
MG651/110	Step iron	and body bracket (fr	ont)	2	<b>2</b>	2
MG651/111	,, ,,		ar) O/S	1	1	1
MG651/112	,, ,,		ar) N/S	1	1	1
MG651/115	Body bra	acket (rear) O/S		î	ī	î
MG651/116	Dody bit	" (rear) N/S		î	i	î
MG651/115	Dacking	de training to the training to		$\frac{1}{2}$	$\overset{\scriptscriptstyle{1}}{2}$	$\frac{1}{2}$
	1 acking	) \ '	••• •••	$\frac{2}{2}$	$ ilde{2}$	$\frac{1}{2}$
MG651/156	Duning	" " (rear) …				
MG651/127	Engine r	ear support bracket O		1	1	1
MG651/128			/S	1	1	1
MG651/129		top bracket		1	1	1
MG <b>651/132</b>	Pedal sha	aft and master cylinde	er bracket	1	1.	1
MG <b>651/121</b>	Bush for	dumb-iron Ceased	l Ch. No. SA2751	8	8	8
MG805/112	Ditte	o (screwed) Comm	c. Ch. No. SA2752	4	4	4
S75/10 °		buffer (rear axle stop)		2	2	2
MG651/150		ring rear bracket	••• ••• •••	$ar{f 2}$	$ar{f 2}$	$\bar{2}$
MG651/117		mb-iron O/S	)	ī	ī	1
MG651/118	T TOTAL CIL	3.7.173	10	-	· i	i
	Doom deed	1 2 6.163				
MG651/119	Rear am	= -1	No. SA275		1	1
MG651/120	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	" N/S	↓	1	1	1
MG805/114	Front du	ımb-iron O/S	]	1	1	1
MG805/115 =	,,	" N/S	Comm.	1	1	1
MG840/111	Petrol ta	ınk support bracket	Ch. No.	<b>2</b>	2	2
MG840/104	Rear dui	mb-iron O/S	SA2752	1	1	1
MG840/105	,,	" N'/S	)	1	1	1
MG651/161	Frame re	einforcement O/S	j Comm. Ch	. 1	1	1
MG651/162	,,	" N/S	No. SA267		i	i
		ALTERAT	IONS			
		ALTERAT	IONS			
		ALTERAT	IONS			
		ALTERAT	IONS			
		ALTERAT	IONS			
		ALTERAT	IONS			
4G842	Front axle as	T AXLE ASSEMBLY (sembly (less springs an	(illustration on pa	ge 6)	1	1
		T AXLE ASSEMBLY (sembly (less springs an	(illustration on pa	0 /	1 1	1 1
AG806/112 AG662/1	Front axle as Front ax	T AXLE ASSEMBLY (sembly (less springs an	(illustration on pa	ິ ′1		
AG806/112 AG662/1	Front axle as Front ax Steering knud	T AXLE ASSEMBLY ( sembly (less springs ar le beam ckle O/S (with bushes)	(illustration on pa nd wheels)	1 1	1	1
MG806/112 MG662/1 MG662/2	Front axle as Front ax Steering knud	T AXLE ASSEMBLY (sembly (less springs ardle beam ckle O/S (with bushes), N/S (with bushes)	(illustration on pa nd wheels) Ceased Ch. No. SA2146	1 1 1 1	1 1 1	1 1 1
MG806/112 MG662/1 MG662/2	Front axle as Front ax Steering knud	T AXLE ASSEMBLY (sembly (less springs ar le beam ckle O/S (with bushes)	(illustration on pa ld wheels)         	1 1 1	1 1	1 1
MG806/112 MG662/1 MG662/2 MG761/1	Front axle as Front ax Steering knuc	T AXLE ASSEMBLY (sembly (less springs ar le beam	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2147	1 1 1 1	1 1 1	1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2	Front axle as Front ax Steering knuc " " " "	T AXLE ASSEMBLY (sembly (less springs at the beam	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2147 Ceased Ch. No. SA2751	1 1 1 1	1 1 1	1 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4	Front axle as Front ax Steering knuc " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam ckle O/S (with bushes) N/S (with bushes) O/S (with bushes)  N/S (with bushes)  N/S (with bushes)  O/S (with bushes)	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2147 Ceased Ch. No. SA2751 Comm. Ch.	1 1 1 1 1 1	1 1 1 1 1	1 1 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam ekle O/S (with bushes) O/S (with bushes)  N/S (with bushes)  N/S (with bushes)  O/S (with bushes)  N/S (with bushes)	(illustration on pa d wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752	1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1	1 1 1 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104	Front axle as Front ax Steering knuc  " " " " " " " Bush for	T AXLE ASSEMBLY (sembly (less springs at alle beam ckle O/S (with bushes) N/S (with bushes) O/S (with bushes) O/S (with bushes) N/S (with bushes) N/S (with bushes) steering knuckle (top	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2751 No. SA2752 Ceased Ch.	1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 2	1 1 1 1 1 1 2
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/105	Front axle as Front ax Steering knuc  " " " " " " " Bush for	T AXLE ASSEMBLY (sembly (less springs ar leb beam	(illustration on paid wheels)	1 1 1 1 1 1 1 1 1 2 2 2	1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 2 2
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/105 MG806/116	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " Bush for Ditte	T AXLE ASSEMBLY (sembly (less springs at the beam N/S (with bushes) O/S (with bushes) O/S (with bushes)	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2167 Ceased Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch.	1 1 1 1 1 1 1 2 2 2	1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 2 2 2
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/104 MG806/116 MG806/117	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam ckle O/S (with bushes) N/S (with bushes) O/S (with bushes) N/S (with bushes) N/S (with bushes) N/S (with bushes) steering knuckle (top o (bottom) o (top) o (bottom)	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch. No. SA2751	1 1 1 1 1 1 2 2 2 2	1 1 1 1 1 1 2 2 2	1 1 1 1 1 1 2 2 2
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG806/116 MG806/117 MG806/117	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs at the beam N/S (with bushes) O/S (with bushes) O/S (with bushes)	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch. No. SA2752 Comm. Ch. No. SA2752	1 1 1 1 1 1 1 2 2 2 2	1 1 1 1 1 2 2 2 2	1 1 1 1 1 1 2 2 2 2
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG806/116 MG806/117 MG806/117 MG662/106 MG806/107	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " Bush for Ditte Ditte Ditte Ditte Slotted in	T AXLE ASSEMBLY (sembly (less springs ar the beam	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 (Ceased Ch. No. SA2752 (Ceased Ch. No. SA2752 (Comm. Ch.	1 1 1 1 1 1 2 2 2 2 1	1 1 1 1 1 1 2 2 2 2 1 1	1 1 1 1 1 1 2 2 2 2 2 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/105 MG806/116 MG806/116 MG662/106 MG662/107 MG662/107	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " Bush for Ditte Ditte Ditte Ditte Slotted in	T AXLE ASSEMBLY (sembly (less springs ar the beam	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Comm. Ch. No. SA2752	1 1 1 1 1 1 2 2 2 2 1 1	1 1 1 1 1 1 2 2 2 2 1 1	1 1 1 1 1 1 2 2 2 2 2 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/105 MG806/116 MG806/116 MG662/106 MG662/107 MG662/107	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " Bush for Ditte Ditte Ditte Ditte Slotted in	T AXLE ASSEMBLY (sembly (less springs ar the beam	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 (Ceased Ch. No. SA2752 (Ceased Ch. No. SA2752 (Comm. Ch.	1 1 1 1 1 1 2 2 2 2 1	1 1 1 1 1 1 2 2 2 2 1 1	1 1 1 1 1 1 2 2 2 2 2 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG806/116 MG806/116 MG806/117 MG662/106 MG662/107 MG662/107	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam ekle O/S (with bushes) O/S (with bushes) O/S (with bushes) O/S (with bushes) N/S (with bushes) N/S (with bushes) N/S (with bushes) steering knuckle (top o (bottom) o (top) o (bottom) ut for steering knuckle "arm" O/S " "arm" O/S " "arm" N/S	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 Ceased Ch. No. SA2752 Comm. Ch. No. SA2752 Ceased Ch. No. SA2752 Comm. Ch. No. SA2752	1 1 1 1 1 1 1 2 2 2 2 1 1 1	1 1 1 1 1 1 2 2 2 2 1 1	1 1 1 1 1 1 2 2 2 2 2 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG806/116 MG806/117 MG662/106 MG662/106 MG662/106 MG662/135 MG662/136 MG662/136	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam	(illustration on paid wheels)  Ceased Ch, No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch. No. SA2752 (Censm. Ch. No. SA2752 (Ceased Ch. No. SA2752 (R.H. thread) (L.H. thread) (L.H. thread) (L.H. thread) (Ceased Ch. No. SA2146 (Ch. No. SA2147	1 1 1 1 1 1 1 2 2 2 2 1 1 1	1 1 1 1 1 1 2 2 2 1 1 1	1 1 1 1 1 2 2 2 2 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/104 MG806/116 MG806/117 MG662/106 MG662/107 MG662/135 MG662/135 MG662/136 MG761/102 MG761/103	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar le beam ekle O/S (with bushes) O/S (with bushes) O/S (with bushes) O/S (with bushes) N/S (with bushes) N/S (with bushes) Steering knuckle (top o (bottom) o (bottom) o (bottom) ut for steering knuckle "arm" O/S "N/S "O/S Comm Ceased	(illustration on paid wheels)  Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch. No. SA2752 (Cased Ch. No. SA2752 (L.H. thread) (L.H. thread) (L.H. thread) (L.H. to SA2146 (Ch. No. SA2147 (Ch. No. SA2147 (Ch. No. SA2147 (Ch. No. SA2147	1 1 1 1 1 1 2 2 2 2 1 1 1	1 1 1 1 1 2 2 2 2 1 1 1 1	1 1 1 1 1 1 2 2 2 2 1 1 1 1 1
MG842 MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/5 MG662/104 MG806/116 MG806/117 MG662/106 MG662/106 MG662/107 MG662/135 MG662/136 MG761/102 MG761/103 MG842/100 MG842/100	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (sembly (less springs ar cle beam	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 (cased Ch. No. SA2751 Comm. Ch. No. SA2752 (cased Ch. No. SA2752 (L.H. thread) (L.H. thread) (L.H. thread) (L.H. to. SA2146 (Ch. No. SA2147 (Comm. Ch. ) No. SA2147 (Comm. Ch.	1 1 1 1 1 2 2 2 2 1 1 1 1	1 1 1 1 1 1 2 2 2 2 1 1 1 1 1	1 1 1 1 1 2 2 2 2 1 1 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG662/105 MG806/116 MG806/117 MG662/107 MG662/107 MG662/107 MG662/106 MG761/102 MG761/103 MG842/100 MG842/101	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (seembly (less springs at le beam	(illustration on paid wheels)	1 1 1 1 1 1 2 2 2 2 1 1 1 1 1	1 1 1 1 1 1 2 2 2 2 1 1 1 1 1 1	1 1 1 1 1 2 2 2 2 1 1 1 1 1 1
MG806/112 MG662/1 MG662/2 MG761/1 MG761/2 MG806/4 MG806/5 MG662/104 MG806/116 MG806/117 MG662/106 MG662/107 MG662/107 MG662/135 MG662/136 MG761/102 MG761/103 MG842/100	Front axle as Front ax Steering knuc  " " " " " " " " " " " " " " " " " "	T AXLE ASSEMBLY (seembly (less springs at le beam	(illustration on paid wheels) Ceased Ch. No. SA2146 Comm. Ch. No. SA2751 Comm. Ch. No. SA2752 Ceased Ch. No. SA2751 Comm. Ch. No. SA2752 (R.H. thread) (L.H. thread) (L.H. thread) (Ceased Ch. No. SA2146 Ch. No. SA2147 d. Ch. No. SA2751 Comm. Ch. No. SA2148 d. Ch. No. SA2751 Comm. Ch. No. SA2752	1 1 1 1 1 2 2 2 2 1 1 1 1	1 1 1 1 1 1 2 2 2 2 1 1 1 1 1	1 1 1 1 1 2 2 2 2 1 1 1 1 1






Part No.	MD	DESCRIPTION	(II)		No. Used	1.
ratt No.				Saloon	Tourer	Four some
MG <b>662/112</b>	Steering	knuckle king pin	) ·	2	2	2
MG <b>662/127</b>		asher for king pin (.188	3"			
MCaaallaa	—.185°	" thick)	Ceased Ch.		As requir	
MG662/128	Ditte	o (.185″—.187″ thick)	No. SA2751		As requir	
MG662/129 MG662/115		o (.187″189″ thick) steering knuckle top bus	, h	2	As requir	ea 2
MG806/106	Steering	knuckle king pin	,,,,,	2	$\frac{\mathbf{z}}{2}$	. 2
MG806/107		asher for king pin		-	~	_
	(upper		(	<b>2</b>	2	2
MG806/108		o (lower)	Comm. Ch.	2	2	<b>2</b>
MG806/114	Lock wa	sher for ditto	No. SA2752	2	<b>2</b>	<b>2</b>
MG806/109		her for king pin		2	2	2 .
MG806/110		for ditto		2	2	2
MG <b>715/137</b>		steering knuckle (bottom		${\color{red}2\\2}$	$egin{smallmatrix} 2 \ 2 \end{matrix}$	2 2
MG <b>662/113</b> MG <b>662/116</b>	Steering	in for king pin stop		2	2	$\frac{2}{2}$
MG662/6		vith studs) O/S		ī	ĩ	ĩ
MG <b>662/7</b>		" " N/S		i	î	ī
MG662/138	"Stud for	front hubs		10	10	10
P234/113		r front hub (split pin h	ole)	<b>2</b>	<b>2</b>	2
MG <b>662</b> /8	Felt oil	retaining washer for	front hub with			
	retaine			2	2	2
MG662/126			Axle No. 1001	2	2	2
MG662/120				2	2	2
$ ext{X}662/1$		ring (inner) for front hu		2	2 2	2 2
MG <b>662/12</b> 1		tube for front hub bear		$\frac{2}{2}$	2	2
X110/86 MG662/122	Brake-dr	ring (outer) for front hu um		$\frac{2}{2}$	$\frac{2}{2}$	$\frac{2}{2}$
MG662/5	Track rod as		Ceased Ch.	ĩ	ĩ	1
MG662/123	Track ro		No. SA2146	ī	ī	1
MG761/3	Track rod as		Ch. No. SA2147	1	$\bar{1}$	1
MG <b>761/104</b>	Track ro		Ch. No. SA2751	2	1	1
MG842/1	Track rod as	sembly	Comm. Ch.	1	1.	]
MG842/102	Track ro		J No. SA2752	1	1	1
A918	Track rod end	l assembly (R.H. thread)	)	1	1	1
A919	" " "	" (L.H. thread)		$rac{1}{2}$	${ \frac{1}{2} }$	$\begin{array}{c} 1 \\ 2 \end{array}$
A918/100 A918/101		her for track rod ball pi	n Ceased Ch.	$\frac{2}{2}$	$\frac{2}{2}$	2
A918/102	Cover for		No. SA2751	$\frac{1}{2}$	$oldsymbol{ ilde{2}}$	$ar{2}$
A918/103	Spring fo		110. 0112/01	$\frac{1}{2}$	$\overline{2}$	2
A918/105	Nut for			2	2	2
A1141	Track rod end	l assembly (R.H. thread)	<b>ົ</b>	1	1	1
A1142	,, ,, ,,	" (L.H. thread)		1	1	1
A1141/100		ver (outer)		2	2	2
A1141/101	Spring fo		Comm Ch.	2	2	2
A1141/102	Nut for			1	1	1
X842/1		t for track rod tube (R.F	1.	1	1	1
X842/2	thread Ditt	′ /T TT /2 1\		1	1	1
X842/3	_	o (L.H. thread) sher for ditto		$\overset{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
A918/104	Nut for	pinch bolt Ceased (	Ch. No. SA2751	ĩ	ī	ī
A1141/103	Nut for			1	1.	1
		ALTERATIO	NS			
		ALTERATIO		*******		
*****************						
MG672	Front spring	FRONT SPRINGS AND complete	SHACKLES	2	2	2
MG672/1	Front spring	main leaf (with bushes)		<b>2</b>	2	2
MG651/121	Bush for	main leaf	Ceased Ch.	8	8 .	8
S98/11		washer for ditto	No. SA2751	4	4	4
MG672/101		ring 2nd leaf		2	2	2
MG <b>672/2</b>		3rd leaf (with clips)		2	2	2 4
MG <b>672/103</b>	Leaf clip	for 3rd leaf	J	. 4	4	

	(AIN)	DESCRIPTION	a	M		No. Used	
Part No.	שוש	DESCRIPTION	(C)	עו	Saloon	Tourer	Four- some
MG <b>672/104</b>	Front en	ring 4th leaf	<u> </u>		2	2	2
MG <b>672/105</b>		ring 5th leaf	- {		$ar{2}$	$oldsymbol{ ilde{2}}$	$\tilde{2}$
MG672/106		ring 6th leaf	ļ		$ar{f 2}$	$ar{f 2}$	$\bar{2}$
MG672/107		ing 7th leaf	i		$ar{2}$	$\frac{1}{2}$	$\frac{1}{2}$
MG <b>672/3</b>		8th leaf (with clips)	Con	sed Ch.	2	2	2
MG672/109	Leaf clip	for 8th leaf		SA2751	4	4	4
AG672/110		ring 9th leaf		5112131	2	2	2
MG672/111		bolt for front spring	[				
MG672/112		re)			2	2	$\frac{2}{8}$
MG672/112 S55/14		tube for ditto	Ì		8 8	8 8	8
MG <b>841</b>	Front spring		₹		2	$\frac{3}{2}$	2
MG841/1		main leaf (with bushes	)		$\frac{-}{2}$	$ar{2}$	$\bar{2}$
m AG805/112		main leaf (front)	´		2	2	2
/IG651/121	,, ,,	" " (rear)			4	4	4
598/11		washer for ditto			2	2	2
AG841/101		ring 2nd leaf			2	2	$egin{array}{c} 2 \ 2 \ 4 \end{array}$
1G841/2		3rd leaf (with clips)			2	2	2
4G808/103		for 3rd leaf	l		4	4	
1G841/103 1G841/104		ring 4th leaf	Cor	nm. Ch.	2 2	$\frac{2}{2}$	2
4G841/104 4G841/105		ring 5th leaf	No.	SA2752	$\frac{2}{2}$	$\frac{2}{2}$	2 2 2
IG841/106		ring 7th leaf			$ar{2}$	$\frac{7}{2}$	$ar{2}$
4G841/3		8th leaf (with clips)	ì		$\frac{7}{2}$	$ar{2}$	$\bar{2}$
MG841/108		for 8th leaf			4	4	4
4G <b>841/109</b>		ring 9th leaf			2	2	2
MG672/112		bolt for front spri	ng				
·	(cent	re)	-		2	<b>2</b>	2
AG808/110		leaf clips			8	8	8
AG808/111		tube for ditto	Į		8	8	8
344/47		ring front shackle		1 (2)	1	1	1
662/2		oin for front spring		sed Ch.	4	4	4
538/7	(fron	t) ut for ditto	100	SA2751	4 4	4	4. 4
556/36		ring front shackle	₹		4	<del></del> 4	4
662/8		oin for front spring	Cor	nm. Ch.	4	4	4
S94/8		ner for ditto	1	SA2752	8	8	8
838/18	Nut for o	litto	j		8	8	8
862/3	Rear pin	for front spring			2	2	<b>2</b>
538/7		ut for ditto	• • •	•••	2	<b>2</b>	2
875/15		r front spring	• • •	•••	2	2	2
869/3	Retaining	plate for ditto	•••		2	2	2
851/3 855/16		front spring "U" clip	CII''	lies	4	4	4 8
855/16 853/5		collar for front spring for front spring		elip	8 4	8 4	4
5 <b>44/37</b>		for torque cable O/S	•••		1	1	1
544/38	Diacket i	" " " N/S			î	î	î
S96/4	Torque c				$\overline{2}$	$\hat{2}$	2
548/4		for ditto		•••	2	2	2
647/6	Fulcrum	pin for ditto			4	4	4
			0310				
		ALTERATI	JNS				
	• • • • • • • • • • • • • • • • • • • •						
				:			
MCars		AXLE ASSEMBLY AND					
	Rear axle ass	embly (less springs and			1	1	1
4G663/1	Rear axle ass Rear axle hor	embly (less springs and using assembly	wheels	)	1 1	1	1
AG663/1 AG689/129	Rear axle ass Rear axle hor Drain plu	embly (less springs and using assembly ug for ditto Comm	wheels  . Axle	)  No. 1889	1 1 1	1 1	1 1
4G663/1 4G689/129 4G663/109	Rear axle ass Rear axle hor Drain plu	embly (less springs and using assembly ug for ditto Common bush for axle housing	wheels  Axle g O/S	)	1 1 1	1 1 1	1 1 1
MG663/1 MG689/129 MG663/109 MG663/110	Rear axle ass Rear axle hor Drain plu Oil return	embly (less springs and using assembly g for ditto Common bush for axle housin	wheels Axle g O/S N/S	No. 1889	1 1 1	1 1	1 1
MG663/1 MG689/129 MG663/109 MG663/110	Rear axle ass Rear axle hor Drain plu Oil return	embly (less springs and using assembly  In g for ditto Common bush for axle housing in the complete with different complet	wheels Axle g O/S N/S erential	No. 1889 assembly	1 1 1 1	1 1 1	1 1 1
MG663 MG663/1 MG689/129 MG663/109 MG663/110 MG663/2	Rear axle ass Rear axle hor Drain plu Oil return "," Differential ca and o	embly (less springs and using assembly g for ditto Common bush for axle housin	wheels Axle g O/S N/S erential	No. 1889 assembly	1 1 1	1 1 1 1	1 1 1







N N1	(II)	DESCRIPTION	,					No. Used	
Part No.		DESCRIPTION					Saloon	Tourer	Four som
S33/44	Bolt for	r differential beari	ng ca	IDS			· 4	4	4
MG <b>663/152</b>		r plug and dipstic					1	1	1
MG <b>663</b> /4		kle dipstick		*			1	1	1
MG <b>663</b> /5		assembly (less cr		wheel a			1	1.	]
MG663/6		case complète					1 pair	1 pair	1 p
MG <b>663</b> /1 <b>2</b> 1	Differen	ıtial wheel					<b>2</b>	<b>`2</b>	2
MG <b>663/122</b>	Differen	itial pinion					4	4 .	4
X555/3		itial spider					1	1	1
533/43		or differential case					8	8	
X364/12	Lock w	asher for ditto					4	4	4
X663/1	Bearing	for differential ca	ase				<b>2</b>	<b>2</b>	2
AG663/123	Adjusti	ng nut for ditto					<b>2</b>	2	2
IG663/124	Lock w	asher for ditto					<b>2</b>	2	2
31/4		or ditto		•••			2	2	:
AG663/7	Crown whee	el and pinion $(12/8)$	57 rat	cio)			1 pair	1 pair	1 p
33/45		rown wheel to diff			e)		10	$\bar{1}0$	1
4G663/128	Lock w	asher for ditto					5	5	
K662/1	Ball be	aring for pinion	•••				1	1	
<b>3663/2</b>	Thrust	bearing for pinion	ı (rea	r)	• • •		1	1	
4G663/153	Dowel :	for ditto					1	1	
4G <b>663/129</b>	Bevel p	oinion housing					1	1	
IG663/154	Spacer	tube for pinion be	earing	(					
,	•	-		m. Ax	le No.	. 762	1	1	
1G <b>663/131</b>	Shim fo	or ditto (.005")						As requ	red
<b>4663/3</b>	Thrust	bearing for pinion	(fro	nt)			1	1	
IG663/125		washer for pinion					1	1	
AG663/132	Retaini	ng spring for ditte	Э				1	1	
4G663/133							1	1	
IG663/134	Cover p	plate for ditto	• • •				1	1	
IG663/138	Lock fo	or bevel pinion ho	using				1	1	
IG <b>663</b> /156	Univers	al joint flange	Com	m. Ch.	No. SA	1829	1	1.	
38/13	Nut for	ditto	Com	m. Ax	le No.	. 687	1	1	
IG <b>663/137</b>	Washer	for ditto					1	1	
AG663/139	Joint fo	or differential carr	ier				1	1	
IG663/140	Joint fo	or rear axle rear o	cover				1	1	
AG663/141		xle rear cover					1	1	
AG663/142	Support	t for rear hub bea	ring	O/S			1	1	
IG663/143	,,	,, ,, ,,	"	N/S			1	1	
4G663/8	Rear hub b	earing housing (w	ith st	ud)			2	1	
AG <b>663/158</b>	Stud fo	r ditto					10	1	
IG <b>663/15</b> 5	Joint fo	or rear hub	Comr	n. Axle	e No.	1266	<b>2</b>	1	
IG <b>663/14</b> 6	Oil seal	for rear hub				• • • •	2	1	
₹663/ <b>4</b>	Ball be	aring for rear hub	·				2	1	
IG663/157	Shim fo	or ditto				• • •		As requ	ired
AG663/147	Nut for	ditto (R.H. threa	ad)				1	1	
IG <b>663/148</b>	,, ,,	" (L.H. threa	$\mathbf{d})$				1	1	
AG663/149		1 1					2	2	
IG663/9	Rear hub (	D/S (with axle sha	ıft)				1	1	
1G <b>663/1</b> 0		N/S (with axle sha					1	1	
4G <b>663/100</b>		ub Ò/S				•••	1	1	
IG <b>663/101</b>	,, ,	, N/S				• • •	1	1	
IG663/150	Rear a	xle shaft				• • •	<b>2</b>	2	
1G662/122		lrum	• • •				2	<b>2</b>	
4G663/151	Safety	ring for ditto					2	2	:
	Propeller sh	aft (61" long) (for	use v	vith dir	rect en	gage-			
	me	nt gearbox) C	eased	Ch. 1	No. SA	X0839	1.	1	
1073									
	•	, , (	omni		<i>G</i>	,	. 1	1	
33/47	Bolts fo	or propeller shaft	flange	•			8	8	
,			- 3				_		
A830 A1073 S33/47	Ditto (55	nt gearbox) C "long) (for use wit cor propeller shaft	eased h syn Comni flange	. Ch. 1 chrome	No. SA	40839	. 1	1	

Part No.	(III)	DESCRIPTION	MD)		No. Used	
		DESCRIPTION	שויי	Saloon	Tourer	Four- some
		REAR SPRINGS AND S	HACKLES			
MG677	Rear springs		)	<b>2</b>	<b>2</b>	2
MG <b>677/1</b>		main leaf with silentbloomshes	C	2	2	2
S17/22		c for main leaf (front)		2	2	2
MG651/121		main leaf (rear)		4	4	4
S98/11 MG <b>677</b> /101		washer for ditto ing 2nd leaf		$rac{2}{2}$	2 2	$\frac{2}{2}$
MG677/102		ing 2nd leaf ing 3rd leaf		$\frac{1}{2}$	$\frac{2}{2}$	$\frac{2}{2}$
MG677/2	Rear spring	4th leaf (with clips)	]	2	2	2
MG677/104		for 4th leaf	C. and Ch	4	4	4
MG <b>677/105</b> MG <b>677/10</b> 6		ing 5th leaf ing 6th leaf	Ceased Ch. No. SA2751	$rac{2}{2}$	2 2	$\frac{2}{2}$
MG677/3		7th leaf (with clips)	110. 0112101	$\frac{7}{2}$	2	2
MG677/108		for 7th leaf	j	4	4	4
MG677/109		ing 8th leaf		$\frac{2}{2}$	2 2	$\frac{2}{2}$
MG <b>677/110</b> MG <b>677/111</b>		ing 9th leaf bolt (centre) for rear		2	2	2
	sprir			<b>2</b>	<b>2</b>	<b>2</b>
MG <b>672/112</b>	Screw for	r leaf clips		8	8	8
S55/14		tube for ditto	Į	8	8	8
MG843 MG843/1	Rear spring of	<b>:omplete</b> main leaf with silentbloo		2	2	2
1.10010/1		bushes	`	2	2	2
S17/22		c for main leaf (front)		2	2	2
MG805/112		main leaf (rear)		2	$\frac{2}{3}$	2 2
MG843/101 MG843/102		ing 2nd leaf ing 3rd leaf		$\frac{2}{2}$	2 2	$\frac{2}{2}$
MG843/2	Rear spring	th leaf (with clips)		$ ilde{2}$	$\frac{7}{2}$	2 4
MG816/104	Leaf clip	for 4th leaf	Comm. Ch.	4	4	4
MG843/104		ing 5th leaf	No. SA2752	2	2	2
MG843/105 MG843/3		ing 6th leaf 7th leaf (with clips)		$\frac{2}{2}$	2 2	2 2
MG843/107		for 7th leaf		4	$\overline{4}$	4
MG843/108		ing 8th leaf		2	2	2
MG843/109		ing 9th leaf		2	2	2
MG <b>677/111</b>	Locating sprii	bolt (centre) for real	1.	2	2	2
MG808/110		r leaf clips		$ar{f s}$	$ar{ar{s}}$	$\bar{s}$
MG808/111		tube for ditto	)	8	8	8
S44/48		ing rear shackle	) C 1 Ch	2	2	2
S62/2 <sup>-</sup> S38/7		ckle pin for rear spring ut for ditto	Ceased Ch.   No. SA2751	4 4	4. 4.	4.4
S56/39		ing rear shackle	11.0. 0.12.01	4	4	4
S62/8	Rear sha	ckle pin for rear spring	Comm. Ch.	4	4	4
S94/8 S38/18		her for ditto	No. SA2752	8	8	8
S62/4	Nut for Front pi	ditto n for rear spring	J	$\frac{8}{2}$	$\frac{8}{2}$	8 2
S56/27		late for rear spring		_	_	-
/1 mm //		Comm. C	In. No. SA1187	2	2	2
S58/6 S111/1	Chook et	p for rear spring rap for rear axle		4	4	4
S56/14	Fixing p	late for ditto		$\frac{2}{2}$	2	$\frac{2}{2}$
201/22	1		NIC	_	_	_
		ALTERATIO	113			
***************************************						
		POWER UNIT AND IN	STALLATION			
MG679/98		LOCK AND COVER-PLAT		1. 0		1
MG <b>679/96</b> X <b>151/</b> 1	Cylinder bloci	<b>k</b> (studded) with main b	earing caps	'n	1	1 3
MG679/96 X151/1 X151/23 X679/1	Cylinder block Core plu		earing caps ge)	1. 0		$\begin{matrix}1\\3\\2\\3\end{matrix}$

Part No.	MD	DESCRIPTION	) N		MD			No. Used	
Part No.		DESCRIPTIO	JN				Saloon	Tourer	For son
1G735/290	Stud for	cylinder head	(long)	•••			13	13	13
[G862/417]	. """		(short)		• • •		5	5	
[G679/558]	Stud for	r main bearings				• • •	4	4	4
[G679/557	_ " "		(short)			• • •	4	4	4
.679/4 [Ce70/149		or locating main		ngs (in		• • •	4 1	4	4
[G679/143 [G679/144		front main bear intermediate ma		ring	•••		$\frac{1}{2}$	$egin{array}{c} 1 \ 2 \end{array}$	1 2
G679/145		rear main bearing					ī	ī	ĩ
679/13		or locating main				•••	4	4	4
IG679/146	Nut for	securing main	bearing	g caps	(front	and			
F (3 amia 1	rear	·		•••	• • •	• • •	4	4	4
lG679/478		(intermediate)	• • •	• • •	•••	•••	4	4	4
.151/ <b>4</b> 5 .679/5		fan bracket or tappet blocks				•••	$\frac{2}{6}$	$\frac{2}{6}$	$\frac{2}{0}$
IG <b>679/232</b>		or distributor					i	ĭ	ì
IG679/110		acket cover-plate				•••	î	ī	í
[G679/111	Joint fo				•••		1	1	1
151/331	Bolt for	securing cover-p	olate				32	32	3:
G679/113		for ditto		• • •	•••		32	32	3:
[G679/112]		ap for cylinder b	olock	***	•••		1	1	_1
151/110		for ditto	•••	• • •	•••	• • •	1	1	1
IG679/118 [G679/120	Guard f	block for tappet		•••	•••		$\frac{3}{3}$	3 3	3
IG <b>679/120</b> I679/7		or ditto securing tappet	hlocks	s	•••	• • •	6	6	6
IG679/119		ate for tappet bl					3	3	;
[G679/1		ection cover (wit					í	ĭ	1
IG679/122		tappet inspectio					3	3	3
(679/8	Circlip f	or ditto					3	3	:3
lG679/123		for ditto	•••	• • •	• • •	• • •	3	3	:3
IG679/124		r tappet inspecti			• • •		1	1	1
1G679/28		r pipe elip (wit			-	-	7	1	1
679/41	Bolt for	her) ditto	•••	• • •	•••	• • • •	1 1	ì	1
(151/5	Nut for						î	î	i
(151/6		washer for ditto		•••	•••		i	1	ĵ
117/1	Breathe						1	1	1
49/11	Clip for	ditto (to oil base					1	1	1
49/28	<i>"</i>	" (to oil base	e) Com	m. Ch.	No. SA:	2752	1	1	1
		ALI	ERAT	IONS					
G679/125	B Bell Ho	ELL HOUSING (	il]ustra	ution o	n page	15)	1	1	1
		using i				•	1 1	1 1	1
lG679/479 .679/3	<b>Bell Ho</b> r Joint fo Bolt (be	using r ditto ell housing to blo	 ock)	•••		• • •	1 12	$\frac{1}{12}$	1 1:
G679/479 679/3 151/15	<b>Bell Ho</b> Joint fo Bolt (be Spring v	using r ditto ell housing to blo vasher for ditto	 ock)				1 12 12	$egin{array}{c} 1 \\ 12 \\ 12 \end{array}$	1 1: 1:
G679/479 679/3 151/15	<b>Bell Ho</b> Joint fo Bolt (be Spring v	using r ditto ell housing to blo	 ock)	•••		•••	1 12	$\frac{1}{12}$	1 1: 1:
MG679/125 1G679/479	Bell Ho	using i		•••		• • •			
(G679/479 679/3 151/15 679/2	Bell Hor Joint fo Bolt (be Spring v Dowel fo	r ditto  Il housing to blowasher for ditto or bell housing	 ock)  ERAT	IONS			1 12 12 2 2	1 12 12 2 2	]
IG679/479 (679/3 1151/15 1679/2 FRON IG679/58	Bell Hon Joint fo Bolt (be Spring v Dowel fo T BEARER PI Front bearer	r ditto r ditto r ditto r ditto r ditto r ditto ll housing to blo vasher for ditto or bell housing  ALT  ALT  LATE AND TIM r plate complete ckets	ERAT	IONS	   CASE (in e supp	illustr	1 12 12 2 2	1 12 12 2 2 page 15)	1 1 2
IG679/479 (679/3 1351/15 1679/2 FRON IG679/58 IG679/229	Bell Hon Joint fo Bolt (be Spring v Dowel fo  T BEARER P Front beare brac Stud for	r ditto  r ditto  il housing to ble washer for ditto or bell housing  ALT  ALT  LATE AND TIMI r plate complete ckets dynamo suppor	ERAT	IONS  HAIN  engir	    CASE (ine supp	illustr	1 12 12 2 2	1 12 12 2 2	1 1: 1: 2
IG679/479 1679/3 1151/15 1679/2 FRON IG679/58	Bell Hon Joint fo Bolt (be Spring v Dowel fo  T BEARER P Front beare brac Stud for	r ditto r ditto r ditto r ditto r ditto r ditto ll housing to blo vasher for ditto or bell housing  ALT  ALT  LATE AND TIM r plate complete ckets	ERAT	IONS  HAIN  engir	    CASE (in energy supproduction of the supproduction of th	illustr	1 12 12 2 2 ation on	1 12 12 2 2 page 15)	1 1: 1: 2

Part No.	[[1]]	DESCRIPTION					No. Usea	12
						Saloon	Tourer	Four some
X151/27	Nut for engine	front support be	racket	bolt		6	6	6
X151/28	Spring washer			• • •		6	6	6
MG <b>67</b> 9/130	Joint for front					1	1	1
X151/19		ng front bearer p	late	• • •	• • •	10	10	10
MG679/131	Ditto (thin I		• • •	• • • •	•••	1	1	1
X151/15 X 670/9	Spring washer		• • •	•••	•••	$\frac{11}{2}$	$\frac{11}{2}$	$\frac{11}{2}$
X679/2 MG679/2	Dowel for front Timing chain case a		• • •	•••	• • •	1	i	1
MG <b>679/135</b>	Cover for oil se				• • • •	1	1	î
X679/12	Oil seal washer					1	î	1
P151/508	Screw for oil se			•••		6	6	6
X151/21	Spring washer	for ditto				6	6	6
X679/9	Thrust spring f	or camshaft				1	1	1
X679/10	Rivet for ditto		• • •	• • •		1	1 1	1
MG <b>679/13</b> 6	Joint for timin		• • •	•••	• • •	1	1	1
X679/11		ig timing chain o		• • •	• • •	7	~	7
X151/15	Spring washer	for ditto	•••	•••		7	7	7
		ALTERATIO						
		***************************************						
			********					
MG <b>679/38</b>	GRANKSHAFT Grankshaft with oil	T, MAIN BEAR!			YWH	EEL 1	1	1
MG <b>795/3</b>	Crankshaft mai	n bearing (front	and in	 ntormed	liate)	3	3	3
MG <b>795/4</b>	Clankshart man	" (rear)		Titer med	.iate;	1	ï	1
MG679/47	Flywheel with clute			wels		1	î	í
MG679/148		pin (in flywheel)				3	3	3
X679/14		kshaft (in flywhe				2	2	2
X679/15	Spigot bearing	for gearbox first	motic	n shaft	i	1	1	1
MG679/57	Centre for spigot be					1	1	1
MG679/151		for spigot beari	ng	• · ·		1	1	1
X679/16	Circlip for spig		• • •		• • •	1	1	1
MG679/152	Bolt for securing		• • •	• • •	• • •	6	6	6
MG679/153		ot bearing centre		• • •	• • •	3	3	3
X679/18	Circlip for ditte	· · · · · · · · · · · · · · · · · · ·				1	-	
	C-0 ml-nh - ft 1				• • •		1	1
	Crankshaft dan	nper plate	ηc	eased		2	2	2
X679/19	Dowel for ditte	nper plate	CE	eased ing. No		$\frac{2}{2}$	$rac{2}{2}$	$\frac{2}{2}$
X679/19 MG679/156	Dowel for ditte Spring for ditte	nper plate 0 0		eased ing. No PHG20	<b>)2</b> 8	2 2 4	$\begin{array}{c}2\\2\\4\end{array}$	2 2 4
MG679/154 X679/19 MG679/156 MG679/580 MG679/531	Dowel for ditte Spring for ditte Crankshaft dan	nper plate	m. E	eased ing. No PHG20 ing. No	9 <b>28</b> o.	2 2 4 2	2 2 4 2	2 2 4 2
X679/19 MG679/156	Dowel for ditto Spring for ditto Crankshaft dan Dowel for ditto	nper plate	m. E IG2029	eased ing. No PHG20 ing. No 9. Cea	9 <b>28</b> o. ased	2 2 4	$\begin{array}{c}2\\2\\4\end{array}$	2 2 4
X679/19 MG679/156 MG679/530 MG679/531 MG679/532	Dowel for ditto Spring for ditto Crankshaft dan Dowel for ditto Spring washer	nper plate	m. E IG2021 No.	eased ing. No PHG20 ing. No 9. Cea	9 <b>28</b> o. ased	2 2 4 2 2	2 2 4 2 2	2 4 2 <b>2</b> 2
X679/19 MG679/156 MG679/530 MG679/531 MG679/532	Dowel for ditto Spring for ditto Crankshaft dan Dowel for ditto Spring washer	nper plate	m. E IG2029 No. onper	eased ing. No PHG20 ing. No 9. Cea QPHG3	<b>928</b> o. ased <b>9020</b>	2 2 4 2 2	2 2 4 2 2 4	2 4 2 2 2
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan	nper plate	m, E G2029 No. on per	eased ing. No PHG20 ing. No 9. Cea QPHG3	<b>928</b> o. ased <b>9020</b>	2 2 4 2 2 4 2 1	2 2 4 2 2 4 2 1	2 4 2 2 2 4 2 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditto	nper plate	m. E G2029 No. nper J. No.	eased ing. No PHG20 ing. No 9. Cea QPHG3	<b>928</b> o. ased <b>9020</b>	2 2 4 2 2 4 2 1 4	2 2 4 2 2 4 2 1 4	2 2 4 2 2 4 2 1 4
X679/19 MG679/156 MG679/580 MG679/581 MG679/582 MG679/155 MG827/9 MG679/227 X151/15	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte	nper plate  nper plate Com  per plate QPF  for ditto Eng.  crankshaft dan  Ceased Eng  per Comm. Eng  No. QPHG	m. É IG2029 No. enper J. No. e	eased Ing. No PHG20 Ing. No 9. Cea QPHG3	028 o. ased 6020	2 2 4 2 4 2 1 4	2 2 4 2 2 4 2 1 4 4	2 4 2 2 4 2 4 2 4 4 4 4
X679/19 MG679/156 MG679/580 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft driving	nper plate  O  nper plate Com QPH for ditto Eng. or crankshaft dar Ceased Eng No. QPHG	m. E CE CE CE No. No. nper No. 8021	eased Ing. No PHG20 Ing. No 0. Cea QPHG3 QPHG3	028 o. ased 0020	2 2 4 2 4 2 1 4 4	2 2 4 2 2 4 2 1 4 4 1	2 4 2 2 4 2 1 4 4 1
X679/19 MG679/156 MG679/1580 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivit Key for ditte	nper plate  O  O  O  O	m. E G2029 No. onper s. No. o	eased ing. No PHG20 ing. No 0. Cea QPHG3 QPHG3 haft)	028 o. ased 6020 	2 2 4 2 4 4 4 4 1	2 2 4 2 2 4 2 1 4 4 1 1	2 4 2 2 4 2 1 4 4 1 1
X679/19 MG679/156 MG679/1580 MG679/531 MG679/155 MG679/155 MG679/157 X151/15 MG679/157 X151/8 MG679/158	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivi Key for ditte Oil thrower for	nper plate  nper plate  nper plate  for ditto Eng.  or crankshaft dar  Ceased Eng  No. QPHG  nper Comm. Eng No. QPHG  ng sprocket (on commands)	m. E Q Mo. E No. e nper No. e 3. 3021	eased Eng. No PHG20 Eng. No PHG20 Eng. No PHG3  QPHG3  Anathr	028 o. ased 0020 	2 4 2 4 2 1 4 4 1 1	2 2 4 2 2 4 2 1 4 4 1 1	2 4 2 2 4 2 1 4 4 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/158	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivii Key for ditte Oil thrower for Distance piece	nper plate  nper plate   Com QPH for ditto   Eng. or crankshaft dar Ceased Eng No. QPHG ng sprocket (on communication) crankshaft  (through timin	m. E GC2029 No. onper c. No. g B021 cranks	eased ing. No iPHG20 ing. No iPHG20 ing. No iPHG30	 028 0. 038ed 0020 	2 2 4 2 4 2 1 4 4 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1	2 2 4 2 2 4 4 4 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/159 MG679/160	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditto Oil thrower for Distance piece Fan pulley	nper plate  nper plate   Composition   C	m. E C C MG2028 No. mper (. No. g B021 cranks  g chai	eased ing. No iPHG20 ing. No iPHG20 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 iPHG	 928 o. ased 6020  	2 2 4 2 4 2 1 4 4 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1 1	2 4 2 2 4 2 1 4 4 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/159 MG679/160 MG827/115	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Oil thrower for Distance piece Fan pulley Cone for fan pi	nper plate  nper plate  nper plate Com	m. E C C MG2028 No. mper (. No. g B021 cranks  g chai	eased ing. No iPHG20 ing. No iPHG20 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 iPHG	 928 o. ased 6020  	2 2 4 2 4 2 1 4 4 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1	2 2 4 2 2 4 4 4 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/160 MG827/115 MG827/116	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring fo Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditto Oil thrower for Distance piece Fan pulley	nper plate  nper plate  nper plate  pper plate  pper plate  pper plate  pper plate  pper plate  Comm. Eng No. QPHG:  ng sprocket (on commands) (through timin  (through timin  Comm. E	m. E G2023 No. nper No. s B021 cranks  g char g. No.	eased ng. No pPHG20 ing. No pPHG20 ing. No pReserved QPHG3 QPHG3 haft) in case) QPHG3	028 o. ased 0020 0020  o o o o o	2 2 4 2 2 4 1 4 1 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1 1	2 4 2 2 4 2 1 4 4 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/160 MG827/116 MG827/116 MG679/161	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Oil thrower for Distance piece Fan pulley Cone for fan pu Fan pulley	nper plate  nper plate  nper plate  for ditto Eng.  r crankshaft dar  Ceased Eng  No. QPHG  ng sprocket (on command)  crankshaft  (through timinCeased Eng  naft  Ceased  Ceased	m. E G2023 No. nper No. s B021 cranks  g char g. No.	eased ing. No iPHG20 ing. No iPHG20 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 ing. No iPHG30 iPHG	028 o. ased 0020 0020  o o o o o	2 2 4 2 4 4 4 1 1 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1 1	2 4 2 4 2 1 4 4 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/158	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Coll thrower for Distance piece Fan pulley Cone for fan pu Fan pulley Nut for cranksl	nper plate  nper plate  nper plate Com	m. E GC2022 No. nper No. s B021 eranks  g char g. No. ng. No.	eased ing. No pPHG20 ing. No pPHG20 ing. No QPHG3 QPHG3  haft) in case QPHG QPHG3  OPHG3	 3020  3020  3020  3020  303021	2 2 4 2 4 2 1 4 4 1 1 1 1 1	2 2 4 2 2 4 4 4 1 1 1 1 1	2 1 2 2 4 2 1 4 4 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/160 MG827/116 MG679/161 MG679/161 MG679/161 MG679/161 MG679/161 MG679/161	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Oil thrower for Distance piece Fan pulley Cone for fan pu Fan pulley Nut for cranks! Starting dog Nut for crank (starting dog	pper plate  pper plate  pper plate  pper plate  precent for ditto Eng.  for crankshaft dar  Ceased Eng.  pper Comm. Eng.  No. QPHG.  ng sprocket (on compart)  crankshaft  (through timin  crankshaft  Ceased Eng.  chaft  Ceased  Ceased  Ceased  Ceased  Ceased  Ceased  Comm. Eng.  Comm. Eng.  Comm. Eng.  Comm. Eng.  Comm. Ceased	m. E GC2022 No. nper No. s B021 eranks  g char g. No. ng. No.	eased ng. No pPHG20 ing. No pPHG20 ing. No pReserved QPHG3 QPHG3 haft) in case) QPHG3	 3020  3020  3020  3020  303021	2 2 4 2 4 4 1 1 1 1 1 1 1	2 2 4 2 2 4 2 1 4 4 1 1 1 1 1 1	2 2 4 4 2 2 4 4 4 4 4 4 1 1 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG6827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/160 MG827/116 MG679/161	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Camshaft drivin Key for ditte Coil thrower for Distance piece Fan pulley Cone for fan pu Fan pulley Nut for cranks Starting dog Nut for crank (starting de Damper front 1	nper plate  nper plate  nper plate  for  for ditto Eng.  or crankshaft dar  Ceased Eng  No. QPHG  ng sprocket (on commands)  crankshaft  (through timinCeased Eng  llley Comm. E  naft  Ceased  comm. Ceased  crankshaft  Comm. E  naft  Comm. Ceased  comm. E  naft  Comm. Comm. Comm.	m. E GC2022 No. nper No. s B021 eranks  g char g. No. ng. No.	eased ing. No pPHG20 ing. No pPHG20 ing. No QPHG3 QPHG3  haft) in case QPHG QPHG3  OPHG3	 3020  3020  3020  3020  303021	2 4 2 4 4 1 1 1 1 1 1 1	2 2 4 2 2 4 4 1 1 1 1 1 1 1	2 2 4 4 2 2 4 4 4 4 1 1 1 1 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/532 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/160 MG827/116 MG679/161	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Camshaft drivin Key for ditte Coil thrower for Distance piece Fan pulley Cone for fan pu Fan pulley Nut for cranks Starting dog Nut for crank (starting de Damper front 1 Bolt (securing)	nper plate  nper plate  nper plate  for ditto Eng.  reased Eng.  Comm. Eng.  No. QPHG.  ng sprocket (on compart)  crankshaft  (through timinCeased Eng.  lilley Comm. Eng.  Comm. Eng.  Crankshaft  Crankshaft  Ceased Eng.  Comm. Comm. Eng.  Comm. Eng.  Comm. Eng.  Comm. Comm. Eng.  Comm. Comm. Comm.	m. E EG GE GE GE GE GE GE GE GE GE GE GE GE	eased ing. No PHG20 ing. No PHG20 ing. No O O O O O O O O O O O O O O O O O O O		2 4 2 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2 2 4 2 2 4 4 1 1 1 1 1 1 1 1 1 1 1 1 1	2 2 2 4 4 4 4 1 1 1 1 1 1 1 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/531 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/160 MG827/116 MG679/161	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Camshaft driving Cone for fan pulley  Nut for cranks Starting dog Nut for crank (starting de Damper front Jabolt (securing) Spring washer	nper plate  nper plate  nper plate Com	m. E GE GE GE GE GE GE GE GE GE GE GE GE GE	eased ing. No iPHG20 ing. No iPHG20 ing. No iPHG30 ing. No iPHG30		2 2 4 2 4 1 1 1 1 1 1 1 1 1 3 3	2 2 4 2 2 4 1 1 1 1 1 1 1 1 1 1 1 1 3 3	2 2 4 4 2 2 2 4 4 1 1 1 1 1 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/531 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/159 MG679/160 MG827/116 MG679/161 MG679/4 MG679/4 MG679/523 MG679/524 X151/30 X151/15 MG827/119	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for the Crankshaft dan Bolt for ditte Camshaft driving Key for ditte Camshaft driving Key for ditte City oil thrower for Distance piece Fan pulley Cone for fan pur Fan pulley Cone for fan pulley Con	prepare plate  more plate  prepare plate  prepare for ditto Eng.  for ditto Eng.  for crankshaft dan  Ceased Eng.  prepare Comm. Eng.  No. QPHG:  massprocket (on compare)  crankshaft  (through timin  crankshaft  (through timin  crankshaft  Comm. Eng.  c	m. E EG GE GE GE GE GE GE GE GE GE GE GE GE	eased ing. No PHG20 ing. No PHG20 ing. No O O O O O O O O O O O O O O O O O O O		2 4 2 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2 2 4 2 2 4 4 1 1 1 1 1 1 1 1 1 1 1 1 1	2 2 2 4 4 4 4 1 1 1 1 1 1 1 1 1 1 1 1 1
X679/19 MG679/156 MG679/530 MG679/531 MG679/531 MG679/155 MG827/9 MG679/227 X151/15 MG679/157 X151/8 MG679/158 MG679/160 MG827/116 MG679/161 MG679/161 MG679/161 MG679/161 MG679/161 MG679/523 MG679/524 X151/30 X151/15	Dowel for ditte Spring for ditte Crankshaft dan Dowel for ditte Spring washer Friction ring for Crankshaft dan Bolt for ditte Spring for ditte Camshaft drivin Key for ditte Camshaft driving Cone for fan pulley  Nut for cranks Starting dog Nut for crank (starting de Damper front Jabolt (securing) Spring washer	prepare plate  more plate  prepare plate  prepare for ditto Eng.  for ditto Eng.  for crankshaft dan  Ceased Eng.  prepare Comm. Eng.  No. QPHG:  massprocket (on compare)  crankshaft  (through timin  crankshaft  (through timin  crankshaft  Comm. Eng.  c	m. E EG2029 No. Ch. S.	eased ing. No PHG20 ing. No PHG20 ing. No O. Cer QPHG3  And Cer QPHG3  And Cer QPHG3  And Cer QPHG3  And Cer		2 2 4 2 4 1 1 1 1 1 1 1 1 1 3 3	2 2 4 2 2 4 1 1 1 1 1 1 1 1 1 1 1 1 3 3	2 2 4 4 2 2 4 4 1 1 1 1 1 1 1 1 1 1 1 1





Part No.	í MD	DESCRIPTION	N	6	(II)			No. Used	
2 411 110.		- DESCRIPTION					Saloon	Tourer	Four- some
		ALTI	ERATIC	NS					
						•••••			••••••••
		***************************************							
		***************************************		· · · · · · · · · · · · · · · · · · ·					
***************************************									•••••
				•••••					
		.,,							
			******						
***************************************									
	CAMEI	AFT AND BEA	DINGS	Glinet	ration	on non	o 91)		
MG852/111	Camshafi			(musu		on pag	1	1	1
MG679/165		procket (on cam					î	Î	î
X151/8	Key for	ditto		• • •			1	1	1
MG679/551	Oil defle	cting plate for ca				.000	,		_
MG679/74	Washer		m. Eng.			889	1 1	1	1
X679/23		for camshaft spre r camshaft sproc			ug 		1	1	1 1
X679/24		sher for ditto			•••		î	î	1
MG679/166		bearing (front)					1	1	1
MG679/5	,,		interm				1	1	1
MG679/6 MG679/171	"	" (rear ii	ntermed	iate)	naives	) • • •	1 1	1 1	1 1
MG679/171 MG679/172	Screwed	dowel for camsh	aft bear	rings			3	3	3
MG679/173		wel for camshaft			•••		2	2	$\frac{3}{2}$
MG679/174	Timing c	hain	•••		• • •		1	1	1
		ΛΙΤΙ	ERATIC	MS					
		· · · · · · · · · · · · · · · · · · ·			· · · · · · · · · · · · · · · · · · ·		• • • • • • • • • • • • • • • • • • • •		
		• • • • • • • • • • • • • • • • • • • •						•••••	•••••
								• · · · · · · · · · · · · · · · · · · ·	
,			• • • • • • • • • • • • • • • • • • • •						
									•••••
	· · · · · · · · · · · · · · · · · · ·		•••••				· · · · · · · · · · · · · · · · · · ·		• • • • • • • • • • • • • • • • • • • •
	***************************************								
									• • • • • • • • • • • • • • • • • • • •
							• • • • • • • • • • • • • • • • • • • •		
						,			•••••
	CONNECTIN	G RODS AND P	ISTONS	(illus	tration	on pa	ge 15)		
MG679/26		d (with cap and	bolts)	,		_	,		
MCOORIO	T):44 - /	Ceasi	ed Eng.	No. Q	PHG3	241	6	6	6
MG827/61 MG827/331		less bearing) earing for ditto (h	···    alves		a. Eng		$\frac{6}{12}$	6 12	$\frac{6}{12}$
MG679/559	Bolt for						12	12	12
X151/12	Nut for o				• • •		12	12	12
X151/14		rew for gudgeon	-		• • •		6	6	6
X151/15		asher for ditto			• • •	• • •	6	6	6
MG <b>679/45</b>	Piston (complipin)	ete with rings and			eased		6	6	6
P151/145	Piston rii				ng. No	).	12	12	12
MG679/480	<i>"</i> "	T /4 - =			PHG1		6	6	6
MG <b>679/178</b>	" "	(bottom scrap	er) ्	J ``	`		6	6	6
MCerouso	Distan /aams	data with *i	] (	Comm	. Eng.				
MG <b>679/59</b>		olete with rings eon pin)	and	No. Q	PHG1:		6	6	6
MG679/482		ng (compression)			Eng.	707	12	12	12
MG679/483	,, ,,	(scraper)	j J <i>'</i>		PHG1	107	6	6	6
MG679/97		ete with rings and	~ 0	10			0	0	
MG679/517	pin) Piston rir				omm. ng No		$rac{6}{12}$	$\frac{6}{12}$	$\frac{6}{12}$
MG679/517	riston m	ng (compression) (scraper)			ng. No PHG17		6	6	6
MG795/223	Gudgeon"			· ) ×			6	Ğ	6

Tourer

Saloon

ALTERATIONS

				••••••
***************************************				
	CYLINDER HEAD AND VALVE GEAR			
MG679/8	Cylinder head assembly	1	1	1
MG679/9	Cylinder head (studded) with valve guides	1	1	1
MG679/181	Stud for cylinder head cover	. 3	3	3
P151/256	Stud for manifolds	5	5	5
X151/27	Nut for ditto	5	5	5
MG679/182	Valve guide	12	12	12
MG679/184	Rear cover-plate for cylinder head	1 1	1 1	1
MG679/185 X151/30	Joint for ditto Bolt for ditto	4	4	1 4
X151/50 X151/15	Spring washer for ditto	4	4	4
MG679/100	Inlet valve	6	6	6
MG827/140	Exhaust valve	6	6	6
MG706/379	Valve spring (outer)	12	12	12
MG706/380	" ", (inner) Ceased Eng.	12	12	12
MG679/104	Cap for valve springs No. QPHG2886	12	12	12
MG679/106	Seating washer for valve springs	12	12	12
MG735/261	Valve spring (outer) Comm.	12	12	12
MG735/262	" (intermediate) Eng. No.	12	12	12
MG735/263	" " (inner) J QPHG2887	12	12	12
MG735/264	Cap for valve springs (top) Comm. Eng. No. QPHG2887	12	12	12
	Ceased Eng. No. QPHG3005	1-		
MG735/265	Seating washer for valve springs			
<b>,</b>	Comm. Eng. No. QPHG2887	12	12	12
MG706/444	Cap for valve springs (top) Comm. Eng.	12	12	12
MG706/443	Packing ring for ditto (rubber) No. QPHG3006	12	12	12
MG679/105	Split cotters for valves halves	<b>24</b>	24	24
MG679/186	Support bracket for rocker-shaft (front and		_	_
MCTORIA	intermediate)	5	5	5
MG706/449	Ditto (rear) Bolt for securing rocker-shaft support brackets	$rac{1}{12}$	$\begin{array}{c} 1 \\ 12 \end{array}$	$\frac{1}{12}$
MG679/188 MG679/189	Lock washer for ditto	6	6	6
MG679/190	Washer for rocker-shaft support bracket (locking	•	v	v
	rocker-shaft)	2	2	2
MG706/450	Ditto (packing) Comm. Eng. No. QPHG3096	4.	4	4
MG679/42	Valve rocker-shaft (with plugs)	1	1	1
MG679/193	Spacer tube for rocker-shaft (long)	2	<b>2</b>	2
MG679/194	" " " " (medium)	3	3	8
MG679/195	" " " (short)	2	2	2
MG679/196	Spacer spring for rocker-shaft (long)	2	$\frac{2}{3}$	$rac{2}{3}$
MG679/197 MG679/198	" " (medium) (short)	$\frac{3}{2}$	$\frac{3}{2}$	3 2
MG679/199	Spring clip for rocker-shaft	$oldsymbol{ ilde{2}}$	$ar{2}$	$\frac{2}{2}$
MG679/200	Washer for ditto	$ar{2}$	$\overline{2}$	$\bar{2}$
MG679/52	Valve rocker with bush (Nos. 1, 3, 5, 7, 9, 11 valves)	6	6	6
MG679/53	" " " " (Nos. 2, 4, 6, 8, 10, 12 valves)	6	6	6
MG679/202	Bush for valve rocker	12	12	12
MG679/215	Tappet adjusting screw	12	12	12
X151/7	Lock nut for ditto	12	12	12
MG679/208	Cylinder head gasket	1	1	1
MG679/207	Nut for securing cylinder head	18 1	18 1	$\begin{array}{c} 18 \\ 1 \end{array}$
MG679/12 MG679/211	Cylinder head cover assembly Valve clearance instruction plate	1	1	1
X679/26	Rivet for ditto	$\frac{1}{2}$	$\frac{1}{2}$	$\frac{1}{2}$
MG706/105	Plug for valve cover Ceased	ī.	ĩ	ī
P110/469	Oil filler cap	1	1	1
MG679/213	Joint for cylinder head cover	1	1	1
MG706/446	Nut for securing cylinder head cover	3	3	3
X679/27	Washer for ditto	3	3	3
MG795/216	Tappet	$\frac{12}{10}$	12	12
MG679/217 MG679/14	Circlip for tappet Ceased Engine No. QPHG3241	12 19	12 19	12
MG679/14	Push rod complete	12	12	12



#### No. Used DESCRIPTION Part No. Four Saloon Tourer some ALTERATIONS MANIFOLDS AND AIR CLEANER (illustration on page 21) MG852/5 Induction manifold (front) (studded) ... 1 . . . MG852/6 (rear) (studded) 1 1 MG852/105 Carburetter balance pipe (in manifold) ... 2 4 Stud for carburetter 4 4 MG679/400 MG852/7 Balance pipe for carburetters with venturi tube 1 1 MG679/350 Hose for ditto 2 ... . . . Shield and clip for ditto 2 MG852/107 2 ... MG852/21 1 1 Air intake pipe . . . . . . Ceased Ch. No. SA0294 Recomm. Ch. No. SA1106 Hose for ditto Clip for ditto MG679/330 1 1 A1168 2 . . . MG679/325 4 .1. 4 Joint for air intake pipe ... MG679/326 Packing piece for air intake pipe Ceased Ch. 1 1 1 (front) ... Stop bracket for slow MG679/327 running No. SA2257 control wire 1 1 1 MG852/100 Packing piece for air intake pipe Comm. (front) 1 7 1 Ch. No. Stop bracket for slow running and MG852/101 SA2258 jet control wire 1 Bolt for air intake pipe MG852/102 4 X151/15Spring washer for ditto . . . A943 Air cleaner ... ... 1 A1222 Clip for ditto MG679/61 Exhaust manifold (front) (studded) 1 1 ... MG679/62 (rear) (studded) 1 Stud for exhaust pipe MG827/321 6 6 . . . . . . ... X679/58Nut for ditto... 6 6 6 Spring washer for ditto X151/286 6 . . . MG679/550 Joint for induction and exhaust manifolds 1 1 1 MG679/338 Clamp for manifolds 5 5 Nut for ditto X706/12 5 ALTERATIONS **CARBURETTERS** (illustration on page 21) Ceased Ch. No. SA2233 **'**1 Front carburetter complete A864/11 A1136/1 Comm. Ch. No. SA2234 1 Rear carburetter complete Ceased Ch. No. SA2257 A864/21 1 1 Comm, Ch. No. SA2258 A1136/2 1 Float-chamber with stud A864/6 Ceased Ch. No. SA2257 2 •2 2 Comm. Ch. No. SA2258 A1136/6 $^{2}$ Stud for cover $\mathbf{2}$ 2 2 A864/148... A1136/7Float-chamber cover assembly Comm. Ch. No. SA2258 2 2 Ceased Ch. No. SA2257 9 A864/7 Ditto $\dots$ A864/117 Balance lever for float $\mathbf{2}$ 2 2 2 $\bar{\mathbf{2}}$ A864/118 2 Fulcrum pin for ditto $\bar{2}$ A864/9Float-chamber needle with seat 2 2

Ceased Ch. No. SA2257

Comm. Ch. No. SA2258

. . . .

2

 $\mathbf{2}$ 

2

2

2

2

2

Tickler pin for float

Tickler pin for float


Spring for ditto


A433/148

A864/121

A1136/104

Part No.	ME	DESCRIPTION	. MD		No. Used	Eou
				Saloon	Tourer	Fou som
A433/115	Filter for	float-chamber cover		2	2	2
A864/116	Banjo un	ion bolt Ceased	l Ch. No. SA2257	2	2	2
A1136/105	,,		i. Ch. No. SA2258	<b>2</b>	2	2
A433/144	Washer fo		•••	4	4	4
A864/114		ecuring float-chamber		2	2	2
A864/109		pipe (front carburette	er) Ceased Ch.	1	1	1
A864/110	,,,	", (rear carburetter	) No. SA2257	1	1	1
A1136/100	"	" (front carburette	No SA9959	1 1	1 1	1 1
A1136/101 A864/149	Washer fo		) J NO. SA2256	$\overset{1}{2}$	2	$\frac{1}{2}$
A864/145	Washer re	, " (bottom)	••• ••• •••	$\frac{7}{2}$	$\frac{5}{2}$	${f  ilde{2}}$
A433/145	Holding-u	p bolt for float-chaml		$ar{f 2}$	$\overline{2}$	$ar{2}$
A433/146		or ditto (langite)		2	$\overline{2}$	2
<b>A433</b> /147	,, ,		chamber and body)	2	<b>2</b>	2
A864/113	Sealing w	asher for float-chambe		2	<b>2</b>	2
<b>1864/101</b>	Float			<b>2</b>	<b>2</b>	2
11268/1	Suction chaml	per (bushed) with pist	on and rod l Ch. No. SA2751	$_2$	2	2
A1269/1	Ditto (bush	ed) with piston and r		-	-	-
11200/1	Ditto (bush		. Ch. No. SA2752	2	<b>2</b>	2
864/122	Spring for	suction piston		$\bar{2}$	$ar{2}$	$\bar{2}$
864/123		or ditto		$\bar{2}$	$ar{2}$	$\bar{2}$
433/128		or suction chamber			-	_
,	r		I Ch. No. SA2257	2	2	2
1136/107	Ditto	Comm	. Ch. No. SA2258	<b>2</b>	$^2$	2
1864/124	Spring wa	sher for ditto		<b>2</b>	<b>2</b>	2
864/143	Lubricato:	r for suction chamber				
		Ceased	Ch. No. SA2257	2	2	<b>2</b>
1960/109	Screw for	suction chamber (long	g) )	2	2	2
433/165	" "	" (sho		2	$^2$	2
.1136/108		for suction chamber	Comm. Ch.	2	2	$\frac{2}{4}$
1136/109		suction chamber	No. SA2258	4	4	4
123/25		er needle		2	2	2
864/125	Screw for	ditto		2	2	3
864/3	Body with pis	ton plate		2	2	2
864/144	-	(front carburetter)	Ceased Ch.	1	1	1
864/126		(rear carburetter)	J No. SA2233	$rac{1}{2}$	1	1
562/107		oring for ditto			2	$\frac{2}{1}$
$1136/111 \\ 1136/112$		(front carburetter) (rear carburetter)	Comm. Ch.	1 1	1 1	1
1136/112 $1136/113$			∫ No. SA <b>2234</b>	$\hat{f 2}$	$\frac{1}{2}$	$\frac{1}{2}$
433/149		et lever (front and re	ear carburetters)	-	_	_
400/140	1201 L		Ch. No. SA2233	2	2	2
1136/114	Ditto (	front and rear carbure		-	_	~
1100/114	Ditto (		Ch. No. SA2234	2	2	<b>2</b>
.864/111	Combined	link for jet lever and		-	_	_
.001,111			Ch. No. SA2257	1	1	1
433/150		oin for ditto (short)		4	4	4
433/151		" " " (long)	•••	<b>2</b>	2	2
562/7	Jet with 1	nead	•••	2	<b>2</b>	2
864/128	Bearing fo	or jet (top half)		<b>2</b>	2	<b>2</b>
433/152		r ditto (sealing)		<b>2</b>	<b>2</b>	2
433/153		jet bearing (top half	)	2	2	2
433/154	Bearing fo	or jet (bottom half)	• • • • • • • • • • • • • • • • • • • •	<b>2</b>	2	2
433/155	Washer fo	r ditto (sealing)		<b>2</b>	2	2
503/115	Gland was	sher (fabric insertion)		4	4	4
433/156	_ "	" (brass)		4	4	4
.433/157		sleeve for jet bearing alf)	(bottom ) Ceased   Ch. No.	2	2	2
433/158		r ditto (brass)	SA2257	$\frac{2}{2}$	$\frac{1}{2}$	$\tilde{2}$
1136/115		sleeve for jet bearing		-	-	~
/		alf)	Ch. No.	2	2	2
1136/116		r ditto (brass)	SA2258	$oldsymbol{ar{2}}$	$\bar{2}$	$\tilde{2}$
433/159	, m	di vi		$\frac{\overline{2}}{2}$	$ar{2}$	$\overline{2}$
433/160			Ch. No. SA2257	$ar{2}$	$\frac{7}{2}$	2
1136/117	-J8		Ch. No. SA2258	$\frac{1}{2}$	$ar{2}$	$\overline{2}$
433/166	Lock sprin	g for ditto		$ar{2}$	$ar{2}$	$\tilde{2}$
523/116		pindle (front)	***	1	1	1
864/130		pindle (rear)		1	1	1
864/138		or throttle spindle (fr		1	1	1
864/131	, ,		ar carburetter)	1	1	1
864/132	Throttle v	alve (butterfly)		2	<b>2</b>	2
	Screw for		Ch. No. SA2257	4	4	4





Don't No.	DESCRIPTION			(III)			Б	
Part No.		DESCRIPTION			_	Saloon	Tourer	Fou som
433/122	Screw for	throttle valve Con	ım. Ch	No. SA2	258	4	4	4
1136/123		operating lever (accel				1	1	1
469/109		t for ditto	•••			1	1	1
433/162		stop bell crank lever		)		2	2	2
.433/163	Adjusting	screw for ditto		Cea	$\operatorname{sed}$	2	2	2
433/164		ing for ditto			No.	2	2	2
469/107		return spring	• • •	SA2	257	2	2	2
469/110	Collar for		•••	ļ		2	2	$\frac{2}{2}$
1136/118		stop bell crank lever		Com		2	$egin{smallmatrix} 2 \ 2 \end{matrix}$	2
1136/119 1136/120		screw for ditto	•••	Con	No.	$rac{2}{2}$	$\frac{2}{2}$	$\frac{2}{2}$
1136/120 $1136/121$		return spring	•••	SA2		ĩ .	í	ĩ
1136/122		throttle spindles	•••	0/12	200	$\hat{f 2}$	$\hat{f 2}$	2
469/111	Screw for		•••	•••		$ar{f 2}$	<b>2</b>	2
1136/3		d for throttle spindle		coupling	S	1	1	1
864/139		disc for ditto			• • • •	<b>2</b>	<b>2</b>	2
433/167	Bolt for		•••		•••	8	8	8
G679/440		ig rod for jet levers		Ceased		1	1	1
16/5		for ditto		Ch. No.		2	2	2
679/87		for ditto		SA2233		2	<b>2</b>	2
1136/4	Connecting ro	d for jet levers with		enas No. SA22	104	1	1	1
G679/401	Igint for	carburetters		NO. 3A44	204	$\frac{1}{2}$	$\overset{1}{2}$	2
706/9		securing carburetters	•••		• • •	4	4	4
151/15		asher for ditto	•••	• • • • • • • • • • • • • • • • • • • •	•••	4	4	4
,	1 0							
		ALTERA			·			
	FNGINE EI	ECTDICAL FAILDM	ENT (S	Unstration		72 graph 97\		
1170		ECTRICAL EQUIPM	ENT (i	llustration 	on	page 27)	1	1
1170 1016/1	Dynamo							
1016/1	Dynamo	, ,	•••	•••	•••	1	1	1
1016/1 848/2 848/3	Dynamo Terminal bloc Field coil set Brush set	k cover with screw	•••	•••		1 1	1 1 1 1	1 1 1
$1016/1 \ 848/2 \ 848/3 \ 1170/2$	Dynamo Terminal block Field coil set Brush set Brush spring	k cover with screw set	•••			1 1 1 1	1 1 1 1	1 1 1 1
1016/1 348/2 348/3 1170/2 348/6	Terminal bloc Field coil set Brush set Brush spring Drive end bra	k cover with screw set acket assembly (less	   bearing	g)		1 1 1 1	1 1 1 1	1 1 1 1
$1016/1 \\ 848/2 \\ 848/3 \\ 1170/2 \\ 848/6$	Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator	k cover with screw set acket assembly (less	   bearing	    g) main bru		1 1 1 1 1	1 1 1 1 1	1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1	Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear	k cover with screw	   bearing	g)		1 1 1 1 1 1	1 1 1 1 1 1	1 1 1 1 1
1016/1 348/2 348/3 1170/2 348/6 1170/1	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature	set	  bearing with aring)	y) main bru	   ish	1 1 1 1 1 1	1 1 1 1 1 1 1	1 1 1 1 1
1016/1 348/2 348/3 1170/2 348/6 1170/1 348/102 348/103	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end	set	  bearing with aring)	   y) main bru 	    ssh 	1 1 1 1 1 1 1	1 1 1 1 1 1 1	1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for	set	bearing with aring)	  y) main bru 	    	1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1
1016/1 348/2 348/3 1170/2 348/6 1170/1 348/102 348/103 348/105 G679/225	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator gear Armature Drive end Bush for Pulley fo	set	bearing with aring)	   g) main bru 	     ssh 	1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1
1016/1 348/2 348/3 1170/2 348/6 1170/1 348/102 348/103 348/105 G679/225 G679/226	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support	set	bearing with aring)	   y) main bru  	     	1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 11170/2 848/6 11170/1 848/102 848/103 848/105 G679/225 G679/226 G679/227	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (second	set	bearing with aring) cket	  y) main bru 	     	1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 2
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/226 G679/227 151/15	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley fo Support I Bolt (sec	set	bearing with aring) cket	   y) main bru	     	1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 2 2
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/225 G679/227 151/15 G679/228	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (second) Spring was Dynamo	set	bearing with aring)	  y) main bru	      	1 1 1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 2 2
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/226 G679/226 G679/228 G679/230	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support   Bolt (sect Spring wa Dynamo Distance	set	bearing with aring)	   y) main bru	     	1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 1 1 1 2 2 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/226 G679/227 155/5 G679/228 G679/230 151/3	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (secon Spring we Dynamo Distance Bolt for	set	bearing with aring) cket	   g) main bru   	      	1 1 1 1 1 1 1 1 1 1 1 2 2 1	1 1 1 1 1 1 1 1 1 2 2 1	1 1 1 1 1 1 1 1 2 2 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/226 G679/227 151/15 G679/230 151/3	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (seed Spring wa Dynamo Distance Bolt for Spring wa	set	bearing with aring)	   main bru   	      	1 1 1 1 1 1 1 1 1 1 2 2 1 1	1 1 1 1 1 1 1 1 2 2 1 1	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/227 151/15 G679/228 G679/230 151/3 151/28 151/151	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (seed Spring wa Dynamo Distance Bolt for Spring wa	set	bearing with aring)cket	  y) main bru	      	1 1 1 1 1 1 1 1 1 1 2 2 1 1 1	1 1 1 1 1 1 1 1 1 2 2 1 1 1	11 11 11 11 11 11 11 11 11 11 11
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/225 G679/227 151/15 G679/228 G679/230 151/3 151/28 151/16	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support I Bolt (sect Spring wat Dynamo Distance Bolt for of Spring wat Spring wat Spring wat Nut for of	set	bearing with aring)	  main bru	      	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 81170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/226 G679/227 151/15 G679/230 151/3 151/28 151/151 151/151	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support   Bolt (sect Spring we Dynamo Distance Bolt for Spring we Swivel be Nut for Spring we Spring we	set	bearing with aring) cket	  main bru	     	1 1 1 1 1 1 1 1 1 1 1 2 2 1 1 1 1	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (seed Spring wat Dynamo Distance Bolt for Spring wat Swivel bo Nut for of Spring wat Nut for of	set	bearing  with aring)	main bru		1 1 1 1 1 1 1 1 1 1 2 2 1 1 1 1 1	1 1 1 1 1 1 1 1 2 2 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/103 848/105 G679/225 G679/225 G679/227 151/15 151/28 151/3 151/28 151/15 151/16 151/16 151/15 181/15	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley fo Support I Bolt (sec Spring wa Dynamo Distance Bolt for of Spring wa Swivel bo Nut for of Spring wa Starter	set	bearing with aring)cket	  y) main bru		1 1 1 1 1 1 1 1 1 1 2 2 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/227 151/15 G679/228 G679/230 151/3 151/16 151/16 151/15 151/16 151/15 151/16 849 849/1	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (sect Spring w. Dynamo Distance Bolt for Spring w. Swivel be Nut for of Spring w. Nut for of Spring w. Starter switch	set	bearing with aring)	main bru	      	1 1 1 1 1 1 1 1 1 2 2 1 1 1 1 1 1	1 1 1 1 1 1 1 1 2 2 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 G679/225 G679/227 151/15 G679/228 G679/230 151/3 151/28 151/151 151/16 151/15 151/16 151/15 849/1 849/2	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (secon Spring we Dynamo Distance Bolt for Spring we Swivel bo Nut for of Spring we Nut for of Spring we Starter Starter switch Pinion and sl	set	bearing with aring)	  main bru		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/105 6679/225 6679/226 6679/220 151/15 151/15 151/16 151/15 151/16 151/15 151/16 151/15 849 849/1 849/2 849/3	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (seen Spring wand Dynamo Distance Bolt for Spring wand Swivel be Nut for of Spring wand Nut for of Spring wand Spring wand Starter Starter switch Pinion and sl Field coil set	set	bearing with aring)	  main bru		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
1016/1 848/2 848/3 1170/2 848/6 1170/1 848/102 848/103 848/103 848/105 G679/225 G679/225 G679/227 151/15 151/28 151/3 151/28 151/15 151/16 151/16 151/15 181/15	Dynamo Terminal bloc Field coil set Brush set Brush spring Drive end bra Commutator of gear Armature Drive end Bush for Pulley for Support Bolt (secon Spring we Dynamo Distance Bolt for Spring we Swivel bo Nut for of Spring we Nut for of Spring we Starter Starter switch Pinion and sl	set	bearing  with aring)	main bru		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1


A849/7 Ba A849/8 Dr	ontact details of and cover with rive end brack xing bracket a		DESCRIPTION		[[7]]			For	
A849/7 Ba A849/8 Dr A849/9 Fi A849/100 A849/101 A849/105 A849/102 A849/104	and cover with rive end brack xing bracket a	complete					Saloon	Tourer	For sor
A849/7 Ba A849/8 Dr A849/9 Fi A849/100 A849/101 A849/105 A849/102 A849/104	and cover with rive end brack xing bracket a						1	1	1
A849/8 Dr A849/9 Fi A849/100 A849/101 A849/105 A849/102 A849/104	ive end brack xing bracket a		rew		•••	•••	ī	ī	1
1849/9 Fi 1849/100 1849/101 1849/105 1849/102 1849/104	xing bracket a						1	1	1
.849/100 .849/101 .849/105 .849/102 .849/104							1	1	1
1849/105 1849/102 1849/104	Oil retaining		•••				1	1	1
849/102 849/104	Oil retaining	g felt ring	•••				1	1	1
849/104	Cork oil ret	aining washe	r				1	1	1
	Starter cont						1	1	1
526/101	Bush for fix					• • •	1	1	1
<i>I</i> .	Main spring		• • •	• • •	• • • •	• • •	1	1	1
IG706/213	Joint for sta		•••	• • •	•••	• • •	1	1	1
X151/3		uring starter		• • •	• • •	•••	3	3	9
(151/28 (Cero/197	Spring wash			•••	• • • •	•••	3	3	3 1
IG679/127		over for star		• • •	•••	• • •	1	1 1	1
IG679/128	Joint for di			• • • •	•••	• • • •	$rac{1}{3}$	3	3
9151/178 [151/21	Spring wash	spection cov	ег	•••	• • • •	• • • •	3	3	9
	stributor		•••	•••	•••	• • •	1	ï	ì
_	ntact set				•••	•••	1	1	i
	crometer lever			• • • •	• • • •	•••	1	i	j
	ming lever wit						î	î	1
	tuating lever						•	•	
110		ew assembly	1111101	Office	. Dody	and	1	1	1
.847/5 Di	stributor cover		with ca	ble m	rts)		î	ī	î
847/100	Rotor		•••		••••		î	i	ĵ
739/102	Condenser	***					ĩ	ī	1
739/103	Oiler	•••			•••	•••	ī	1	1
IG679/234	Drive gear f	for distribute	or		•••	•••	1	1	1
IG679/235	Pin for ditte	o					1	1	1
[G <b>679</b> / <b>233</b>	Screw for di	stributor					1	1	1
$[\mathrm{G}679/15]$ Igi	nition cables c	omplete with	carrie	tube			1	1	1
IG <b>679/238</b>	Clip for ditt				• • •		<b>2</b>	<b>2</b>	2
<b>(679/100</b>	Bolt for ditt	to	• • •				<b>2</b>	<b>2</b>	2
X151/15	Spring wash		• • •				<b>2</b>	<b>2</b>	<b>2</b>
	ritch for revers		n gearb	ox)	•••	• • •	1	1	1
1806	Sparking ph				• • •	• • •	6	6	•
1972	Terminal for	r ditto	• • • •	•••	•••	•••	6	6	6
		ALL	ERATI	ONS					
***********									
					· · · · · · · · · · · · · · · · · · ·				
E IG679/46 <b>O</b> il	NGINE LUBRI I base with ba	ICATION SYS	STEM (	illustra	ation o	n page	e <b>22</b> ) 1	1	1
<b>E</b> [G679/46 <b>O</b> il [G679/241	NGINE LUBRI I base with ba Baffle for oi	ICATION SYS ffles I base (front	STEM ( 	illustra 	ation o	n page 	22) 1 1	1 1	1
E  G679/46 <b>Oi</b>    G679/241  G679/242	NGINE LUBRI I base with ba Baffle for oi	ICATION SYS ffles I base (front , , (rear)	STEM (  )	illustra  	ation o  	n page  	22) 1 1 1	1 1 1	1 1
E  G679/46 Oil  G679/241  G679/242  151/331	NGINE LUBRI I base with ba Baffle for oi Bolt for baf	ffles I base (front , (rear) ffles	STEM ( )	illustra 	ation o  	n page 	22) 1 1 1 1 12	1 1 1 12	] ] 1
E(G679/46 Oil (G679/241 (G679/242 151/331 (151/6	NGINE LUBRI I base with ba Baffle for oi Bolt for baf Spring wash	files I base (front , (rear) fles er for ditto	STEM (  )	illustra	ation o  	on page	22) 1 1 1	1 1 1	] ] 1 1
E(G679/46 Oil G679/241 (G679/242 151/331 1.151/6 (151/43	NGINE LUBRI I base with ba Baffle for oi Bolt for baf	files I base (front , (rear) fles er for ditto for oil base	STEM ( )	illustra	ntion o	on page	22) 1 1 1 1 12 12	1 1 1 12 12	1 1 1: 1:
E [G679/46 Oi [G679/241 [G679/242 151/331 151/6 [151/43 [151/44	NGINE LUBRI base with ba Baffle for oi """ Bolt for baf Spring wash Drain plug	ICATION SYS ffles I base (front , (rear) ffles er for ditto for oil base ditto	STEM (	illustra	ation o	on page	22) 1 1 1 12 12 12	1 1 1 12 12 1	1 1 1; 1; 1
EG679/46 Oil G679/241 G679/242 151/331 151/6 151/43 151/44 G679/243	NGINE LUBRI I base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil	ICATION SYS ffles I base (front , (rear) ffles er for ditto for oil base ditto	STEM ( )	illustra		on page	22) 1 1 1 1 12 12 1 1	1 1 12 12 12 1	1 1; 1; 1; 1
EG679/46 Oil G679/241 G679/242 151/331 151/6 151/43 151/44 G679/243 151/30	NGINE LUBRI I base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil	ffles I base (front , (rear) ffles er for ditto for oil base ditto base	STEM ( )	illustra		on page	22) 1 1 1 12 12 12 1 1	1 1 12 12 12 1 1	1 1: 1: 1: 1: 1: 1:
EG679/46 Oil G6679/241 G6679/242 151/331 C151/6 C151/44 C16679/243 C151/30 C679/28	NGINE LUBRI base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec	IGATION SYS ffles (rear) fles er for ditto for oil base ditto base uring oil bas	STEM ( ) se (shor (long	illustra		on page	22) 1 1 1 12 12 12 1 1 1	1 1 12 12 12 1 1 1	11 11 11 11 11 11 11
EG679/46 Oil G6679/241 G6679/242 151/331 G151/6 G151/44 G151/44 G151/44 G679/243 G679/28 G679/29	NGINE LUBRI base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec "" Spring wash	ICATION SYS ffles I base (front , (rear) fles er for ditto for oil base ditto I base uring oil bas , """ er for ditto	BTEM ( ) se (shor (long (long	illustra t)		on page	22) 1 1 1 1 12 12 1 1 1 10	1 1 1 12 12 12 1 1 1 12 10	1 19 19 11 11 11 12 2
E G679/46 Oil G679/241 G679/242 151/331 C151/6 C151/43 C151/44 G679/243 C151/30 G679/28 G679/29 G679/30	NGINE LUBRI base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec "" Spring wash	ICATION SYS  ffles  I base (front	BTEM ( ) se (shor (long (long	illustra t) (slott	ation o	on page	22) 1 1 1 12 12 1 1 1 1 1 1 1 2 2	1 1 12 12 12 1 1 1 12 10 2	11 15 15 16 11 16 17 2 2
EG679/46 GG679/241 GG679/242 151/331 G151/43 G151/43 G151/43 G151/30 G679/243 G679/28 G679/29 G679/29 G679/250 G679/251	Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec	ICATION SYS ffles I base (front , (rear) ffles er for ditto for oil base ditto l base uring oil bas , " " " mer for ditto for sump (re , " (fr	stem ( )	illustra t) (slott	ation o	on page	22) 1 1 1 12 12 1 1 1 1 1 1 1 2 2 24	1 1 12 12 12 1 1 1 12 10 2 24	1 11 11 11 11 11 12 2 1
EG679/46 GG679/241 GG679/242 151/331 G151/6 151/43 G679/243 G679/243 G679/28 G679/28 G679/29 G679/250 G679/251 G679/251	Bolt for bat Spring wash Drain plug Washer for Joint for oil Bolt for sec	ICATION SYS ffles  I base (front , " (rear) ffles er for ditto for oil base ditto l base uring oil bas " " " er for ditto for sump (re er bar to cyl	stem (  )	illustra t) ) (slott	ted)	on page	22) 1 1 1 12 12 1 1 1 1 1 2 24 1 4	1 1 1 12 12 1 1 1 1 12 10 2 24 1 1	1 13 15 1 1 1 10 2 2 2 1 1
IG679/46 IG679/241 IG679/242 P151/331 C151/6 C151/44 IG679/243 C151/30 C679/28 C679/29 G679/29 IG679/250 IG679/251 C679/251	Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec	ication systems.  If base (front grear) if its grear if its grear)  If base grear if its grear its great its gr	STEM ( ) see (shor (long (long (long ont)))	illustra t) ) (slott	ted)	on page	22) 1 1 1 12 12 1 1 1 1 2 24 1 4 2	1 1 12 12 12 1 1 1 12 10 2 24 1 1	1 13 13 14 10 10 10 2 2 2 11 14 2
EG679/46 IG679/241 IG679/242 151/331 151/6 151/43 151/43 151/43 16679/243 151/30 16679/28 1679/29 16679/29 16679/250 IG679/251 16679/35 1679/35 151/19	MGINE LUBRI I base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec "" Spring wash Bearer bar i "" Screw (beare Bolt (rear b Screw (sump	ication systems.  ffles  I base (front  fror ditto for oil base ditto  I base  uring oil base  uring oil base  " " " "  eer for ditto for sump (re re bar to cylearer bar to cylearer bar to be to bearer left.	stem ( ) se (shor (long (long ar) ont) linder to bell he bear)	illustra t) ) (slott	ted)	on page	22) 1 1 1 12 12 1 1 1 1 2 24 1 1 4 2	1 1 12 12 12 1 1 1 1 12 10 2 2 24 1 1 1 4 2	1 12 13 14 15 16 22 24 14 24
EG679/46 IG679/241 IG679/242 151/331 151/6 151/43 151/44 IG679/243 151/30 6679/29 6679/29 16679/250 IG679/251 16679/34 16679/35 151/19 151/15	Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec "" " Spring wash Bearer bar " " Screw (beard Bolt (rear b Screw (summy Spring wash Spring wash Spring wash Spring wash Spring wash	ication systems.  files  I base (front for oil base ditto for oil base ditto for oil base ditto for oil base ditto for oil base for sump (remains of the for sump (remains of the for oil base for oil to be for oil to be for oil to be for ditto	stem ( )	::::::::::::::::::::::::::::::::::::::	ation o	on page	22) 1 1 1 12 12 1 1 1 1 1 2 24 1 1 4 4	1 1 1 12 12 12 1 1 1 12 10 2 2 4 1 1 4 4	1 12 13 14 15 16 22 24 44 44
EG679/46 IG679/241 IG679/242 151/331 IJ51/43 IJ51/43 IJ51/43 IJ51/30 IG679/28 IG79/29 IG679/29 IG679/250 IG679/35 IJ51/19 IJ51/15 IG679/71	MGINE LUBRI I base with ba Baffle for oi Bolt for baf Spring wash Drain plug Washer for Joint for oil Bolt for sec "" Spring wash Bearer bar i "" Screw (beare Bolt (rear b Screw (sump	ICATION SYS ffles I base (front , (rear) ffles er for ditto for oil base ditto l base uring oil bas """ """ for of ditto for sump (re "" (fr er bar to cy earer bar to o to bearer l er for ditto oil base	stem ( )	illustra t) (slott block) ousing)	ted)	on page	22) 1 1 1 12 12 1 1 1 1 2 24 1 1 4 2	1 1 12 12 12 1 1 1 1 12 10 2 2 24 1 1 1 4 2	11 12 13 14 11 10 22 2 11 14 24


art No.	MB DESCRIPTION MB		No. Used	Four	
		Saloon	Tourer	som	
<b>A852/101</b>	Terminal for sump attachment for oil gauge	1	1	1	
1852/102	Joint for sump attachment	1	1	1	
X679/31	Bolt for sump attachment	6	6	6	
X679/32	Spring washer for ditto	6	6	0	
AG679/16	Oil suction pipe	1	1	1	
IG679/249	Joint for ditto	1	1	]	
\$679/33 #C670/444	Bolt for ditto Strainer for oil base	1 1	1 1	1	
IG679/444 K679/38	The law and the few little	1	1	1	
IG679/17	Oil pump assembly	1	i	1	
IG679/18	Oil pump body (bushed)	î	î	ĵ	
IG795/222	Bush for oil pump body	î	î	i	
IG679/80	Oil pump cover with relief valve seat	î	î	-	
IG679/264	Seat for relief valve	ī	ī		
151/317	Dowel for oil pump cover	1	1	]	
1G679/255	Joint for oil pump cover	1	1	]	
IG679/19	Oil pump cover plug with relief Ceased				
•	valve plug Eng. No.	1	1	]	
(679/37	Washer for relief valve plug J QPHG3150	1	1		
IG <b>795/11</b> 9	Guide for oil pump relief valve Comm. Eng.	1	1		
IG795/118	Cover plug for ditto J No. QPHG3151	1	1		
(679/36)	Washer for oil pump cover plug		1		
(679/59)	Bolt for oil pump cover (long)		2	:	
K679/98	" " " " (intermediate)	2	2	:	
(679/39)	" " " " " (short)		.1	4	
IG679/258	Oil pump shaft	1	1		
1G679/259	Oil pump shaft gear		1		
2151/185	Key for ditto	1	1		
IG679/260	Pin for ditto	1	1		
IG679/261	Oil pump gear (driving)	1	1		
7151/185	Key for ditto	1	1		
(679/8 (Cerolos	Circlip for ditto		1 1		
1G679/98 1G670/590	Oil pump gear (driven) with bush Bush for oil pump driven gear	1 1	1		
1G679/520 1G679/263	G : 11 ( 5	1	ì		
1307 <i>9</i> /203	Ball for oil relief valve	1	i		
2151/319	Spring for ditto Ceased Eng. No. QPHG3150		ĵ		
AG795/117	" " " Comm. Eng. No. QPHG315		î		
4G679/20	Oil pipe (pump to filter)	1	1		
(679/41)	Bolt for ditto	2	2		
IG679/27	Oil filter assembly	1	1		
IG679/87	Oil filter container assembly	1	1		
913	Oil filter element	1	1		
IG679/88	Oil filter cover assembly	1	1		
1G489/229	Spring for ditto	1	1		
IG679/487	Felt washer for ditto	1	1		
IG679/488	Plate for element	1	1		
IG679/ <b>45</b> 6	Joint for oil filter cover	1	1		
IG679/491	Bolt for oil filter cover (short)	5	5		
1G679/492	"""""" " (long)		1		
IG679/493	Nut for ditto	6	6		
1G679/89	Relief valve for oil filter	1	1		
IG679/490	Washer for ditto		1		
1G679/90	Bolt for securing oil pipe banjos to oil filter (with		_		
********	washers)		2		
IG679/495	Washer for ditto (fibre)		2		
IG679/496	" " (copper and asbestos)		2		
(151/3	Bolt for securing oil filter		$rac{2}{2}$		
(151/28 (Ce70/21	Spring washer for ditto Oil pipe (filter to block) Ceased				
IG679/21	Oil sine (Glass de block)	1	1 1		
IG852/8 IG679/270	THE STATE OF THE STATE OF	-	1	~	
4G679/270 4G679/22	O'l ford sine (to redisable break)	-	1		
AG679/22 AG679/274	www.state.com	-	1		
IG679/548	Screw for banjo Ceased Eng. No. QPHG2649		1		
4G679/546	277 1 6 177	-	i		
4G679/346 4G679/23			1		
AG862/391	r d / k = \itu_		5		
16802/391 3679/43	Bolt for securing bearing oil feed pipe (front and		.,		
1010/ <b>3</b> 0			6		
<b>ζ679/44</b>	TD'14 ( ) '	-	2		
.UIU/##					
3.679/45	Lock plate for bolts	. 4	4		

Tourer

#### ALTERATIONS


•••••			
••••			
	·		
V	ATER PUMP, FAN AND THERMOSTAT (illustration or	1 page 32)	
MG679/402	Fan blade Ceased Eng.	i 1	1
MG679/403	" " (offset) J No. QPHG <b>241</b> 1	1 1	1
MG852/109	" " ) Comm. Eng.	1 1	1
MG852/110	" " (offset) ∫ No. QPHG <b>2412</b>	1 1	1
MG6 <b>79/28</b> 9	Distance piece for fan blades	1 1	· 1
MG679/540	Distance ring for fan blades		
	Comm. Eng. No. QPHG2412	1 1	1
X679/47	Bolt for fan blades Ceased Eng. No. QPHG2411	4 4	4
MG679/541	" " " Comm. Eng. No. QPHG2412	4 4	4
X151/21	Spring washer for ditto	4 4	4
MG679/91	Water pump assembly	1 1	1
MG679/24	Bearing bracket for water pump (bushed) Ceased	1 1	1
MG679/283	Bush for ditto Eng. No.	1 1	1
S1/17	Greaser cup for ditto J QPHG1196	1 1	1
MG679/83	Bearing bracket for water pump (bushed) Comm.	1 1	1
MG679/473	Bush for ditto Eng. No.	1 1	1
S1/18	Oiler for ditto J QPHG1197	1 1	1
MG679/286	Water pump spindle Ceased Eng.	1 1	1
MG679/297	Water pump rotor No. QPHG1196	1 1	1
MG679/509	Water pump spindle Comm. Eng.	1 1	1
MG735/281	Water pump rotor No. QPHG1197	1 1	1
P151/272	Taper pin for ditto	1 1	1
X151/12 Vezo/46	Nut for water pump spindle	1 1	1
X679/46 MC c70/900	Washer for ditto	1 1	1
MG679/290	Fan pulley	1 1	1
P151/185	Key for ditto	1 1	1
MG679/291 MC679/202	Felt dust excluding washer for spindle (front)	1 1 1 1	1 1
MG679/292 MG679/293	Retaining cover for ditto		1
X679/48	Bearing for fan spindle	1 1	i
MG679/294	That is a second of the second	1 1	1
MG679/295	13 4 1 1 1 6 13 14 16 13 1	1 1	1
MG679/296	TO 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1	i
MG679/298	Gland packing for water pump	1 1	1
MG679/299	Cover for ditto (rear)   Ceased Eng.	1 1	i
MG679/300	Gland for water pump No. QPHG1196	i i	î
P151/549	Key for ditto	i i	i
MG679/301	Spring for water pump gland	i i	1
MG679/476	Seal for water pump spindle		
1.100.0,110	Comm. Eng. No. QPHG1197	1 1	1
MG679/477	Spring for water pump seal		-
/ -	Comm. Eng. No. OPHG1197	1 1	1
	Ceased Eng. No. OPHG1692		-
MG679/513	Spring for water pump seal	1 1	1
MG679/514	Collar for ditto Comm. Eng.	î î	ī
MG862/51	Carbon sealing washer No. QPHG1693	î . î	î
MG679/512	Peg for ditto	ı i	1
X679/97	Circlip for water pump spindle	=	_
•	Comm. Eng. No. QPHG1197	1 1	1
MG679/302	Joint for water pump body	1 1	1
X151/30	Bolt for ditto	2 2	2
X827/352	Extension nut for ditto	2 2	2
X151/15	Spring washer for ditto	4 4	4
MG <b>679/303</b>	Connecting pipe to water pump	1 1	1
MG679/304	Hose for ditto	1 1	1
A1215	Clip for ditto	2 2	2
A853	Thermostat complete	1 1	1
A853/102	Elbow for thermostat	1 1	1
A85 <b>8</b> /100	Joint for ditto	1 1	1
A853/101		2 2	<b>2</b>






Part No.	MD)	DESCRIPTION				Saloon	No. Used Tourer	Fo
AC eroloor	Taint for	thermestat body						
MG679/305 X151/16		thermostat body ecuring thermostat	•••	• • • •	•••	$rac{1}{2}$	$rac{1}{2}$	2
X151/16 X151/15		sher for ditto	•••	•••		$\frac{2}{2}$	$\tilde{\tilde{2}}$	- 2
IG679/306		ose for thermostat				ĩ	ĩ	ĵ
1216	Clip for d					$\hat{2}$	$\mathbf{\hat{2}}$	2
IG679/72		pipe with studs				1	1	1
<b>X151/4</b> 5	Stud for	ditto				2	2	5
IG679/308		water outlet pipe	•••			1	1	
<b>ξ151/30</b>	Bolt for v	water outlet pipe (sh		•••	• • •	2	2	
£679/50	.""		ng)	•••	• • •	2	$\frac{2}{4}$	:
K151/15 AG679/549		isher for ditto t for fan and dynan	 10		•••	4 1	4 1	
· ·		ALTERA	TIONS					
		CIUTCH DI	ETAII S					
IG <b>67</b> 9/25	Clutch cover-	GLUTCH DI Dlate complete	LIAILS			1	1	
IG679/312		for clutch springs		• • • •		15	15	]
ζ679/51		securing clutch cov		•••		12	13 12	
X151/15		asher for ditto				$\frac{12}{12}$	12	
IG679/48		e plate assembly	•••	• • •		1	1	
(G679/315	Clutch sp					15	15	
1G <b>679</b> /316		her for clutch cover				1	1	
IG <b>679</b> /317		rust race				1	1	
<b>4679/53</b>	Nut for c	litto	•••	• • •		1.	1 .	
IG <b>679/67</b>		plate assembly with		inserts	• • • •	1	. 1	
X151/40		rts for clutch driven		• • •		56	56	
AG679/553		ing for clutch centre	· · · ·	•••	• • •	_	As requir	ed
AG679/321	Clutch wi	thdrawal shaft O/S	•••	• • •	• • • •	1	1	
AG679/322	() ()	", "N/S	•••	• • •	• • • •	1	1	
4G679/323 Vezo/55	Clutch fo		•••	•••	• • • •	1 1	1	
X679/55 X679/56	Key for e	-14-1- f1	•••	•••	• • •	$\frac{1}{2}$	$egin{array}{c} 1 \ 2 \end{array}$	
MG679/324		perating lever	• • • •			ī	1	
X151/8	Key for		• • • • • • • • • • • • • • • • • • • •			i	1	
X151/25		for ditto				1	1	
564/10		perating rod		•••		î	1	
662/1		for ditto				î	î	
72/2		spring for clutch op				1	1	
S105/3		nut for ditto	•			1	1	
547/5	Clevis pir	on (operating rod to l	ever)	• • •		1	1	
MG660/2	Clutch pedal				• • •	1	1	
MG <b>660/101</b>		clutch pedal	•••	• • • •	• • •	1	1	
MG660/102		clutch pedal (steel)		•••		1	1	
X151/3		t for ditto	• • • •	•••	• • • •	1	1	
568/9 500/9		clutch pedal (rubber)	• • •	•••	• • •	1	1	
590/2 510/18	Shaft for		•••	•••	•••	1 1	1 1	
810/18 898/7		asher for ditto sher for ditto	•••	• • • •	•••	1	1	
881/4		ew for pedal shaft			• · · ·	i	í	
573/2		oring for clutch peda			• • • •	î	i	
544/ <b>2</b> 9		racket for ditto	•••••			î	î	
544/128		or clutch pedal retu	rn spri	ng				
200/20	TD 11 C			No. SA		1	1	
833/53 80/0	Bolt for		···	• • •	• • •	1	1 1	
868/8 869/1		excluder for clutch property and plate for ditto	edai	•••	• • •	1 1	1	
	- 6	ALTERA	rions					
					• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·		
				************		· · · · · · · · · · · · · · · · · · ·		


Part No.	DESCRIPTION		N	MB			No. Used		
1 410 147.								Tourer	For son
		EARBOX DETA	ILS	SYNCH	ROMES	SH)			
MG679/344	Clutch ho	using		•••		<b>.</b>	1	1	]
X679/63		for ditto	• • •	• • •	• • •		1	1	]
MG679/345		clutch housing		•••	• • • •	• • •	1	1	]
X151/49		ecuring clutch			• • • •	• • • •	9	-9 9	9
X151/28 MC679/56	Gearbox casing	sher for ditto		•••	•••	•••	9 1	1	]
MG679/56 X151/45		gearbox top cov		•••	• • •		6	6	ě
X151/16	Nut for d		•••				6	6	ì
X151/15							6	6	(
X151/29	Stud for	gearbox rear co	ver	(short)		• • •	<b>2</b>	<b>2</b>	:
MG679/405	,, ,,	" "	,,	(long)	• • •	• • •	4	4	4
X151/27	Nut for d		• • •	• • •	• • •	• • •	6	6	(
X151/28		sher for ditto	• • • •	•••	•••	• • •	6	6	
X151/43 X151/44	Washer fo	g for gearbox or ditto	• • • •	•••	• • •		1 1	1 1	
P151/151		box to clutch l	 housi				10	10	1
X679/30		sher for ditto					10	10	î
MG679/73	Gearbox dipst						1	1	
MG679/78		haft with synch	rome	esh cone			1	1	
MG679/357	Constant	mesh pinion (on	first	motion	shaft)		1	1	
X679/74	Key for d			•••	• • •		1	1	
P105/112		or first motion			• • •	• • •	1	1	
P170/437	Guard for	1114	•••	• • •	• • •	• • •	1	1	
MG679/358	Plate for		• • •	•••	•••		1	1 1	
MG <b>679/35</b> 9 V 670/65	Circlip for	ate for ditto	• • •	••:			1 · 1	1	
X679/65 MG679/360		or first motion	 shaft			•••	1	i	
MG679/459	Mainshaft					•••	î	î	
MG679/362		got bearing for				•••	1	1	
2 <b>151/4</b> 33	Bearing fo	or mainshaft (ii	ıterm	rediate)	• • • •	• • • •	1	1	
$^{\circ}151/437$		mainshaft bear	ring	•	liate)		1	1 .	
MG679/363	Plate for			~···	• • •		1	1	
MG679/364		ite for ditto	•••	•••	• • • •	• • • •	1	]	
MG679/466 P151/195		ter driving gear or mainshaft (re		•••	• • •	•••	1 1	1 1	
MG679/503	Guard for		.a.,		• • • •	• • • •	1	i	:
MG679/504		er for mainshaf					ī	î	-
MG679/460		piece for mainsl					1	1	
MG679/461		sliding hub (to					1	1	
MG679/462		og (top and th					1	1	
MG679/463	Synchroni	sing cone (fema	le)				2	2	:
MG679/396		ting) for mainsl		sliding h			3	3	
AG679/464	Spring for				···		3	3	
X679/94		aining ring for d speed dog w					2	2	:
MG679/79		constant mesh g			using (		1	1	
MG679/368		mainshaft third					i	ī	:
MG679/369		ring for ditto					î	î	-
4G <b>67</b> 9/370	Thrust wa	sher for ditto					1	1	
MG679/371	Rollers for	r third speed g	ear				44	44	4
MG679/445	Locking p	late for third s	$\mathbf{peed}$	mainsha	ift bus	h	1	1	
£679/67		circlip for ditte		• • •	• • •	• • •	1	1	
/IG679/446		or locking plate		• • •	• • •	• • •	1	1	
AG679/447	Spring for			***		•••	1	1 1	
4G <b>679/85</b> 4G <b>67</b> 9/ <b>52</b> 6		and second sp shaft flange	į		-	• • •	1 1	1	
X151/10	Nut for d			•••			i	î	
X679/70	Washer fo						ĩ	ī	
IG679/94	Gearbox rear	cover with spee					1	1	
1G679/374	Speedomet	ter pinion					1	1	
IG679/535		or ditto (bush)					1	1	
X679/68	Screw for		• • •				2	2	:
4G679/377		gearbox rear co		• • •	• • •		1	1	
AG679/406		ar steady brack		• • •	• • •	• • •	1	1	
AG679/379 8679/75	Layshaft	crew for ditto	• • •			•••	1	1	
X679/75 X151/15		screw for ditto sher for ditto		•••	·	•••	1 1	1 . 1	
AG679/451		first speed gear				•••	1	1	]
2170/427		or layshaft					$\overset{1}{2}$	$\frac{1}{2}$	:
/IG679/381		oe for ditto	• • • •		•••		ĩ	ī	
IG679/86		d and third sp					ī	1	]
1 -		fourth speed ge					ī	$\overline{1}$	]





	MD	DESCRIPTIO	N				Saloon	No. Used Tourer	Four some
X679/71	Retaining	circlip for Lay	shaft	fourth	speed g	ear	2	<b>2</b>	2
MG <b>679/75</b>		(driven) with bu	ısh		٠.,	• • •	1	1	1
MG679/385		reverse gear	•••	•••			1	. 1	1
MG679/386	Reverse s		• • •	•••	•••	• • • •	1	1	1
MG679/387	Plug for		•••	•••	•••	• • • •	1	1	1
P151/498		reverse shaft asher for ditto	•••	•••	•••	•••	1 1	1 1	1
X151/15 MG679/388		haft (first and :	···	ط) 	•••	•••	1	1	1 1
MG679/389		ork (first and s			•••		i	î	î
MG679/70	Selector s	haft (third and	four	th) (wit	h pin)		î	î	î
MG678/470	Selector f	ork (third and	fourt	h)			ī	$\bar{1}$	ĩ
MG679/471	Distance	piece for ditto		•••			1	1	1
MG679/392		haft (reverse)				• • •	1	1	1
MG679/393		ork (reverse)	• • •		For		1	1	1
MG679/394	Plunger f		• • •		use with		1	1	1
MG679/395	Spring for		•••	1	one-piec	3	1	1	1
MG679/396		reverse plunger	•••		remote		1	1	1
MG679/397 MG679/4 <b>22</b>	Spring for	r ditto ork (reverse)	•••	ر	control		1	1	1
10015/442	Sciector 1	For use with	isolar	ted rem	ote cont	rrol	1	1	1
X679/90	Screw for	selector shafts				,101	$\bar{3}$	$\hat{3}$	3
X151/17		selector shafts					š	3	3
X151/18	Spring for			•••			3	3	3
X151/17		nge interlock ba		•••	•••		<b>2</b>	2	2
P <b>151/497</b>		interlock hole	• • •				1	1	1
MG679/84	Gearbox top	cover assembly		ر			1	1	1
MG <b>679/40</b>		cover with bush		• • •			1	1	1
MG679/408		gear change co			_		<b>2</b>	2	2
MG <b>67</b> 9/ <b>43</b> 3		nge operating sl			For		1	1	1
MG679/416		nge selector leve		1	use with	i	1	1	1
P151/549	Key for o	72.4	• • •		isolated		1	1	1
X679/83 X151/8	Bolt for a	ditto asher for ditto	• • •	- 1	remote control		1 1	1 1	1 1
X151/6 MG679/41		oil filler plug		- 1	COILLIOI		1	1	1
X151/44	Washer fo						î	î	1
MG679/331		gearbox top co		}			î	i	î
			•••••				· · · · · · · · · · · · · · · · · · ·		
									•••••
<b>GEAR</b> MG679/81 MG679/50 MG679/408	RBOX REMOTE Gearbox remo Gearbox remo Bush for	CONTROL (ON te control assemte control housing remote control for remote control to the control contro	IE-PI ibly ing w shaft	ECE TY	'PE) (illu  hes 	ustra  	tion on 1 1 2	page 31) 1 1 2	1 1 2
GEAR MG679/31 MG679/50 MG679/408 X679/76	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug	control (on te control assem te control housi remote control for remote con	IE-PI Ibly ing w shaft atrol	vith bus	<b>/PE</b> ) (illumbes)	ustra  	tion on 1 1 2 1	page 31) 1 1 2 1	1 1 2 1
<b>GEAR</b> MG679/31 MG679/50 MG679/408 X679/76 X679/77	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for	control (on te control assem te control house remote control for remote con change speed le	IE-PI Ibly ing w shaft atrol ever	vith bust housing	'PE) (illu  hes  	ustra   	tion on 1 1 2 1 2	page 31) 1 1 2 1 2	1 1 2 1 2
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for	control (on te control assem te control housi remote control for remote con change speed le oil filler plug	IE-PI Ibly ing w shaft atrol	vith bus	<b>/PE</b> ) (illumbes)	ustra  	tion on 1 1 2 1	page 31) 1 1 2 1	1 1 2 1 2 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 X151/44	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo	control (on te control assem te control housi remote control for remote con change speed le oil filler plug	IE-PI bly ing w shaft atrol ever 	vith bust housing	'PE) (illumbes) (illum	ustra   	tion on 1 1 2 1 2 1	page 31)  1  1  2  1  2  1  2  1	1 1 2 1 2 1 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 X151/44 MG679/410	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo	control (on the control assemble to control house remote control for remote cor change speed leoil filler plug or ditto peed lever	IE-PI  ibly ing w shaft atrol ever	vith bust housing	'PE) (illumbes	ustra   	tion on 1 1 2 1 2 1 2 1	page 31)  1  2  1  2  1  1  1  1  1  1  1  1  1	1 1 2 1 2 1 1 1
GEAR AG679/31 AG679/50 AG679/408 X679/76 X679/77 AG679/41 X151/44 AG679/410 AG679/505	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox of Washer for Change sp Knob for	te control assemente control house remote control for remote cor change speed leoil filler plug or ditto peed lever	iE-PI ibly ing w shaft atrol ever	vith bust housing	/PE) (illumber) (illum	ustra   	tion on 1 1 2 1 2 1 1 1	page 31) 1 1 2 1 2 1 1 1 1 1	1 1 2 1 2 1 1 1
GEAR MG679/31 MG679/50 MG679/408 K679/76 K679/77 MG679/41 K151/44 MG679/410 MG679/505 K679/79	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox Washer fo Change sp Knob for Lock nut Circlip fo	te control assemente control house remote control for remote cor change speed leoil filler plug or ditto peed lever ditto for ditto r lever	iE-PI ibly ing w shaft atrol ever	vith bust housing	/PE) (illumber) (illum	   	tion on 1 1 2 1 2 1 1 1 1 1	page 31) 1 1 2 1 1 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 X151/44 MG679/410 MG679/505 X679/79 X679/80 MG679/412	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo Change sp Knob for Lock nut Circlip for Cover for	te control assemente control house remote control for remote cor change speed leoil filler plug or ditto peed lever ditto for ditto r lever change speed l	ing we shaft atrol ever ever	vith bust	/PE) (illumber) (illum	   	tion on 1 1 2 1 2 1 1 1 1 1 1	page 31) 1 2 1 2 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 X151/44 MG679/410 MG679/505 X679/79 X679/80 MG679/412 P151/520	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo Change sj Knob for Lock nut Circlip for Cover for Spring for	control (on the control assemble control assemble control house remote control of for remote conchange speed levil filler plug for ditto for ditto for ditto for ditto change speed lever change speed lever change speed lever	ing we shaft atrol ever	vith bust housing fulcrum	/PE) (illumber) (illum	ustra	tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 1 2 1 1 1 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 MG679/410 MG679/505 X679/79 X679/80 MG679/412 P151/520 MG679/426	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox of Washer for Change sp Knob for Lock nut Circlip for Cover for Spring for Cover for	control (on the control assemble to control assemble to control for remote control of for remote control of for remote control of for remote contange speed lever ditto for ditto for ditto change speed lar	ing we shaft atrol ever	vith bust housing fulcrum	/PE) (illumber) (illum	ustra	tion on 1 2 1 2 1 1 1 1 1 1 1 1	page 31) 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1	11 11 22 11 11 11 11 11
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 MG679/410 MG679/505 X679/79 X679/80 MG679/412 P151/520 MG679/426 P151/518	Gearbox remore Gearbox remore Gearbox remore Gearbox remore Gearbox of Gearbox of Washer for Change spread for Cover for Spring for Cover for Circlip for Circlip for Cover for Circlip for Circlip for Cover for Circlip for Ci	control (on the control assemble to control assemble to control house remote control for remote control for remote control for remote control for ditto peed lever ditto for ditto r lever change speed 1 r ditto change speed 1 r ditto	in the state of th	with bust housing housing fulcrum fulcrum	(inner)	ustra	tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1	page 31) 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	11 12 22 11 11 11 11 11
GEAR MG679/31 MG679/50 MG679/408 K679/76 K679/77 MG679/41 K151/44 MG679/410 MG679/505 K679/80 MG679/412 **151/520 MG679/426 **151/518 **P151/516	Gearbox remore Gearbox remore Gearbox remore Gearbox remore Gearbox of Gearbox of Change specific Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattle	te control assemente control house remote control for remote cor change speed leoil filler plug or ditto peed lever ditto for ditto r lever change speed l r ditto change speed l r ditto e spring for change for change speed l r ditto e spring for change speed e spring fo	ing we shaft atrol ever	with bust housing housing fulcrum fulcrum	(inner)	ustra	tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
GEAR MG679/31 MG679/408 K679/76 K679/76 K679/74 K151/44 MG679/410 MG679/505 K679/79 K679/80 MG679/412 P151/520 MG679/426 P151/516 MG679/413	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox of Washer for Change sp Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattl Distance	control (on the control assemble to control house remote control for remote correlations) for remote correlations of the control for remote correlation of the control for ditto for ditto change speed lar ditto change speed lar ditto e spring for chapiece for ditto	iE-PI ibly ing w shaft atrol ever ever lever ange	rith busing housing housing housing housing housing fulcrum speed le	(PE) (illumber) hes	ustra	tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1	page 31) 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1 1 1 1
GEAR MG679/31 MG679/408 K679/76 K679/76 K679/74 K151/44 MG679/410 MG679/505 K679/79 K679/80 MG679/412 P151/520 MG679/426 P151/516 MG679/413	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo Change s; Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattle Distance Anti-rattle	control (on the control assemble control assemble control house remote control of for remote conchange speed lever ditto for ditto for ditto change speed lever cha	iE-PI ibly ing w shaft atrol ever lever lever ange ever)	rith busing housing housing housing housing housing housing housing housing housing fulcrum fulcrum speed le housing for ch	(PE) (illumber) hes		tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1 1 1 1 1
GEAR MG679/31 MG679/50 MG679/408 X679/76 X679/77 MG679/41 MG679/410 MG679/505 X679/79 MG679/412 P151/520 MG679/426 P151/518 P151/516 MG679/413 MG679/414	RBOX REMOTE Gearbox remo Bush for Core plug Snug for Gearbox of Washer for Change sp Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattl Distance Anti-rattl opera	control (on the control assemble control assemble control house remote control of for remote conchange speed level of the control of the cont	iE-PI  ibly  ing w shaft  atrol  ever   ever  ever  ever  ever  ever  ever	to the control of the	rPE) (illumber) hes		tion on 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 2 1 1 1 1 1 1 1 1 1 1 1 1
GEAR MG679/31 MG679/50 MG679/408 K679/76 MG679/41 K151/44 MG679/410 MG679/505 K679/79 K679/80 MG679/412 P151/520 MG679/426 P151/518 P151/516 MG679/413 MG679/414 K679/414	RBOX REMOTE Gearbox remo Bush for Core plug Snug for Gearbox of Washer for Change sp Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattl Distance Anti-rattl opera	te control assemente control house remote control for remote corrol for remote corrol for remote corrol for ditto for ditto for ditto change speed lar ditto change speed lar ditto e spring for chapiece for ditto ditto e spring for chapiece for ditto ditto e spring for chapiece for ditto di	lE-PI by shaft atrol ever ever ange ever)	rith buss to the control of the cont	(PE) (illumber) hes		tion on 1 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 2 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	11 11 11 11 11 11 11 11 11 11 11 11 11
<b>GEAR</b> MG679/31 MG679/50	RBOX REMOTE Gearbox remo Gearbox remo Bush for Core plug Snug for Gearbox o Washer fo Change sp Knob for Lock nut Circlip for Cover for Spring for Cover for Circlip for Anti-rattl Distance Anti-rattl opera Washer fo	control (on the control assemble control assemble control house remote control of for remote control of for remote control of for remote control of for ditto on the control of the co	IE-PI Inbly ing w shaft atrol ever ever ever ever)	to the control of the	rPE) (illumber) hes		tion on 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	page 31) 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 2

MG679/416 P151/549 X679/83 X151/6 MG679/396 MG679/419 MG679/420	Selector lever Key for shaft Bolt for ditt Spring washe	t actuating				aft	1	1	1
P151/549 X679/83 X151/6 MG679/396 MG679/419	Key for shaft Bolt for ditt	t actuating							
X679/83 X151/6 MG679/396 MG679/419	Bolt for ditt				16 467 2		2	2	2
MG679/396 MG679/419	Spring washer						<b>2</b>	2	2
MG679/419			• • •			• • •	<b>2</b>	2	2
and the second second	Ball (anti-rat		ige spee	ed oper	rating s	shaft	1	1	1
MG679/420	Spring for dif		•••	• • •	• • •	•••	1	1	1
COMOJON	Plug for ditte		•••	•••	• • •	• • •	1	1	1
\$679/37 AG679/331	Washer for d Joint for rem	_	housin	ıg	•••	•••	1 1	1 1	1 1
	<b>J</b>		ERATI	_					
			• • • • • • • • • • • • • • • • • • •			· · · · · · · · · · · · · · · · · · ·	•••••		
		· · · · · · · · · · · · · · · · · · ·							
							· · · · · · · · · · · · · · · · · · ·	·····	<b></b>
•••••							• • • • • • • • • • • • • • • • • • • •		
***************************************							· · · · · · · · · · · · · · · · · · ·		
				•••••			•••••••		· · · · · · · · · · · · · · · · · · ·
ICe#0/90		REMOTE C		•			,	1	,
IG679/39 IG679/427	Gearbox remote co Change speed			• • •	•••		1	1 1	1 1
1679/77	Snug for char						1	1	. 1
IG679/428	Change speed					• • • •	î	i	ĺ
4G679/505	Knob for ditt						î	î	ĵ
(679/79	Lock nut for						1	1	1
4G <b>6</b> 79/506	Safety washer	r for change		lever			1	1	1
IG679/429	Spring for dit			• • •			1.	1	1
IG679/430	Washer for d				• • •	• • •	1	1	1
IG679/454	Circlip for dit		• • •	• • •	• • •	• • •	1	1	1
IG679/431	Gate for ditte			• • •	• • •	• • •	1	1	]
X679/85	Bolt for ditto	4	• • •	• • •	•••	•••	1	1	1
X151/6 4Cero/409	Spring washer Reverse catch		•••	•••	• • •	• • • •	1 1	1 1	1 1
4G679/423 4G679/424	Pin for ditto	_	···	• • •	•••	•••	1	1	1
IG679/497			`	Comr	 m	• • •	i	i	1
X679/101	Circlip for dit			Comm	.11.		î	i	i
AG679/425	Spring for re			<b>.</b>			î	î	ī
X679/84	Screw for dit			,,,			î	ī	ī
AG679/434	Connecting ro						-	-	_
,	1 (1)		•••			•••	1	1	1
X679/83	Bolt for ditte	(to control	shaft)	)			1	1	1
X151/6	Spring washer	r for ditto					1	1	1
MG679/92	Silentbloc for	ditto (with	housin	1g)		• • •	1	1	1
317/17	, , , ,	" …			• • • •	• • • •	1	1	1
K679/92 K679/79	Bolt for ditto Lock nut for		•••	• • •	•••	•••	3 5	3 5	3 5
2010/10	LOCK Hut for		 ERATI	ONE	***	•••	J	3	J
		ALII							•••••
••••	•••••••••••••••••			*					•••••
***************************************				••••					
***************************************									
		***************************************							
5118/3	Engine moun	ENGINE ting block	E MOU	NTING	3		4	4	4
398/8	Seating washe			nting	•••		4	4	4
	Collar for eng				• • •	•••	$\overline{4}$	4	4
S55/19	Special nut fo			g (top)	)		4	4	4
	_* .					ma + a			
855/19 8 <b>88/11</b> 8 <b>44/2</b> 8	Combined eng			r and	accele	lator	_		
\$38/11 \$44/28	Combined eng return sp	oring bracket	t		accelei		1	1	
538/11 544/28 4G692	Combined eng return sp Engine front	oring bracket steady tie o	t complet			rator	<b>2</b>	<b>2</b>	1 2
38/11 44/28	Combined eng return sp	oring bracket steady tie o steady block	t complet			•••			



. . .

...

Bolt for ditto

Nut for ditto

Master cylinder complete...

Master cylinder barrel

Spring washer for ditto

Filler cap for supply tank

Pipe (supply tank to master cylinder)

Inlet connection for ditto ...

X661/3

X661/4

X661/5

MG661/104

MG661/3

MG661/4

MG661/107

MG661/108

. . .

...

...

. . .

. . .

. . .

...

. . .

. . .

. . .

. . .

1

1

1

1

1

1

1

1

1

1

1

1

1


1


1

1

1

Part No.	(II)	DESCRIPTION		(IM)			No. Used	_
						Saloon	Tourer	Four- some
MG <b>661/1</b> 09		inlet connection				1	1	1
MG661/110	Washer f			• • • •		1	1	1.
MG <b>661/111</b>		nnection for master	cylinder	• • • •		1	1	1
MG661/102		or ditto (small)	•••	• • • •	• • •	1	1	1
MG661/112		" " (large) outlet connection	•••		• • • •	1 1	1 1	1 1
MG <b>661/113</b> MG <b>661/114</b>		or valve (rubber)				1	1	1
MG661/115		valve (rubber)				î	i	î
MG <b>661/116</b>		dy`'				1	ī	1
MG <b>661/12</b> 0		r master cylinder				1	1	1
MG <b>661/117</b>		oring for ditto	• • •	• • • •		1	1	1
MG661/118		for return spring	•••	•••	• • •	1	1	1
MG661/119		oiston (rubber) z cup for piston (rul	hbor)	•••	• • •	1 1	1 1	1 1
MG661/121 MG661/122		op in pistoir (rai				1	1	1
MG661/123		tainer for ditto				í	i	1
MG661/194		for master cylinder	•••			î	î	î
MG661/125		for master cylinder	(rubber	)		1	1	.1
548/3		for master cylinder	• • • •			1	1	1
347/5		for ditto	• • •	• • •	• • •	1	1	1
538/5 570/3		for yoke end	•••	• • •	•••	1	1	1
579/1 ACCC1/5		r master cylinder cylinder to O/S front	hoen	• • • •	•••	1 <b>1</b>	1	1
MG661/5 MG661/6	. /	cylinder to three-way		•••	• • •	1	1 1	1 1
MG661/130	Three-wa		y piece)			1	1	i
MG661/7		ay piece to N/S fron	t hose)			î	i	î
MG661/192	Front lios					$ar{2}$	$\hat{2}$	$\hat{2}$
MG661/133	Hose unio	on no			• • • •	<b>2</b>	2	2
X661/6	Nut for o			• • •	• • • •	2	2	2
X661/7	3	asher for ditto	•••	• • •	• • •	$\frac{2}{2}$	2	2
MG661/8	Rear hose	ay piece to rear hose	,	• • • •	• • •	1 1	1 1	1 1
MG661/193 MG661/133	Hose unio		•••	•••	•••	1	1.	1
X661/6	Nut for o		•••			1	î	î
X661/7		asher for ditto				î	î	ī
MG661/136		y connection for reas		• • •		1	1	1
S44/50	Bracket f					1	1	1
MG661/9		se to O/S rear wheel			• • • •	1	1	1
MG661/10		se to N/S rear wheel			•••	1	1	1
S2/40 S2/41		pipes (round centre c	ring hole	e)		$\frac{2}{6}$	$\frac{2}{6}$	$\frac{2}{6}$
82/42	""	", $(\frac{9}{32}" \text{ dia.}, \frac{3}{8}" \text{ fix}]$ ", $(\frac{3}{8}" \text{ dia.}, \frac{1}{4}" \text{ fix}]$	ng hole)	.,		2	$\frac{3}{2}$	$\frac{9}{2}$
S55/17	Distance	piece (clip to spring	pad)	•••		$\overline{2}$	${f 2}$	2
,		ALTERA	TIONS					
								• • • • • • • • • • • • • • • • • • •
								• • • • • • • • • • • • • • • • • • • •
					• • • • • • • • • • • • •			• • • • • • • • • • • • • • • • • • • •
							· · · · · · · · · · · · · · · · · · ·	
		BRAKE GEAR (F	RONT A	XLF				
MG <b>661/12</b>		anchor bracket ass	embly		vheel	2	2	2
MG661/140		in for brake-slice				$\overline{4}$	$\tilde{4}$	4
MG661/141		cam for brake-shoe				4	4	4
MG661/142	Spacing v	vasher for ditto				4	4	4
MG661/143		washer for ditto	• • •			4	4	4
MG661/144		r adjuster cam		• • •	• • •	4	4	4
MG661/145		adjuster cam	• • • •	• • •	• • •	4	4	4
MG661/146 MC661/147		adjuster cam	•••	• • •	•••	4 2	$rac{4}{2}$	4
MG661/147	Nut for o	in for brake-shoe litto		• • • •	•••	$\frac{\mathbf{z}}{2}$	2 2	$\begin{array}{c} 2 \\ 2 \end{array}$
X 663 1 /8		ntto	•••	• • •			$\frac{2}{2}$	
X661/8 X661/9	Plain was	sher for ditto (small)				7.	7.	
$\times 661/9$	Plain was	sher for ditto (small)	•••	• • • •	•••	$rac{2}{2}$	2	$\frac{2}{2}$
X661/9 X661/15	"	sher for ditto (small) " " " (large) y washer for anchor			•••			$\frac{2}{2}$
	Thackera Circlip fo	" " " (large)		•••		2	<b>2</b>	$\begin{array}{c} 2 \\ 2 \\ 2 \\ 2 \\ 2 \\ 2 \end{array}$







	<i>✓</i>			<i>←</i>			No. Used	
Part No.	MD)	DESCRIPTION	N	MB)		Saloon	Tourer	Four some
MCeel /10"	E+	hool owlinder (E						
MG661/195 MG661/149		heel cylinder (bar or front wheel cy			•••	2 4	2 4	$\frac{2}{4}$
MG661/150		spring for piston			•••	$oldsymbol{2}$	$\hat{f 2}$ .	$\hat{f 2}$
MG661/25	Crown s	pring with retain				4	4	4
MG661/153		cup for piston		,	• • •	4	4	4
MG661/154		t for wheel cylin		,	• • •	4. 4.	4 4	4 4
MG661/155 MG661/156		l for wheel cyling nnection for front		inder		2	2	2
MG661/102		for ditto (small)				$oldsymbol{ar{2}}$	$ar{f 2}$	$\frac{1}{2}$
MG661/112	,,	" " (large)				<b>2</b>	2	2
MG661/157		inlet connection		• • •	• • •	2	2	2
MG661/158		screw for wheel o	-	•••	•••	2	$egin{smallmatrix} 2 \ 2 \end{matrix}$	$\frac{2}{2}$
X661/10 X661/11		w for ditto vasher for ditto				${ 2 \atop 2}$	2	$\frac{2}{2}$
X661/12		r securing wheel				4	4	$\frac{7}{4}$
X661/13		vasher for ditto	•••			4	4	4
MG661/14	Brake-shoe (	with lining, O/S	front, N/S	rear)	•••	2	<b>2</b>	2
MG661/15		with lining, N/S				2	2	2
MG661/28	Rivets f	rake-shoe (set of or ditto	4 with rive	ets)	•••	1 set 32	$egin{array}{c} 1 & \mathrm{set} \\ 32 \end{array}$	1 set 32
X661/16 X661/14		for brake-shoe st				8	8	8
MG661/162		spring for brake-			•••	$\hat{2}$	2	2
		ALTI	ERATIONS					
		•••••						
••••	· · · · · · · · · · · · · · · · · · ·	•••••			• • • • • • • • • • • • • • • • • • • •			
***************************************		•						
		***************************************						
							*****	
******	***************************************		*******					
	DDAVE							
		DEAD DEAD	AYLE\ 611	stration	2 02 2	000 971		
MG661/18		GEAR (REAR / anchor bracket as				age 37)		
MG661/18		GEAR (REAR A anchor bracket as cylinder, brake-s	sembly O/S	less (		age 37)	1	1
MG661/18 MG661/19	Rear brake a	anchor bracket as cylinder, brake-s N/S (less wheel	ssembly 0/8 hoes and c cylinder,	less (	wheel	1		
MG <b>661/19</b>	Rear brake a	anchor bracket as cylinder, brake-s N/S (less wheel and cable)	hoes and c cylinder,	less able) brake- 	wheel -shoes	1 1	1	1
MG661/19 MG661/140	Rear brake a  Ditto  Steady	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-shoe	ssembly 0/8 hoes and c cylinder, 	less able) brake	wheelshoes	1 1 4	1 4	1 4
MG661/19 MG661/140 MG661/141	Rear brake a  Ditto  Steady J  Adjuster	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-show cam for brake-s	hoes and c cylinder,  e hoe	dess (less able) brake	wheelshoes	1 1 4 4	1 4 4	1 4 4
MG661/140 MG661/141 MG661/142	Rear brake a  Ditto  Steady J  Adjuster  Spacing	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shor cam for brake-s washer for ditto	ssembly 0/8 hoes and c cylinder, e hoe	dess (less able) brake	wheelshoes	1 1 4	1 4	1 4
MG661/19 MG661/140 MG661/141	Rear brake a  Ditto  Steady J  Adjuster  Spacing  Friction	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-show cam for brake-s	ssembly 0/8 hoes and c cylinder, e hoe	dess (less able) brake	wheelshoes	1 1 4 4 4	1 4 4 4	1 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144	Rear brake at Ditto  Steady J Adjuster Spacing Friction Spring f Cover fo	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-shor cam for brake-s washer for ditto washer for ditto or adjuster cam or adjuster cam	sembly 0/8 hoes and c cylinder, e hoe	dictions (less able) brake	wheelshoes	1 1 4 4 4 4 4	1 4 4 4 4 4	1 4 4 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/146	Rear brake a  Ditto  Steady J  Adjuster Spacing Friction Spring f Cover fo Bolt for	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shor cam for brake-s washer for ditto washer for ditto washer for ditto or adjuster cam adjuster cam	ssembly O/S hoes and c cylinder, hoe	dicess (less able) brake	wheelshoes	1 1 4 4 4 4 4	1 4 4 4 4 4 4	1 4 4 4 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/146	Rear brake a  Ditto  Steady J  Adjuster  Spacing  Friction  Spring f  Cover for  Bolt for  Anchor	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shor cam for brake-s washer for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho	seembly 0/8 hoes and c cylinder, e hoe e e	dicess (less able) brake	wheelshoes	1 1 4 4 4 4 4 4	1 4 4 4 4 4 4 2	1 4 4 4 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-s washer for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho ditto	ssembly 0/8 hoes and c cylinder, e hoe	(less able) brake	wheelshoes	1 4 4 4 4 4 4 2 2	1 4 4 4 4 4 2 2	1 4 4 4 4 4 2 2
MG661/19 MG661/140 MG661/141 MG661/143 MG661/144 MG661/145 MG661/146 MG661/147 X661/8 X661/9	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for	archor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-s washer for ditto washer for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr	ssembly 0/8 hoes and c cylinder, e hoe	dicess (less able) brake	wheelshoes	1 4 4 4 4 4 4 2 2	1 4 4 4 4 4 4 2	1 4 4 4 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shor cam for brake-shor cam for ditto washer for ditto washer for ditto adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (st. " " " (la	seembly 0/8 hoes and c cylinder, hoe e e mall) rige)	(less able) brake	wheelshoes	1 4 4 4 4 4 4 2 2	1 4 4 4 4 4 2 2 2	1 4 4 4 4 4 4 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoc cam for brake-shoc cam for brake-shoc cam for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (sray washer for anor anchor pin	ssembly 0/8 hoes and c cylinder, e hoe e e anall) arge) chor pin	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2	1 4 4 4 4 4 2 2 2 2 2 2 2	1 4 4 4 4 4 4 2 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/23 MG661/189 MG661/30	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa "Thackers Circlip f Rear wheel	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for ditto washer for ditto or adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., "," (la ay washer for anchor pin cylinder assembly	seembly 0/8 hoes and c cylinder, e hoe	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2	1 4 4 4 4 4 2 2 2 2 2 2 2	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/145 MG661/146 MG661/147 X661/8 X661/9 X661/23 MG661/189 MG661/30 MG661/195	Steady padjuster Spacing Friction Spring for Cover for Bolt for Anchor Nut for Plain was "Thacker Circlip for Rear wheel a Rear wheel a steady page 1.00 miles to the control of the contr	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for ditto washer for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho ditto (la ay washer for anchor pin cylinder assembly leel cylinder (bare	seembly 0/8 hoes and c cylinder, e hoe mall) chor pin e) e)	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2	1 4 4 4 4 4 2 2 2 2 2 2 2 2	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189 MG661/195 MG661/195 MG661/149	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain was "Thackers Circlip f Rear wheel (Rear wheel Piston for Pi	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-shor cam for brake-shor cam for ditto washer for ditto washer for ditto adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (sr. " " (law washer for anor anchor pin cylinder assembly leel cylinder (bare or rear wheel cylinder cy	seembly 0/8 hoes and c cylinder, e hoe mall) chor pin e) e) inder e) e) inder	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2	1 4 4 4 4 2 2 2 2 2 2 2 2 4	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189 MG661/189 MG661/149 MG661/149	Steady J Adjuster Spacing Friction Spring f Cover fo Bolt for Anchor Nut for Plain wa "Thacker Circlip f Rear wheel of Reserver for Return f	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-swasher for ditto washer for ditto or adjuster cam pin for brake-sho ditto asher for ditto (single as washer for anor anchor pin cylinder assembly leel cylinder (bare or rear wheel cylspring for ditto	seembly 0/8 hoes and c cylinder, e hoe mall) rarge) chor pin e e e e e e e e	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2	1 4 4 4 4 4 2 2 2 2 2 2 2 2	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189 MG661/195 MG661/195 MG661/149	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa Thackers Circlip f Rear wheel of Rear wheel of Returns Crown s	anchor bracket as cylinder, brake-s N/S (less wheel and cable) pin for brake-shor cam for brake-shor cam for ditto washer for ditto washer for ditto adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (sr. " " (law washer for anor anchor pin cylinder assembly leel cylinder (bare or rear wheel cylinder cy	seembly 0/8 hoes and c cylinder, e hoe mall) rarge) chor pin e e e e e e e e	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2	1 4 4 4 4 2 2 2 2 2 2 2 4 2	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/153 MG661/150 MG661/153 MG661/153 MG661/153 MG661/153	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain was "Thacker Circlip f Rear wheel Rear wheel Return Crown s Rubber End boo	anchor bracket as cylinder, brake-s cylinder, brake-s (less wheel and cable) bin for brake-shor cam for brake-shor cam for ditto washer for ditto washer for ditto or adjuster cam adjuster cam adjuster cam pin for brake-sho ditto (la ay washer for anchor pin cylinder assembly heel cylinder (bare or rear wheel cyl spring for ditto pring with retain cup for piston of the cylinder cylinder or to wheel cylinder to wheel	seembly 0/8 hoes and c cylinder, e hoe mall) chor pin es et chor pin et et der (rubbes	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4 4 4	1 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189 MG661/189 MG661/195 MG661/150 MG661/150 MG661/153 MG661/153 MG661/154 MG661/154 MG661/154	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa "Thacker Circlip f Rear wheel of Rear wheel of Return f Return f Return s Rubber End boo	anchor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shor cam for brake-shor cam for brake-shor cam for ditto washer for ditto or adjuster cam pin for brake-shor ditto asher for ditto (sing may washer for anor anchor pin cylinder assembly leel cylinder (barrour ear wheel cylinder bring with retain cup for piston by for wheel cylinder differ wheel cylinder differ wheel cylinder differ wheel cylinder differ wheel cylinder for wheel cylinder cylinder for wheel cylinder cylinder for wheel cylinder for wheel cylinder cylinder for wheel cylinder cylinder for wheel cylinder c	seembly 0/8 hoes and c cylinder, e hoe mall) ee chor pin einder (rubbeder	(less able) brake-	wheelshoes	1 1 4 4 4 4 4 2 2 2 2 2 2 2 4 4 4 4 4 4	1 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4	1 4 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/189 MG661/189 MG661/150 MG661/150 MG661/153 MG661/153 MG661/153 MG661/155 MG661/155 MG661/155	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa Thackers Circlip f Rear wheel of Rear wheel of Return: Crown s Rubber End boo Push roo	anchor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto washer for ditto or adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., "," (la ay washer for anchor pin cylinder assembly leel cylinder (barror rear wheel cylinder ditto pring with retain cup for piston of for wheel cylind for wheel cylind for wheel cylind for wheel cylinder for wheel cylinder cyl	seembly 0/8 hoes and c cylinder, e hoe mall) ee mall) erge) einder chor pin einder (rubbeder wheel cylin	(less able) brake	wheelshoes	1 1 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4 4 4	1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	1 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/145 MG661/145 MG661/189 X661/8 X661/8 X661/8 MG661/153 MG661/159 MG661/165	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa Thackers Circlip f Rear wheel of Rear wheel of Return: Crown s Rubber End boo Push roo	archor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., "," (la ay washer for anchor pin cylinder assembly neel cylinder (barror rear wheel cyling for ditto pring with retain cup for wheel cylind for wheel cylind for wheel cylind for wheel cylind for ditto (small)	seembly O/8 hoes and c cylinder, e hoe mall) chor pin e) inder e) der (rubber der wheel cylin wheel cylin	(less able) brake	wheelshoes	1 1 4 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4 4	1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	1 4 4 4 4 4 4 4 4 4 2 2 2 2 2 2 4 2 4 4 4 4 4 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/153 MG661/159 MG661/150 MG661/153 MG661/153 MG661/154 MG661/154 MG661/154 MG661/155 MG661/156 MG661/102 MG661/102 MG661/112	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain was "Thacker Circlip f Rear wheel company of Return scrown sand Rubber End boo Push rounlet compassion of the compassion of the Return scrown sand sand some sand s	anchor bracket as cylinder, brake-s cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto washer for ditto washer for ditto or adjuster cam adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (si , , , , (la ay washer for anchor pin cylinder assembly leel cylinder (bare or rear wheel cylinder or rear wheel cylinder or piston of for wheel cylind for wheel cylind for wheel cylind for wheel cylind for ditto (small) , , (large)	seembly O/8 hoes and c cylinder, e hoe mall) chor pin e) der (rubber der wheel cylin	(less able) brake	wheelshoes	1 1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2	144444222222222424442222	1 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 4 2 4 4 4 4 4 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/145 MG661/145 MG661/189 X661/8 X661/8 X661/8 MG661/153 MG661/159 MG661/165	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain was "Thacker Circlip f Rear wheel Rear wheel Rear wheel Rear wheel Rear wheel Crown s Rubber End boo Push roo Inlet co Washer "Bolt for	archor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., "," (la ay washer for anchor pin cylinder assembly neel cylinder (barror rear wheel cyling for ditto pring with retain cup for wheel cylind for wheel cylind for wheel cylind for wheel cylind for ditto (small)	seembly O/8 hoes and c cylinder, e hoe mall) chor pin er der (rubber der wheel cylin	(less able) brake	wheelshoes	1 1 4 4 4 4 4 2 2 2 2 2 2 2 2 4 4 4 4 4	1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	1 4 4 4 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 4 2 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/8 X661/23 MG661/153 MG661/159	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa Thackers Circlip f Rear wheel of Rear wheel of Return of Return of Return of Return of Push roof Inlet cool Washer	anchor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., ","," (la ay washer for anchor pin cylinder assembly neel cylinder (barror rear wheel cylinder pring with retain cup for wheel cylind for wheel cylind for wheel cylind for wheel cylind for ditto (small) ,"," (large) inlet connection screw for wheel cylinder	seembly 0/8 hoes and c cylinder, e hoe e mall) chor pin e e e chor pin er er chor pin er er chor pin er er chor pin chor pin chor pin er er cylinder	(less able) brake	wheelshoes	1 1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2 2	144444422222222224244442222222222222222	1 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/159	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa "Thackers Circlip f Rear wheel a Rear wheel a Rear wheel a Return of Crown s Rubber End boo Push rou Inlet con Washer Bolt for Bleeder Set scree	anchor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., "," (la ay washer for anchor pin cylinder assembly leel cylinder (bareor rear wheel cylinder or rear wheel cylinder for wheel cylind for wheel cylind for wheel cylind for wheel cylind for wheel cylinds for ditto (small) "," (large) inlet connection screw for wheel w for bleeder screwasher for ditto	seembly 0/8 hoes and c cylinder, e hoe mall) chor pin er der (rubber der wheel cylin cylinder ew cylinder	(less able) brake	wheelshoes	1 1444444 222222424444 2222222222222222	144444222222222444442222222222222222222	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 2 4 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/144 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/15 MG661/15 MG661/15 MG661/15 MG661/15 MG661/15 MG661/155 MG661/11 MG661/158 X661/10 X661/11 X661/11	Steady padjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain was "Thacker Circlip f Rear wheel company of Return Crown s Rubber End boo Push rounded to Washer "Bolt for Bleeder Set screen Spring ventures and post of the set screen spring ventures and post of the set screen spring ventures and post of the set screen spring ventures v	anchor bracket as cylinder, brake-s Cylinder, brake-s (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto washer for ditto or adjuster cam adjuster cam adjuster cam pin for brake-sho ditto (laay washer for anchor pin cylinder assembly leel cylinder (bare or rear wheel cylinder or rear wheel cylinder for wheel cylind for wheel cylinder for ditto (small) " (large) inlet connection screw for wheel cylinder washer for ditto (small) where the connection for rear for ditto (small) where the connection screw for wheel cylinder screw for wheel cylinder for ditto (small) where the connection screw for wheel cylinder for ditto (small) where the connection screw for wheel cylinder for ditto (small) where for ditto we for securing where the cylinder for ditto we for securing wheel cylinder for ditto we for securing where the cylinder for ditto we for securing wheel cylinder for ditto we for securing where the cylinder for ditto we cylinder for ditto we for di	seembly O/8 hoes and c cylinder, e hoe mall) chor pin er der (rubber der wheel cylinder cylinder ew heel cylinder	(less able) brake	wheelshoes	1 1444444222222424444422222222222222222	144444422222222424442222222222222222222	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 2 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/153 MG661/195 MG661/150 MG661/150 MG661/155 MG661/153 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/11 X661/11 X661/11	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa "Thacker Circlip f Rear wheel of Rear wheel of Return: Crown s Rubber End boo Push roo Inlet con Washer Bolt for Bleeder Set scre Spring v Set scre	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto washer for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (sr " " " (law ay washer for anor anchor pin cylinder assembly neel cylinder (barror rear wheel cylinder (barror pring with retain cup for piston but for wheel cylinder ditto (small) " " (large) inlet connection for rear for ditto (small) " " (large) inlet connection screw for wheel cylinder of ditto wheel cylinder connection screw for wheel cylinder cylinde	seembly 0/8 hoes and c cylinder, e hoe mall) chor pin chor pin er chor pin cho	(less able) brake	wheelshoes	1 1444444444222222222222222222222222222	144444422222222242444422222222222222222	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 2 4 4 4 4 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/145 MG661/189 X661/8 X661/8 X661/8 MG661/153 MG661/159 MG661/158 MG661/111 X661/11 X661/11 X661/11 X661/13 MG661/13	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa Thackers Circlip f Rear wheel of Rear wheel of Returns Crown s Rubber End boo Push roo Inlet cool Washer Bolt for Bolt for Returns Crown s Rubber End boo Push roo Inlet cool Washer	anchor bracket as cylinder, brake-s Cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto or adjuster cam adjuster cam adjuster cam pin for brake-shoe ditto asher for ditto (sr., ","," (la ay washer for anchor pin cylinder assembly neel cylinder (barror rear wheel cylinder pring with retain cup for wheel cylind for wheel cylind for wheel cylind for wheel cylind for wheel cylinder competition for rear for ditto (small) ",", (large) inlet connection screw for wheel wheel cylinder connection for rear for ditto (small) wheel cylinder connection for rear wheel cylinder for ditto (small) wheel cylinder connection for rear for ditto (small) wheel cylinder connection for car for ditto wheel cylinder connection for car for ditto wheel cylinder for ditto (with lining, O/S)	seembly O/8 hoes and c cylinder, e hoe mall) chor pin er der (rubber der wheel cylinder ew cylinder ew front, N/S	(less able) brake	wheelshoes	1 1444444222222244444422222222222222222	144444442222222222444442222222222222222	1 4 4 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 2 2
MG661/19 MG661/140 MG661/141 MG661/142 MG661/143 MG661/144 MG661/145 MG661/147 X661/8 X661/9 X661/15 X661/23 MG661/153 MG661/195 MG661/150 MG661/150 MG661/155 MG661/153 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/155 MG661/11 X661/11 X661/11	Steady J Adjuster Spacing Friction Spring f Cover for Bolt for Anchor Nut for Plain wa "Thacker Circlip f Rear wheel of Rear wheel of Return of Crown s Rubber End boo Push roo Inlet con Washer Bolt for Bleeder Set scree Spring was Brake-shoe	anchor bracket as cylinder, brake-s N/S (less wheel and cable) bin for brake-shoe cam for brake-shoe cam for brake-shoe cam for brake-shoe cam for ditto washer for ditto washer for ditto or adjuster cam adjuster cam pin for brake-sho ditto asher for ditto (sr " " " (law ay washer for anor anchor pin cylinder assembly neel cylinder (barror rear wheel cylinder (barror pring with retain cup for piston but for wheel cylinder ditto (small) " " (large) inlet connection for rear for ditto (small) " " (large) inlet connection screw for wheel cylinder of ditto wheel cylinder connection screw for wheel cylinder cylinde	seembly 0/8 hoes and c cylinder, hoe hoe mall) rge) chor pin et der (rubber der wheel cylinder ew front, N/S front, O/S	(less able) brake	wheelshoes	1 1444444444222222222222222222222222222	144444422222222242444422222222222222222	1 4 4 4 4 4 4 2 2 2 2 2 2 2 2 2 4 2 4 4 4 4 2

Part No. X661/14 MG661/162 MG661/21	10.11.21			IMIL				
MG661/162	100	DESCRIPTION				Saloon	Tourer	Fou som
MG661/162	Washer	for brake-shoe stead	r nina			8	8	8
		spring for brake-sho		•••	•••	${f 2}$	2	2
		operating lever as		0.15	and	-	2	
10001/21		ake)	•	(II	and	1	1	1
IG661/22		N/S (hand brake)			•••	1	i	ì
IG661/171		1111 010	• • •		•••	1	i	i
$\frac{16001}{172}$	Spring 1	or ditto U/S				1	i	1
661/17	Washer	for brake-shoe opera		er nivot		$\dot{f 2}$	$\frac{1}{2}$	2
3661/18	Slotted	nut for ditto			Pitt	$\frac{5}{2}$	$\frac{2}{2}$	2
IG661/173		g plate for brake-s			ver	~	-	•
10001/110		ush rod	_			<b>2</b>	<b>2</b>	2
IG661/174	Bolt for					2	$\frac{1}{2}$	2
661/19		nut for ditto		•••	•••	$ar{f 2}$	$\bar{2}$	2
IG661/175		ring washer for ditto			•••	$ar{2}$	$ar{f 2}$	5
lG661/26		complete O/S				1	ī	]
IG661/27		", N/S				ī	î	]
IG661/182	Pin for	brake cable fork end				$\dot{2}$	$\overline{2}$	2
IG661/183	Bracket	for brake cable (on	back p			$ar{2}$	$ar{2}$	2
IG661/184		r brake cable bracke				$ar{2}$	$ar{f 2}$	5
IG661/185	Cap for			• • •		$\overline{2}$	$ar{f 2}$	
661/21	Bolt for			• · •	• • • •	$oldsymbol{ar{4}}$	4	-
661/22	Nut for			• • •	• • • •	4	4	- 4
3661/11		vasher for ditto			• • • •	4	4	4
116/1		able stop bracket			• • • •	$ar{f 2}$	${f  ilde{2}}$	2
72/2		spring for brake ca		•••		$ar{2}$	$\frac{1}{2}$	2
105/2		nut for brake cable		•••		$\frac{1}{2}$	$ar{2}$	2
2/42		brake cables (front)				$\bar{2}$	$\frac{2}{2}$	- 2
49/12		clip for brake cables		•••		-	-	_
IG670	Accelerator o	CONTROLS (illustra				3	1	
IG670 64/11		ross shaft assembly	• • •	• • • • • • • • • • • • • • • • • • • •	•••	1	1	
64/11	Accelera	tor pedal stem	•••			1	1	3
$\frac{64}{11}$	Accelera Securing	tor pedal stem bolt for ditto	•••		•••	1 1		]
64/11 61/2 47/7	Accelera Securing Sleeve fo	tor pedal stem bolt for ditto or accelerator pedal	  roller		•••	1	1	] ]
64/11 61/2 47/7 122/1	Accelera Securing Sleeve fo Accelera	tor pedal stem bolt for ditto or accelerator pedal tor pedal tor pedal roller	roller			1 1 1	1 1 1	] ! !
64/11 $61/2$ $47/7$ $122/1$ $44/53$	Accelera Securing Sleeve fo Accelera Bracket	cross shaft assembly tor pedal stem bolt for ditto or accelerator pedal tor pedal roller for accelerator peda	roller			1 1 1 1	1 1 1 1	] ] ] ]
64/11 61/2 47/7 122/1 44/53 73/4	Accelera Securing Sleeve fo Accelera Bracket Spring fo	tor pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal	roller			1 1 1 1 1	1 1 1 1	] ] ] ]
64/11 61/2 47/7 122/1 44/53 73/4 43/3	Accelera Securing Sleeve fo Accelera Bracket Spring fo Accelera	tor pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator peda or accelerator pedal tor pedal	roller			1 1 1 1	1 1 1 1 1	; ; ; ; ;
64/11 $61/2$ $47/7$ $122/1$ $44/53$ $73/4$ $43/3$ $62/5$	Accelera Securing Sleeve fo Accelera Bracket Spring fo Accelera Fulcrum	tor pedal stem bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal tor pedal pin for ditto	roller !			1 1 1 1 1 1 1	1 1 1 1 1 1 1	; ; ; ;
64/11 $61/2$ $47/7$ $122/1$ $44/53$ $73/4$ $43/3$ $62/5$ $73/3$	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal tor pedal pin for ditto spring for accelerator	roller l			1 1 1 1 1 1 1	1 1 1 1 1 1 1 1	! ! ! ! ! ! !
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9	Accelera Securing Sleeve fo Accelera Bracket Spring fo Accelera Fulcrum Return s Accelera	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal tor pedal pin for ditto spring for accelerator tor control rod	roller			1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1	! ! ! ! ! ! !
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/8 64/9 16/5	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return s Accelera Ball join	cross shaft assembly tor pedal stem bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal tor pedal pin for ditto spring for accelerator tor control rod tfor ditto	roller			1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 1 2
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17	Accelera Securing Sleeve fc Accelera Bracket Spring fc Accelera Fulcrum Return s Accelera Ball join	to pedal stem bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal or accelerator pedal tor pedal pin for ditto pin for ditto spring for accelerator tor control rod tt for ditto colluder for accelerator	roller l r pedal	     	   	1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 2 2
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4	Accelera Securing Sleeve fo Accelera Bracket Spring f Accelera Fulcrum Return Accelera Ball join Fume ex Retainer	to pedal stem bolt for ditto bor accelerator pedal tor pedal roller for accelerator pedal tor pedal roller for accelerator pedal tor pedal pin for ditto spring for accelerator tor control rod to for ditto cluder for accelerator for ditto	roller  I roller  pedal	     Comm. (	   	1 1 1 1 1 1 1 1 1 1 2	I I I I I I I I I I I I I I I I I I I	1 1 1 1 1 1 1 2 2
64/11 61/2 47/7 122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4 828	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return Accelera Ball join Fume ex Retainer	to pedal stem bolt for ditto bolt for ditto bolt for ditto bor accelerator pedal tor pedal roller for accelerator pedal tor pedal pin for ditto spring for accelerator tor control rod tt for ditto cluder for accelerator for ditto control wire	roller	     	   	1 1 1 1 1 1 1 1 1 2 1	1 1 1 1 1 1 1 1 1 1 2	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 68/4 828 827	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return Accelera Ball join Fume ex Retainer Throttle Mixture	both for ditto  control wire	roller	    Comm. (	      	1 1 1 1 1 1 1 1 1 2 1 1 1	1 1 1 1 1 1 1 1 2 1	1 1 1 1 1 1 2 2 1
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4 828 8.827	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return son Accelera Ball join Fume ex Retainer Throttle Mixture Starter	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal accelerator pedal tor pedal pin for ditto pin for ditto spring for accelerator tor control rod tt for ditto colluder for accelerator for ditto control wire control wire pull wire	roller	Comm. (No. SA0:	      	1 1 1 1 1 1 1 1 1 2 1	1 1 1 1 1 1 1 1 1 2 1 1	1 1 1 1 1 1 2 2 1
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4 828 8.827	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return son Accelera Ball join Fume ex Retainer Throttle Mixture Starter	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal tor pedal pin for ditto pin for ditto pin for ditto spring for accelerator tor control rod cluder for accelerator for ditto cluder for accelerator for ditto control wire control wire control wire for throttle and ini	roller  I  pedal )	Comm. (No. SAO)	         	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 2 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4 .828 .827 .826 27/43	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return son Accelera Ball join Fume ex Retainer Throttle Mixture Starter	to pedal stem bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal tor pedal roller pin for ditto pin for ditto spring for accelerator tor control rod tot for ditto cluder for accelerator for ditto control wire control wire (for throttle and ini Cea	roller  l  pedal   xture cosed Ch.	Comm. (No. SAO)	         	1 1 1 1 1 1 1 1 2 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	3 3 3 3 3 3 3 3 3 3 3 3
64/11 61/2 47/7 122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 68/17 68/17 828 .827 .826 27/43	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return Accelera Ball join Fume ex Retainer Throttle Mixture Starter Ferrule Ditto	both for ditto  both for ditto  both for ditto  bor accelerator pedal tor pedal roller  for accelerator pedal tor pedal  pin for ditto  spring for accelerator tor control rod  to for ditto  control wire  control wire  for throttle and in Cea  Cor	roller  l  pedal   xture coused Ch. nm. Ch.	Comm. (Control with No. SAC	         	1 1 1 1 1 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 68/17 68/4 828 827 826 27/43 27/42 2/51	Accelera Securing Sleeve fe Accelera Bracket Spring fe Accelera Fulcrum Return s Accelera Ball join Fume ex Retainer Throttle Mixture Starter Ferrule Ditto Clip for	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal or accelerator pedal tor pedal pin for ditto pin for ditto pin for ditto to control rod colluder for accelerator for ditto control wire control wire (for throttle and ini Cea Cor throttle and starter	roller  l  pedal )  xture control	Comm. (Control with No. SAC	         	1 1 1 1 1 1 1 1 1 2 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
64/11 61/2 47/7 1122/1 44/53 73/4 43/3 62/5 73/3 64/9 16/5 68/17 69/4 828 8.827 .826 27/43	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return son Accelera Ball join Fume ex Retainer Throttle Mixture Starter son Ferrule  Ditto Clip for Pin for	to pedal stem boly tor pedal stem bolt for ditto bolt for ditto for accelerator pedal tor pedal roller for accelerator pedal tor pedal for accelerator for ditto for d	roller  l  pedal   xture cosed Ch. nm. Ch. control	Comm. (No. SA0:	         	1 1 1 1 1 1 1 1 2 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
64/11 61/2 447/7 1122/1 44/53 73/4 43/3 62/5 63/3 64/9 16/5 68/17 68/17 68/4 828 827 826 27/43 27/42 2/51	Accelera Securing Sleeve for Accelera Bracket Spring for Accelera Fulcrum Return son Accelera Ball join Fume ex Retainer Throttle Mixture Starter son Ferrule  Ditto Clip for Pin for	to pedal stem bolt for ditto bolt for ditto or accelerator pedal tor pedal roller for accelerator pedal tor pedal pin for ditto spring for accelerator tor control rod tot for ditto cluder for accelerator for ditto control wire control wire (for throttle and mi Cea Cor throttle and starter carburetter levers spring for slow runn	roller  l  pedal   pedal   xture coused Ch. nm. Ch. control ing con	Comm. (No. SA0:		1 1 1 1 1 1 1 1 1 2 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

Part No.	MD	DESCRIPTION		MD)		No. Used	
	الالك	DESCRIPTION			Saloon	Tourer	Four- some
MC eoz		EERING GEAR (illu		n on page 38)			
MG <b>697</b>	oteering gear	unit complete (less Cea		No. SA0902	1	1	1
MG844	Ditto (	less wheel) (telescop Cor		. No. SA0903	1	1	1
MG667/1	Steering box	(bushed)			1	1	1
MG667/103 MG697/1	Bush for Inner column	steering box		No. SA0902	$rac{2}{1}$	$rac{2}{1}$	$rac{2}{1}$
MG708/1		(telescopic) Con	nm. Ch.	No. SA0903	1	1	1
MG844/1	Ditto			No. SA2751 No. SA2752	1	1	1
MG <b>667/106</b>		with balls			$ar{2}$	2	$\bar{2}$
MG667/107	Ball cup				2	2	2
MG667/101		nd cover for steering			1	1	1
MG667/110 MG708/102				No. SA0902 . No. SA0903	1 1	1 1	1 1
		∫ Cea	sed Ch.	No. SA2558	•	-	•
MG708/105	Bottom (	end cover for steerin		. No. SA0903	1	1	1
MG708/106	Olive for		) (	Comm. Ch.	i	i	i
MG <b>708/107</b>	Nut for	ditto	J 1	No. SA2559	1	1	1
MG667/108		bottom end cover			1	1	1
MG667/109		for junction box		N. CA0000	1	1	1
MG667/111 MG708/103	• Outer tu			No. SA0902 No. SA0903	1 1	1 1	1 1
10100/100	,, ,,			No. SA2751	1	1	
MG <b>844/2</b>	,,	(with socket) Co			1	1	1
MG667/112		or outer tube			1	1	1
MG667/113	Packing	plate for outer tube			1	1 .	, 1
MG667/114 MG667/115		ditto (.0024")				As requir	
MG667/116	" "	" (.005") " (.010")				As requir	
MG667/117	Joint for				1	1	1
MG <b>429</b> /126	Felt bush	for steering column	(top)	Ceased Ch.	1	1	1
MG569/104				No. SA2751	1	1	1
MG538/103 MG538/104	Cover for	ing for steering colum ditto		No. SA2752	1 1	1 1	1 1
MG <b>667/118</b>				No. SA0902	1	1	1
MG708/104				. No. SA0903	1	1	1
MG667/3	Rocker-shaft		•••		1	1	1
MG667/120		ocker-shaft		,	1	1	1
MG667/121 MG667/122		ning washer for rock g ring for ditto			1 1	1 1	1 1
MG <b>62</b> 8/ <b>120</b>		g ring for ditto plug for steering be			1	1	1
MG628/121		sher for ditto			î	î	î
MG <b>667/123</b>		er for steering box			1	1	1
MG667/124		ditto (.0024")		• • • • • • • • • • • • • • • • • • • •		As requir	
MG667/125 MG667/126	,, ,,	" (.005″)		•••		As requir	
MG667/126 MG667/127	Joint for	" (.010″) side cover			1	As requir	ea 1
MG <b>667/100</b>				No. SA0690	i	i	1
MG <b>697/100</b>	,,	" Con	nm. Ch.	No. SA0691	1	1	1
MG <b>665</b>	Steering box	bracket with cap ar				,	,
MG762	Ditto			No. SA2102 No. SA2103	1 1	1 1	1 1
1919		column clamp		No. SAZ103	1	1	1
A813	Steering whee		_	Ceased Ch.	î	ī	1
538/6	Nut for	litto	اِ	No. SA0902	1	1	1
A926	Steering whee	1 11 11	J		1	1	1
A926/1 A926/103		l clip assembly nut for ditto	.	Comm. Ch.	1 1	1 1	1 1
A926/100		nut for ditto r steering wheel		No. SA0903	1	1	1
A926/101		washer for ditto			î	1	ĩ
A926/102	Ditto (	bottom)	/		1	1	1
MG668	Draglink asse		•••		1	1	1
MG668/100	Draglink		• • •	•••	$rac{1}{2}$	$rac{1}{2}$	1
MCGGGG/IAI	Ball seat	(inner) draglink			2	$\frac{2}{2}$	$\frac{2}{2}$
			• • •	• • • • • • • • • • • • • • • • • • • •			$\bar{2}$
MG668/102					<b>2</b>	<b>2</b>	2
MG668/102 MG668/103	Ball seat				$\frac{2}{2}$	$rac{2}{2}$	2
MG668/101 MG668/102 MG668/103 MG668/104 MG668/105	Ball seat Spring fo End plug	(outer) r draglink ball for draglink			2 2	$\frac{2}{2}$	2 2
MG668/102 MG668/103 MG668/104	Ball seat Spring fo End plug Slotted n	(outer) r draglink ball	•••		2	2	2

Part No.	MD	DESCRIPTION	MD		Saloon	No. Used Tourer	f ou som
552/6 559/7		ip for draglink gaiter (lar	<b>•</b> ,		1 1	1 1	1 1
S <b>52/7</b>	<i>n</i> :	,, ,, (small)		•••	1	1	1
		ALTERATION					
					• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·	
***************************************						· · · · · · · · · · · · · · · · · · ·	
						· · · · · · · · · · · · · · · · · · ·	•••••
• • • • • • • • • • • • • • • • • • • •			,,			· · · · · · · · · · · · · · · · · · ·	<b></b>
				······			
••••••		***************************************			**************		
IG <b>653</b>	Padiatar sam	RADIATOR AND CON	NECTIONS		1	1	. 1
IG <b>653/1</b>	Radiator com Radiator case	with medallion and grill	 e		1	1	1
IG497/102	M.G. Me	dallion		• • •	1	1	1
IG <b>653/102</b> IG <b>444/106</b>		grille complete for bonnet hinge rod		•••	1 1	1 1	1 1
IG <b>44</b> 4/100 IG <b>65</b> 3/2		block with tanks		•••	i	1	1
.153/100	Radiator	thermometer union			1	1	1
$214/102 \ 214/103$		drain tap sher for ditto		•••	$\frac{1}{2}$	$egin{smallmatrix} 1 \\ & 2 \end{smallmatrix}$	$-rac{1}{2}$
G6 <b>5</b> 3/106		radiator stay rod O/S		•••	ĩ	1	1
IG653/107	,, ,, (D)	", ", ", N/S		• • •	1	1	1
1G <b>653/1</b> 08 2 <b>14/1</b> 00		for headlamp brackets p for radiator		• • • •	1 1	1 1	1
214/101		ring for ditto			î	i	j
23/3	Bonnet r	est rubber			1 lgth.	1 lgth.	1 18
75/16 66/6		stay tube			$egin{array}{c} f 4 \ f 2 \end{array}$	$rac{4}{2}$	4
48/5		l for ditto		•••	2	$ar{2}$	2
528/8		ose connection (top)		• • • •	1	1	1
<b>A915</b> S <b>28</b> /9	Clip for Water b	ditto ose connection (bottom)			$\frac{2}{1}$	$\frac{2}{1}$	2
1914	Clip for				$ar{2}$	$ar{2}$	2
*******		ALTERATION	s			,	
		••••••			• • • • • • • • • • • • • • • • • • • •		
		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
				• • • • • • • • • • • • • • • • • • • •			
	*****************	EXHAUST SYST	'EM			***************************************	
IG <b>676/1</b>	Front exhaus	•			1	1	3
98/12		vasher for ditto (steel)		•••	$\frac{2}{2}$	$rac{2}{2}$	$\frac{2}{2}$
8 <b>15</b> /5 866/9		for ditto (copper and asbe or front exhaust pipe	,		1	1	1
IG706/207	Bolt for	ditto (to cylinder block)		•••	2	2	. 2
1679/27 $16676/2$	Fibre wa Front silence	sher for ditto r complete	• •••	•••	4 1	4 1	4
4G676/5		complete		•••	1	1	í
15/4	Washer	for silencer		• • • •	3	3	9
$815/6 \ 827/37$		silencers Ferrule for silencer support		•••	$\frac{2}{3}$	$\frac{2}{3}$	2 8
5108/3	Cap for				3	3	. 8
555/20		washer for front silencer		• • • •	2	<b>2</b>	2
AG676/4 AG676/6	Intermediate Rear exhaust			•••	· 1	1 1	1
889/20		stay for ditto		• • •	1	i	i
549/6 10/7	Bracket	for ditto (on rear cross to		•••	1	1	1
549/7 549/8	Clip for	ditto (ou rear cross tube) ,, (on rear exhaust pip	 e)		1 1 1	1 1	1
,	<i>"</i> "		•			-	
		ALTERATION					







Petrol tank complete	Part No.	(AD)	DESCRIPTION	(II)			No. Used	_
	rait No.		DBSCRIT TION	ران ا		Saloon	Tourer	Four- some
			PETROL TANK A	AND PIPE				
15/3	MG <b>671</b>	Petrol tank c				1	1	1
Petrol tank strap   2   2   2   2   2   2   2   2   2	MG671/1					1	1	1
2  20	S15/3					1	1	1
49/90   Rear end clip for tank strap   2   2   2   2   2   2   2   2   2	S <b>76/1</b>				•••			2
Rubber washer for tank strap   2   2   2   2   2   2   2   2   2	521/20							2
Hose connection for petrol filter neck   1	549/9				• • • •			2
Clip for ditto								2
10.719/1   Filler neck for petrol tank   No. SA0902   1   1   1   1   1   1   1   1   1	1							1
Filler cap for petrol tank								$\frac{2}{1}$
Corner   Filler neck for petrol tank   Comm. Ch.   1   1   1   1   1   1   1   1   1								1
1.0667	MG712/1							î
Cork washer for filler cap	A1067			No. S	A0903	1	1	1
1.   1	A1067/100	Spring fo	r filler cap catch	Cease	d Ch.	1	1	1
1374/9	A1067/101				A1983	1	1	1
Month   Filler cap for petrol tank   Comm.   1   1   1   1   1   1   1   1   1	MG732	Filler nec	k for petrol tank witl	ı cap		1	1	
Trigger for filler cap with screw   Ch. No. 1   1	B274/9	"	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					1
SA194   1	A1069	Filler cap	for petrol tank					1
Catch spring for trigger   1   1   1   1   1   1   1   1   1				v				1
Cork washer for tank cap     1   1   1   1   1   1   1   1   1					SA1984			1
Petrol pipe (16" long) (tank to connector)				•••				1 1
1   1   1   1   1   1   1   1   1   1				connector	١	_		1
Petrol pipe (125' long) (connector to pump connecting pipe)   1   1   1   1   1   1   1   1   1		Petrol ni	ne connector					1
necting pipe      1		Petrol pi	pe (125" long) (connec			•	•	
Ditto (main pipe to pumps)   1	<u>-</u>			*	-	1	1	1
### Petrol pump	S67/29							1
Rubber mounting for petrol pumps   2   2   2   2   556/19   Retaining plate for ditto       2   2   2   2   556/19   Retaining plate for ditto       2   2   2   2   556/19   Retaining plate for ditto       2   2   2   556/19   Retaining plate for ditto       1   1   1   1   1   1   1	A444					2	2	2
Retaining plate for ditto	S <b>44/4</b> 9							1
### WHEELS AND HUB NUTS    Wheels (18×3.25 W.B.)	S <b>2</b> 3/19				• • • •			2
Sepsize	S56/19				• • • •			2
### Section   Petrol pipe (flexible pipe to carburetters)   1   1   1   1   1   1   1   1   1	S67/80							1
Sala   Sala   Olive for petrol pipes   .	".							1
WHEELS AND HUB NUTS   S   S   S   S   S   S   S   S   S								1
Clip (petrol pipe to dash and frame)								5 5
### WHEELS AND HUB NUTS    Wheels (18 × 3.25 W.B.)   .	_ 1.	Clin (net	rol nine to dash and f					3
### WHEELS AND HUB NUTS  AS14 Wheels (18 × 3.25 W.B.)					••••			2
### Screw for ditto								ī
### WHEELS AND HUB NUTS  AS14 Wheels (18×3.25 W.B.)	S32/9			-				6
### WHEELS AND HUB NUTS  A814 Wheels (18×3.25 W.B.)	S2/52					1	1	1
WHEELS AND HUB NUTS  A814 Wheels (18×3.25 W.B.)	S68/6	Ferrule 1	or filler neck (rubber)		• • •	1	1	1
$\begin{array}{cccccccccccccccccccccccccccccccccccc$			ALTERAT	IONS				
$\begin{array}{cccccccccccccccccccccccccccccccccccc$								
$\begin{array}{cccccccccccccccccccccccccccccccccccc$								
$\begin{array}{cccccccccccccccccccccccccccccccccccc$								
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	• • • • • • • • • • • • • • • • • • • •							
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	• • • • • • • • • • • • • • • • • • • •							
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	• · · · · · · · · · · · · · · · · · · ·							
$\begin{array}{cccccccccccccccccccccccccccccccccccc$								
$\begin{array}{cccccccccccccccccccccccccccccccccccc$							*************	
A814/1 Wheel spoke (outer) with nipple As required A814/2 ", ", (inner) with nipple As required As required A819/3 Hub lock nut O/S	1014	Wheels (		HUB NUTS	i	F		_
A814/2 ", ", (inner) with nipple As required 5109/3 Hub lock nut O/S 2 2 5109/4 ", ", ", N/S 2 2					• •••	ð		rod 5
6109/3       Hub lock nut O/S		wneer st						
5109/4 , , , $N/S$ 2 2		Hub lock				Q		.eu •)
					• • • • • • • • • • • • • • • • • • • •	$\frac{7}{2}$		$\frac{2}{2}$
ALIERATIONS	1 =	<i>"</i> "	·	IONS		_	-	_
			ALIEKAL					
	• • • • • • • • • • • • • • • • • • • •					• • • • • • • • • • • • • • • • • • • •		
								• • • • • • • • • • • • • • • • • • • •
			***************************************					· · · · · · · · · · · · · · · · · · ·

Part No.	(II)	DESCRIPT	ION	MD)		No. Used	
		DESCRIPT		(العالم)	Saloon	Tourer	Four- some
	SHO	CK ABSORBE	R8 (illustra	ation on page	<b>44</b> )		
MG <b>72</b> 0/1	Front shock a	lbsorber comp			1	1	1
MG <b>72</b> 0/2			" N/S	. 1	1	1	1
A997	Front shock at				2	2	2
MG678/3	Front shock	absorber arn ecting link a			1	1	1
MG678/4	Ditto N	* 100		10 1	1	1	1 1
MG560/105		for shock al			$\overset{1}{2}$	$\overset{1}{2}$	2
MG <b>721/1</b>	Rear shock ab				ī	ī	ĩ
MG721/2	,, ,,	,, ,,	N/S	· [	1	1	1
A998	Rear shock ab	_ `		, I	2	2	2
MG <b>664/</b> 3	Rear shock a			-	4	,	
MG <b>664/4</b>	Ditto N	ecting link ar I/S	id pili O/S		1 1	1 1	1 1
MG <b>56</b> 0/105		for shock at	osorber arm		$\frac{1}{2}$	$\frac{1}{2}$	2
MG847/1	Front shock				_	_	_
,-		piston type)	·	.	1	· 1	1
MG847/2		/ <b>\$</b> (piston typ			1	1	1
MG848/1	Rear shock abs	_	<b>0/8</b> (pistor				
1004010		ype)	٠٠. ٠٠	O A OPPEO	1	1	1
MG848/2		<b>'\$</b> (piston typ reinforcemen			1	1	1
644/137		hock absorber		ł	2	<b>2</b>	<b>2</b>
S33/81		ear shock abs			4	4	$\bar{4}$
538/17	Special nu	t for ditto		. }	4	4	4
861/3	Support pi	n for front sho	ck absorbers	s	<b>2</b>	<b>2</b>	<b>2</b>
		AL."	reration	S			
	Front num	iber-plate	BER-PLAT	ES	_	1	1
56/17	Support fo	nber-plate or ditto			1	1	1
556/17	Support fo Rear numb	nber-plate or ditto ber-plate	Ceased Ch		1 1		
56/17 112/1	Support fo Rear numb	nber-plate or ditto	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27	  n. No. S <b>A0902</b>	1 1 1	1	1
5112/2 556/17 5112/1 A980	Support fo Rear numb	aber-plate or ditto ber-plate ar number- ate complete	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer)	n. No. SA0902 h. No. SA0903 ody No. <b>1399</b> / oon) and Ch. 73 (Coupé and	1	1 1	1
.56/17 .112/1 .980 .979	Support fo Rear numb	nber-plate or ditto ber-plate ar number- ate complete	Ceased Cr Comm. Cl Ceased Bo 6249 (Sal No. SA27' Tourer) m. Body N	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and	1 1 1	1 1 1	1
556/17 5112/1 4980 4979 41041	Support fo Rear numb Illuminated re pl Ditto Ditto	nber-plate or ditto ber-plate ar number- ate complete Conf	Ceased Cr Comm. Cl Ceased Bo 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl	n. No. SA0902 h. No. SA0903 ody No. <b>1399</b> / oon) and Ch. <b>73</b> (Coupé and No. <b>1400</b> /6250 h. No. SA2782	1 1 1 1	1 1 1 —	1 1 - 1
56/17 112/1 .980 .979 .1041 .973/101	Support fo Rear number	nber-plate or ditto or ditto or number- late complete Com ate glass	Ceased Ch Comm. Cl Ceased B 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl	n. No. SA0902 h. No. SA0903 ody No. <b>1399</b> ( oon) and Ch. <b>73</b> (Coupé and No. <b>1400</b> /6250 h. No. SA2782	$     \begin{array}{ccccccccccccccccccccccccccccccccc$	1 1 1 	1 1 1
556/17 5112/1 4980 4979 41041 4973/101	Support fo Rear number number-pla Ditto Number-pla Bulb for se Bulb for se	ar number- ate complete  Com ate glass stop and tail- eversing lamp	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer) m. Body N Comm. Cl 	n. No. SA0902 h. No. SA0903 ody No. <b>1399</b> / oon) and Ch. 73 (Coupé and No. <b>1400</b> /6250 h. No. SA2782 	$     \begin{array}{ccccccccccccccccccccccccccccccccc$	1 1 1 —	1 1 - 1
556/17 5112/1 4980 4979 41041 4973/101 220/8	Support for Rear number plants  Ditto Ditto Number-plants Bulb for reference cover for the Rear number.	ar number- ate complete  Com ate glass ate glass eversing lamp or rear num	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl 	n. No. SA0902 h. No. SA0903 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm.	1 1 1 1 1 3 1	1 1 1 	1 1 1 3 1
556/17 112/1 5980 5979 11041 5973/101 20/8 20/10 5973/1	Support for Rear number plants of the plants	nber-plate or ditto ber-plate ar number- ate complete Con ate glass stop and tail- eversing lamp or rear num ess glasses)	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27 Tourer) m. Body N Comm. Cl 	n. No. SA0902 h. No. SA0903 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No.	1 1 1 1 1 3 1	1 1 1 1 1 3 1	1 1 1 1 3 1
556/17 5112/1 5980 5979 51041 5973/101 20/8 20/10 5973/1	Support for Rear number lilluminated replacement of the placement of the p	nber-plate or ditto  ar number- ate complete Com ate glass stop and tail- eversing lamp or rear num sess glasses) adding for ditt	Ceased Ch Comm. Cl Ceased Bd 6249 (Sal No. SA27' Tourer) m. Body M Comm. Cl 	n. No. SA0902 h. No. SA0903 ody No. 1399, oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903	1 1 1 1 1 3 1	1 1 1 1 1 1 3 1	1 1 1 3 1
556/17 5112/1 4980 4979 41041 4973/101 520/8 220/10 4973/1	Support fo Rear number lilluminated replement of the plant of the plan	nber-plate or ditto  ar number- late complete  Com ate glass stop and tail- eversing lamp or rear num ess glasses) adding for ditt stop and	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl 	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased	1 1 1 1 3 1 1	1 1 1 1 1 3 1	1 1 1 1 1 3 1 1
56/17 112/1 .980 .979 .1041 .973/101 20/8 20/10 973/1 973/104 973/103	Support for Rear number plants of the plants	ar number- ar number- ate complete  Com ate glass stop and tail- eversing lamp or rear num ess glasses) ading for ditt stop and ound)	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body M Comm. Cl 	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No.	1 1 1 1 3 1 1 1	1 1 1 1 1 3 1 1 1	1 1 1 1 1 3 1 1 1
556/17 5112/1 5980 5979 51041 5973/101 5973/101 5973/10 5973/103 5973/100	Support for Rear number of Rubber of Rubber ber Glass for the Rubber of Rubb	nber-plate or ditto ber-plate commer- ate complete commercate glass cate glass cate glass estop and taileversing lamp or rear numbers glasses) acting for ditt stop and ound) eversing lamp for ditt stop and ceversing lamp	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer) Tourer m. Body M Comm. Cl clamp and dber-plate tail-lamp o (round)	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased	1 1 1 1 3 1 1	1 1 1 1 1 3 1	1 1 1 1 1 3 1 1
556/17 5112/1 5980 5979 51041 5973/101 5973/101 5973/10 5973/103 5973/100	Support for Rear number of Rear numb	ar number- ar number- ate complete  Conn ate glass stop and tail- eversing lamp or rear num ess glasses) ading for ditt stop and ound) eversing lamp or rear num eversing lamp	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer) Tourer m. Body M Comm. Cl clamp and dber-plate tail-lamp o (round)	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No.	1 1 1 1 3 1 1 1	1 1 1 1 1 3 1 1 1	1 1 1 1 1 3 1 1 1
.56/17 .112/1 .980 .979 .1041 .973/101 20/8 20/10 .973/1 .973/104 .973/103 .973/100 .980/1	Support for Rear number lilluminated replace place pla	nber-plate or ditto ber-plate commer- ate complete commercate glass cate glass cate glass estop and taileversing lamp or rear numbers glasses) acting for ditt stop and ound) eversing lamp for ditt stop and ceversing lamp	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body M Comm. Cl clamp and dber-plate tail-lamp o (round)	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858	1 1 1 1 3 1 1 1 1	1 1 1 1 3 1 1 1 1	1 1 1 1 1 3 1 1 1 1
556/17 5112/1 5980 5979 51041 5973/101 20/8 20/10 5973/10 5973/103 5973/100 5980/1	Support for Rear number plants of the plants	ar number-plate  ar number-plate  ar number-ate complete  Com  ate glass  ate gl	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer) Tourer) m. Body M Comm. Cl clamp and her-plate tail-lamp o (round) her-plate tail-lamp tail-lamp	n. No. SA0902 h. No. SA0903 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858	1 1 1 1 3 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1
556/17 5112/1 5980 5979 51041 6973/101 20/8 20/10 6973/10 6973/10 6973/10 6973/10 6980/10 6980/10 6980/10 6980/10	Support for Rear number lilluminated replace place pla	ar number- late complete  Com ate glass stop and tail- eversing lamp or rear num ess glasses) ading for ditt stop and ound) eversing lamp or rear num ess glasses) ading for ditt stop and D" shape)	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body M Comm. Cl 	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858  Comm. Body No.	1 1 1 1 3 1 1 1 1	1 1 1 1 3 1 1 1 1	1 1 1 1 1 3 1 1 1 1
\$56/17 \$112/1 \$1980 \$1041 \$1041 \$1041 \$20/8 \$20/10 \$1041 \$100 \$100 \$100 \$100 \$100 \$100 \$	Support for Rear number lilluminated replace place pla	ar number- late complete  Conn ate glass stop and tail- eversing lamp or rear num ess glasses) ading for ditt stop and ound) eversing lamp or rear num ess glasses) ading for ditt stop and D" shape) reversing lamp	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body M Comm. Cl 	n. No. SA0902 h. No. SA0903 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858	1 1 1 1 3 1 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1 1	1 1 1 3 1 1 1 1 1 1
56/17 112/1 .980 .979 .1041 .973/101 20/8 20/10 .973/1 .973/104 .973/103 .973/100 .980/104 .980/104 .980/104	Support for Rear number lilluminated replace place pla	ar number-plate or ditto  ar number-plate  ar number- ate complete  Com  ate glass  stop and tail- eversing lamp or rear num ess glasses) adding for ditt stop and ound)  eversing lamp or rear num ess glasses) adding for ditt stop and D" shape) reversing lam ape)	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl clamp and tail-lamp tail-lamp tail-lamp p ("D""	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858  Comm. Body No.	1 1 1 1 3 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1	1 1 1 1 1 3 1 1 1 1 1
.56/17 .112/1 .980 .979 .1041 .973/101 20/8 20/10 .973/1 .973/103 .973/103 .973/100 .980/104 .980/103 .980/104	Support for Rear number lilluminated replace place pla	ar number-plate or ditto  ar number-plate  ar number- ate complete  Com  ate glass  stop and tail- eversing lamp or rear num ess glasses) adding for ditt stop and ound)  eversing lamp or rear num ess glasses) adding for ditt stop and D" shape) reversing lam ape)	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27' Tourer) m. Body N Comm. Cl clamp and tail-lamp tail-lamp tail-lamp p ("D""	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858  Comm. Body No.	1 1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 3 1 1 1 1 1 1 1 1 1	1 1 1 3 1 1 1 1 1 1 1 1 1
56/17 112/1 .980 .979 .1041 .973/101 20/8 20/10 973/1 973/103 973/103 973/100 980/1 980/103 980/104 980/104	Support for Rear number lilluminated replace place pla	ar number-plate ber-plate commer-plate commer-plate commer-plate commer-plate complete commer-plate complete commer-plate glass stop and tailleversing lamp or rear numbers glasses) adding for ditt stop and ound) eversing lamp or rear number plate glasses) adding for ditt stop and D" shape) reversing lamp ape) for stop and versing lamp im	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA27 Tourer) Tourer) Touren m. Body M Comm. Cl clamp and tail-lamp	n. No. SA0902 h. No. SA0903 ody No. 1399/ oon) and Ch. 73 (Coupé and No. 1400/6250 h. No. SA2782 number-plate Comm. Ch. No. SA0903 Ceased Body No. 884/3858  Comm. Body No.	1 1 1 1 3 1 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1 1	1 1 1 1 3 1 1 1 1 1 1
556/17 5112/1 5980 5979 51041 5973/101 20/8 20/10 973/10 973/103 973/100 980/10 980/104 980/104 980/104 980/2	Support for Rear number lilluminated replement of the plant of the pla	ar number-plate or ditto  ar number-plate  ar number- ate complete  stop and tail- eversing lamp or rear num eversing lamp	Ceased Chy Comm. Cly Ceased Bo 6249 (Sal No. SA27) Tourery m. Body Manner and comm. Cly Comm. Comm. Cly Cly Comm. Cly Comm. Cly Comm. Cly Comm. Cly Comm. Cly Comm. Cly	n. No. SA0902 h. No. SA0903 h. No. SA0903 h. No. SA0903 h. No. SA2782 h. No. SA0903 h.	1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 3 1 1 1 1 1 1 1 1 1	1 1 1 3 1 1 1 1 1 1 1 1 2
556/17 112/1 5980 5979 1041 1973/101 20/8 20/10 1973/103 1973/103 1973/103 1973/100 1980/104 1980/104 1980/104 1980/105 14/35	Support for Rear number lilluminated replace place pla	ar number-plate or ditto ber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate complete comber-plate comber-pl	Ceased Ch Comm. Cl Ceased Be 6249 (Sal No. SA277 Tourer) m. Body N Comm. Cl	n. No. SA0902 h. No. SA0903 h. No. SA0903 h. No. SA0903 h. No. SA2782 h. No. SA0903 h. No. SA384/3858 h. Comm. h. Body No. Sa85/3859	1 1 1 1 1 1 1 1 1 2 2 1 1	1 1 1 1 1 3 1 1 1 1 1 1 1 1 1	1 1 1 3 1 1 1 1 1 1 1 1 1
856/17 8112/1	Support for Rear number lilluminated replace place pla	ar number-plate or ditto ber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate comber-plate complete comber-plate comber-pl	Ceased Ch Comm. Cl Ceased Bo 6249 (Sal No. SA27 Tourer) Tourer) Touren T	n. No. SA0902 h. No. SA0903 h. No. SA0903 h. No. SA0903 h. No. SA2782 h. No. SA0903 h.	1 1 1 1 1 1 1 1 1 2 2	1 1 1 1 1 3 1 1 1 1 1 1 1 1 1	1 1 1 3 1 1 1 1 1 1 1 1 1

Part No.	(IM)	DESCRIPTION	(N	(B)		No. Used	***
				<u> </u>	Saloon	Tourer	For
MG718	Cowl for rear	number-plate complete	e )		1	_	-
MG718/101		ortion of cowl	ĺ		1		_
MG <b>718/102</b>	Hinge rod	l for ditto '	Com	ını.	1		
568/27	Rubber p	acking for cowl O/S		y No.	1		-
568/28	_ "	" " N/S		0/6250	1		-
544/75		for rear number-plate	e				
S105/6		o body for rear number-plate	e		1 1		_
·	· ·	ALTERATIO	ONS				
,							
						•••••	
		······			••••••		
	GRO	OUPED NIPPLE LUBRI	ICATIN	G SYSTEM		*******************************	
AG669/100	Pipe (3' 3	½" long) (grouped nipple	e to fro	ont spring		0	
MG <b>669/102</b>	Ditto ('	ear pin) <b>7' 11½</b> " long) (grouped :		to brake	2	2	
MG <b>669/103</b>	Ditto (	ables) <b>10</b> ′ 9″ long) (grouped			2	2	
•	c	onnectors) (rear)	•••	·	2	2	
AG669/5		coiled) (connector to rea D/S with tee piece)	_	ig shackle	1	1	
/IG669/6	Ditto (e	coiled) (connector to rea	ar sprin	ig shackle	,	1	
IG <b>669/10</b> 6		N/S with tee piece) 6″ long) (between rear	 r spring	g shackle	1		
		ins)			<b>2</b>	<b>2</b>	
1G669/1 4G669/2	Pipe conne Elbow fee	ector d connector (front sprin	 ng rear	 pin rear	2	2	
	Sj	pring rear shackle)			4	4	
1G <b>66</b> 9/3	Tee feed	connector (rear spring		shackle) SA <b>2001</b> .	. 2	2	
4G <b>66</b> 9/7	Ditto (1	rear spring rear shackle	e)				
TC 000 IA	Cur told (			. SA2002	2	2	
IG669/4		eed connector (brake ca			<b>2</b>	2	
4G669/116		pipe connectors	• • •			As require	
4G669/117				•••		As require	ea .
1/14		ipple (for front spring thackle)	110111		4	4	
1/15		for steering knuckles, t	track	Ceased	-TE		
1,10		od and fan)		Ch. No.	7	7	
1/7		for rear hubs)		SA2751	2	2	
<b>1/10</b>		for propeller shaft)			1	1	
1/1		or draglink)	]		1	1	
1/22	Ditto (f	for front spring front sha			4	4	
1/21		or steering knuckles			_	_	
- 1				Comm.	5	5	
1/23		/	1	Ch. No.	2	2	
1/26			- 1	SA2752	$rac{2}{1}$	$rac{2}{1}$	
1/25					1	1	
$1/24 \\ 1/21$		or draglink) or front hubs) Comm.	J	No. 2008	$\overset{1}{2}$	$\frac{1}{2}$	
IG <b>66</b> 9/115		late fitting (on dash si		NO. 9090	2	4	
	Ditto (-			SA2751	6 6	6 6	(
[(]888/1100		on dash sides) Comm. ( ne pipe (2BA bolt fixin			· 4	4	
	CIID TOL OI	vo pipes (2BA bolt fixi		•••	6	4 6	(
4G833/100 2113/109 2278/111			·45/		$\frac{0}{2}$	${f 2}$	3
9113/109 9278/111	Clip for tv	ne nine (1" holt fiving)					
P113/109 P278/111 IG669/112	Clip for tv Clip for or	ne pipe $(\frac{1}{4}'')$ bolt fixing)		 .e)			
113/109 278/111 IG669/112 IG669/114	Clip for tv Clip for or Support fo	he pipe ( $\frac{1}{4}$ " bolt fixing) or three pipes (2BA bo	lt fixin	.g)	<b>2</b>	$ar{rac{-}{2}}$	
2113/109 2278/111	Clip for tv Clip for or Support fo	ne pipe ( $\frac{1}{4}$ " bolt fixing) or three pipes (2BA bolion plate for nipples C	lt fixin D/S			2	





	(II)	DESCRIPTION		(III)			No. Used	
Part No.	(10)	DESCRIPTION		(U)		Saloon	Tourer	Four som
52/44	Clip for pipe	s (double centr	e fixing)	•••	•••	4	4.	4
S2/45	, , , ,	(clip on type				2	<b>2</b>	2
S2/41	Clip for pipe	to rear axle				1	1	1
<b>52</b> /46		s (to front spri				<b>2</b>	. 2	2
,			RATIONS					
						· · · · · · · · · · · · · · · · · · ·	•	
	***************************************					· · · · · · · · · · · · · · · · · · ·	***************************************	• • • • • • • • • • • • • • • • • • • •
	***************************************	••••••••••••		·················	••••••••••••••••••••••••••••••••••••••			· · · · · · · · · · · · · · · · · · ·
		•••••		· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·			· - • • • • • • • • • • • • • • • • • •
			· · · · · · · · · · · · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·	,		
•••••					· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·		
	DASHBO	ARD DETAILS	(illustrati	ion on p	age 4	<b>49</b> )		
IG <b>652</b> /1	Dashboard comple	e (less foot ra	amp) eased Ch.	No. SA1	.500	1	1	1
IG <b>728/1</b>	Ditto (less	foot ramp) C	Comm. Ch. Ceased Ch.			1	1	1
[G <b>765/1</b>	Ditto (less	foot ramp) Co	omm, Ch	No. SA2	103	1	1	1
52/1		ting handle (gr		eased Ch		î	ī	1
52/ <b>4</b>	Ditto (sha			o. SA15		$\mathbf{\hat{2}}$	$\hat{f 2}$	2
52/11	Ditto		omm. Ch.			3	3	5
52/5	Clip for copp	er hammer Ce	eased Ch.	No. SA0	902	. 2	2	2
5 <b>2</b> / <b>4</b>	Clip for tyre					<b>2</b>	2	2
52/2	Clip for jack					<b>2</b>	2	2
G652/106	Foot ramp		eased Ch.	No. SA2	102	1	1	1
G765/100	,, ,,	Co	omm. Ch.	No. SA2	103	1	1	1
66/7	Dash stay tu	ıbe				2	2	2
15/4	Bracket for o	litto O/S .				1	1	1
<b>1</b> 5/5	" "	" N/S .		• • • •		1	1	1
56/13		e for dash sta	y tubes	•••	• • • •	1 .	, 1	1
G <b>652/107</b>	Tool box lid			•••	• • •	.1	.1	1
25/5	Hinge for dit			•••		<b>2</b>	2	2
854	Catch for lid			•••	• • •	2	2	2
68/18	Seal for clute				• • •	1	1	]
68/7		uder for steeri		n	• • •	1	1	1
69/2	Retaining pla	ate for ditto .	••	•••	•••	1	1	1
		ALTER	RATIONS				•	
			<b></b>			· · · · · · · · · · · · · · · · · · ·		· • • • • • • • • • • • • • • • • • • •
· <b></b>								
·••••				**************				<b></b> .
								· · · · · · · · · · · · · · · · · · ·
	FACIA BO	ARD EQUIPM				NTS		
	FACIA BO	ARD EQUIPM	Ceased	Body	No.	NTS		
977			Ceased 1935/ <b>864</b>	Body 3 (Salo	No. oon)		1	1
077	FACIA BO		Ceased 1935/ <b>864</b> Ch. No	Body <b>3</b> (Salo 5. SA2	No. oon) 7 <b>51</b>	NTS	1	1
977			Ceased 1935/ <b>864</b> Ch. No (Coupé a	Body 3 (Salo 5 SA2 and Tou	No. oon) 7 <b>51</b> rer)		1	1
977			Ceased 1935/ <b>864</b> Ch. No (Coupé a Comm.	Body 3 (Salo 5 SA2 and Tou Body	No. 2751 rer) No.		1	1
	Instrument panel		Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939	Body 3 (Salo 5 SA2 and Tou Body 4 (Salo	No. oon) 751 rer) No. oon)		1	
			Ceased 1935/ <b>864</b> Ch. No (Coupé a Comm.	Body 3 (Salo 5 SA2 and Tou Body 4 (Salo 5 SA2	No. 2751 rer) No. 2752	1		
1019	Instrument panel	with switches for instrumen	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel	Body 3 (Salo 5. SA2 and Tou Body 4 (Salo 5. SA2 und Tou	No. 2751 rer) No. 2001) 2752 rer)	1	1	1
1019 4/70	Ditto Support stay	with switches for instrumen Comm.	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel	Body 3 (Salo 5 SA2 1 Tou Body 4 (Salo 6 SA2 1 Tou 6 G69/3	No. 2751 rer) No. 2001) 2752 rer)	1 1 1	1	1
1019 4/70 7/3	Ditto Support stay	with switches for instrumen	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel . Body No tt panel	Body 3 (Salo 5 SA2 and Tou Body 4 (Salo 5 SA2 and Tou 6 SA2 and Tou 6 SA9/3	No. 2751 rer) No. 200n) 7752 rer) 696	1	1	1 1 1
1019 14/70 17/3 17/4	Ditto Support stay Cork packing	with switches for instrumen Comm. for instrumen	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel Body No tt panel C	Body 3 (Salo 5 SA2 1 Tou Body 4 (Salo 6 SA2 1 Tou 6 G69/3	No. 2751 rer) No. 2000) 7752 rer) 696	1 1 1 1	1 1 1	1 1 1 1
1019 44/70 37/3 37/4 378	Ditto Support stay Cork packing Ignition warning I	with switches for instrumen Comm. for instrumen light complete	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel Body No tt panel C	Body 3 (Salo 5 SA2 and Tou Body 4 (Salo 5 SA2 and Tou 6 SA2 and Tou 6 SA9/3	No. 2001) 2751 rer) No. 2001) 2752 rer) 696	1 1 1 1 1 1 1	1 1 1 1	1 1 1 1 1
1019 44/70 17/3 17/4 378 378/100	Ditto Support stay Cork packing Ignition warning I	with switches   for instrumen  for instrumen  light complete s for ditto	Ceased 1935/864 (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel Body No tt panel C	Body 3 (Salo 5 SA2 6 SA2 7 SA2 8 SA2 8 SA2 9 SA2	No. 2001) 2751 rer) No. 2001) 2752 rer) 696	1 1 1 1 1 1	1 1 1 1 1	1 1 1 1 1 1
1019 14/70 17/3 17/4 1378 1378/100	Ditto Support stay Cork packing Ignition warning I Rim and glas Bulb for ditte	with switches   for instrumen Comm. for instrumen light complete s for ditto	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel . Body No tt panel C	Body 3 (Salc o. SA2 and Tou Body 4 (Salc o. SA2 and Tou o. 669/3 N/S	No. pon) 7751 rer) No. pon) 7752 rer) 696	1 1 1 1 1 1 1	1 1 1 1	1 1 1 1 1 1 1
977 1019 14/70 37/3 37/4 878/100 20/19 20/18 323	Ditto Support stay Cork packing Ignition warning I Rim and glas Bulb for ditte Bulb for pane	with switches   for instrumen Comm. for instrumen light complete ss for ditto el illumination	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel Body No tt panel C	Body 3 (Salo . SA2 . SA2 . SA2 . SA2 . SA2 . Galo	No. pon) 7751 rer) No. pon) 7752 rer) 696	1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 4	1 1 1 1 4
1019 14/70 37/3 37/4 378 878/100	Ditto Support stay Cork packing Ignition warning I Rim and glas Bulb for ditte	for instrumen Comm. for instrumen iight complete s for ditto o el illumination at for panel ill	Ceased 1935/864 Ch. No (Coupé a Comm. 1945/939 Ch. No (Coupé a t panel t panel t panel t panel Commandat t panel t pan	Body 3 (Salo . SA2 . SA2 . SA2 . SA2 . SA2 . Galo	No. pon) 7751 rer) No. pon) 7752 rer) 696	1 1 1 1 1 1 1 1 1 1	1 1 1 1 1	1 1 1 1 1 1

Dest No		DECCRIPTION			No. Used	
Part No.	(MP)	DESCRIPTION	(TI)	Saloon	Tourer	Four- some
A825	Dynamo and I	amp switch		1	1	1
A894		l (locking) with key	Quote type	1	1	1
A894/100	Key for d	litto J	letters and numb	ers 1	1	1
	Ÿ	∫ Co	mm. Body No.			
A1019/3	Spare switch		45/ <b>9394</b> (Saloon) a. No. SA2752	1	1	1
A101 <i>0</i> /0	· ·	) (C	oupé and Tourer)	•	•	
A879		ning light com-	ased Body No.	1	1	1
A879/1	Cap for ditto		35/8643 (Saloon)	$\bar{1}$	ī	ĩ
A879/2	Bulb holder fo		. No. SA2751	1	1	1
A879/100			oupé and Tourer)	1	1	1
S20/19	Bulb hold		TO 1 N	1	1	1
A1019/1			mm. Body No.	1	7	4
Δ1019/9			45/ <b>9394</b> (Saloon) L. No. SA2752	1 1	1 1	1 1
A1019/2 S20/19	Bulb for	ditto (Co	oupé and Tourer)	i	1	î
A815	Speedometer			i	î	î
A817		unter and clock		ī	ī	ī
A815/100	Rim for s	speedometer and revo	lution counter	2	<b>2</b>	2
A815/102		speedometer and revo	olution counter	<b>2</b>	2	2
A815/103		acking for glass		<b>2</b>	<b>2</b>	2
A815/104		speedometer and rev		2	2	2
A815/105	Nut for c			4	4	4
A816	Speedometer c		•••	1	1	1
A816/1		ing for ditto le	••• •••	1 1	1 1	1 1
A816/100 A818		inter cable complete		1	i	î
A818/1		ing for ditto		i	1	i
A818/100	Inner cab			ī	î	î
S27/38		r revolution counter				
	****		1 Ch. No. SA0852	1	1	1
S27/48	Ditto		i. Ch. No. SA0853	1	1	1
A819		for revolution coun	,	1	1 1	1
$rac{A821/2}{A821/3}$	Ammeter	nometer with pipe lin	e	1 1	1	1 1
A822/1	Oil pressure ga			î	i	i
A1173/1	Petrol and oil			ī	î	î
A821/4		iments (with glass)		<b>2</b>	2	2
A821/100	Rim for o	litto		<b>2</b>	<b>2</b>	2
A822/100	Glass for			2	2	2
A821/102		acking for glass		2	2	2
A821/103		instruments		2	2	2
A821/104	Nut for c		··· ··· ···	4	4	4
S67/6	Pipe fine	for oil pressure gauge	; d Ch. No. SA2451	1	1	1
S67/20	Ditto (		1 CH. 110. SHEETI	i	î	i
S99/28			. Ch. No. SA2452	î	î	i
S3/38		for ditto		1	1	1
S2/12	Binding c	lip for radiator therm	no pipe	5	5	5
		ALTERAT	IONS			
		***************************************	***************************************		·····	
A1071	Haadlamn com	LAMPS (illustration	on page 50)	•)	.,	o
77011	Headlamp com	) Cea	ased Body No.	4	2	2
			74/6333 (Saloon)			
A869/1			. No. SA2135	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	<b>2</b>
A869/1	g	lass) Ch		_	-	
A869/1	g	) (Ca	oupé and Tourer)	2	-	
A869/1	g	∫ ( <b>C</b> c Co:	oupé and Tourer) mm. Body No.	2	-	
A869/1 A1071/1	·	∫ ( <b>C</b> c Co:	oupé and Tourer) mm. Body No. 75/6318 (Saloon)	2	2	9

Part No.	MD	DESCRIPTIO	N		MD.			No. Used	
rati No.		DESCRIPTIO	-24				Saloon	Tourer	Four- some
A869/100	Headlam	p glass					2	2	2
A869/102		king for ditto				•••	$ar{f 2}$	$ar{2}$	$\overline{2}$
A396/1		plete with bulb		der			<b>2</b>	2	<b>2</b>
A869/2	Bulb holder o						f 2	<b>2</b>	2
A869/3		w assembly for					$\overline{2}$	$\overline{2}$	2
A869/4		s piece with M.	,G, n	nedallion			2	$\overline{2}$	2
A471/101	Rim lock	ing screw		Ceased 1 <b>474/633</b>	Body	No. loon)	2	2	2
A869/101		at for ditto		Ch. No		2135	${f  ilde{2}}$	${f {2}}$	$\frac{2}{2}$
'				(Coupé a		~ ~ ′			
A1071/2	Catch assemb	dy for rim		Comm. <b>1475/631</b>	Body 8 (Sa)	No. loon)	2	2	2
31071/2	Catch assemb	1y 101 11111		Ch. No		2136	~	_	_
				(Coupé a					
S20/22	Bulb for	headlamp			• • •		2	2	2
A868	Headlamp dip	per switch					1	1	1
S <b>55/18</b>	Distance	tube for ditto			• • •		<b>2</b>	<b>2</b>	2
A870	Sidelamp com	iplete			• • •	• • •	2	${f 2}$	2
A870/1	Contact asser		• • •	•••		• • • •	2	<b>2</b>	$\begin{array}{c} 2 \\ 2 \end{array}$
A870/2	Front rim as	sembly (less glas	ss)				2	<b>2</b>	2
A870/3	Reflector com	plete with joint	beac	d and fix	ting wi	re	<b>2</b>	2	$rac{2}{2}$
A870/100	Sidelamp	shell		•••			2	2	2
A870/102	Sidelamp		• • •				<b>2</b>	2	2
A870/103		rubber base	• • •	•••		• • •	<b>2</b>	<b>2</b>	$\frac{2}{2}$
A870/104		der for sidelamp		• • •			<b>2</b>	<b>2</b>	2
S <b>2</b> 0/8		sidelamp					<b>2</b>	2	<b>2</b>
575/13	Rubber 1	packing for sidel	lamp	(upper)		• • •	<b>2</b>	2	$rac{2}{2}$
<b>575/14</b>	,,	n n	,,	(lower)			2	2	<b>2</b>
856/16	Backing	plate for sidelar	np	• • •		• • •	2	<b>2</b>	2
556/22		strip for sidela	mp	• • • •		• • •	<b>2</b>	2	2 2 2
A883	Passiamp con	nplete		•••	j		<b>2</b>	2	2
A883/100	Rim for	passlamp		• • •			<b>2</b>	2	2
A883/101		passlamp	• • • •	• • • •	Ceas		<b>2</b>	<b>2</b>	$\frac{2}{2}$
A883/102	Cork was	sher for ditto			Ch.		<b>2</b>	<b>2</b>	2
A883/2	Bulb cov	rer assembly	• • •	• • •	SA0	902	<b>2</b>	<b>2</b>	2
S20/ <b>2</b> 2	Bulb for	passlamp		•••	)		2	2	2
A959	Passiamp con	ıplete			)		1	1	1
A959/4	Front rim co	mplete with joi	int b	ead and					
		wires		•••	Com		1	1	1
4959/100	Passlamp	glass		• • • •	Ch.		1	1	1
A959/1	Reflector com		• • •	• • • •	SA0	903	1	1	1
A959/2	Reflector bac	k shell complete					1	1	1
4959/3	Bulb holder o	complete					1	1	1
520/24	Bulb for	passlamp			J		1	1	1
527/44		oush for passlan	тр са	ables (in	splash	er)	2	<b>2</b>	2
4717	Stop and tail-	·lamp complete	• • •		)		1	1	1
<b>A406/2</b>	Rim for	ditto (less glass)	)		Ceas		1	1	1
<b>A717/100</b>	Glass for	stop and tail-la	amp	•••	Ch.	No.	1	1	1
1717/102	Screw for	rim			SA0	902	1	1	1
S <b>20</b> /8		stop and tail-la		• • • •	j		<b>2</b>	2	2
A873	Stop lamp sw	itch with spring		• • •		• • •	1	1	1
4873/100		or ditto	• • •	• • •	• • •		1	1	1
S <b>44/44</b>	Bracket	for stop lamp s	witch	1	• • •		1	1	1
5114/1		ng link for stop	lam	p switch	ı ʻ	• • •	1	1	1
52/52	Clip for	tail-lamp cable					3	3	3
<b>A406</b>	Reversing lan	np complete			)		1	1	1
1406/2	Rim for	ditto (less glass)	)				1	1	1
A406/100	Glass for	reversing lamp			Ceas	ed	1	1	1
<b>1717/102</b>	Screw for	r rim		• • •	Ch.	No.	1	1	1
<b>A406/101</b>	Rubber i	pead for glass			SA09	902	1	1	1
520/10	Bulb for	reversing lamp			J		1	1	1
		ALT	ERA	TIONS					
	•••••								• • • • • • • • • • • • • • • • • • • •
	· · · · · · · · · · · · · · · · · · ·				•••••				
					••••••				


last No.	(AIN)	DESCRIPTION	MD)		No. Used	
'art No.		DESCRIPTION	ر <u>نان</u> 	Saloon	Tourer	son
	WINDS	CREEN WIPER	illustration on page 50	))		
1875	Windscreen wip		,	´ 1	-	_
A875/1	Fixing plate at	nd bearing bush		1		
. 1.				i		_
A875/2	Brush gear (wit					
<b>A875/100</b>		asher for mountin		2		_
1876/1	Rack assembly		n wiper			
	bla	ades	]	1		_
<b>A968/1</b>	Windscreen with	er motor unit	) _	1		]
A968/2	Brush gear with		1	1	_	
			1			
1968/100		ip for wiper motor	1 .	1	_	
<b>A968/101</b>		ip for ditto		1		
4968/102	Rubber bloo	ck for wiper motor	1	1		]
344/74	Bracket for	wiper motor	1	1		
55/21		tube for wiper	i			
000/21		otor	l l	2		9
			1	4		•
627/54		wiper cable (in				
	·da		Comm. Ch. No.	1		
1969	Driving cable for	r windscreen wiper	SA0903 (Saloon)	1		
<b>327/53</b>		iper drive (in dash)	<b>1</b>	1		
				-		
7990		er blade actuating		•		
		sembly		1		
<b>1990/1</b>	Knob for ditte	with set screw	[ 1935/ <b>8643</b> (Saloon)			
,		river's side), black		1	_	
000/9			ì	-		
1990/2		, 0	}	4		
		ack	l .	1		
$\lambda 990/3$	Ditto. (dr	river's side), brown		1	_	
<b>1990/4</b>	Ditto (pa	assenger's side),	ſ			
		own	ì	1	_	1
000/100		racket for angle	· I	-		
1990/100				4		
		ive box	Į	1	-	]
11127/1	Windscreen wip	er motor unit	1	1	-	
11127/103	Rubber me	ounting block for				
,	dit	tto	+	1		
<b>344/138</b>		windscreen wiper	ł			
TT/100			}	1		]
*****		otor	1	1	_	_
1134/1		er drive assembly		_		_
	(m	otor to link)	1	1		]
1129/100	Operating li	ink for windscreen	Comm. Body No.			
	wi	per (long)	1845/9394 (Saloon)	1	_	]
1134/100	Ditto (sh		1 ' ' '	1	_	]
		er for ditto (thin)	1	$\bar{6}$		ē
1127/100						
1127/106	Ditto (th		J	3	_	8
1127/102	Spring wash	her for ditto		3		;
1127/101	Felt washer	for ditto	1	9		ç
		er spindle assem-				
1134/4				-		,
*****		/ (driver's side)		1	_	]
1129/3	Ditto (pa	ssenger's side)	1	1	_	1
1127/5		le with set screw	1			
		river's side)		1		1
1197/E	Ditto (ar	econgor's side	1	1	_	j
1127/6		ssenger's side)	. ·	1	_	,
.388/107	Squeegee fo	or windscreen				
	wij	per   Cea	ased Body No.	<b>2</b>		2
876/3			35/ <b>8643</b> (Śaloon)	<b>2</b>		2
1134/2		or windscreen	, ( )			
			mm Rody No	9		2
1104/0	wij		mm, Body No.	2		
.1134/3		bly for ditto J 194		2		2
.876/101	Rubber bus	sh (squeegee to ar				
			sed Ch. No. SA0902	<b>2</b>		
970/100	Ditto lea		a. No. SA0903 (Saloon)	<b>2</b>		2
				-		_
OWA N.CC		arm) J Ch. No. S				
.876/100	Rubber bus	sh for wiper spind				
		Ceased Body	y No. <b>1935/8643</b> (Saloon)	) <b>2</b>		2
1127/107	Ditto		1845/9394 (Saloon)	2		2
		<b>,</b>	, , , , , , , , , , , , , , , , , , , ,			
112./10.		ALTERA	TIONS			
1121/101					,	
					·····	· • • • • • • • • • • • • • • • • • • •
						·••••
				······································		· · · · · · · · · · · · · · · · · · ·


Part No.	MIS	DESCRIPTION	MI		No. Used	-
				Salo	on Tourer	some
		RIVING MIRROR (ill	lustration on p			
882		r with bracket	•••	1	_	
882/100	Glass for		•••	1	-	
882/1		p for ditto	•••	1		_
882/2		ssembly for mirror	-11 5	1	_	_
389		r with bracket (extern		Ch	1	1
389/101		nirror (less bracket)	Ceased		1	1
.389/100	Glass for	or driving mirror	No. SA		1	1
257/101 1190		mirror r (internal) Comm. Ch.			1	1
		ALTERAT				
.874	Horn (high to	HORN (illustratio	n on page 50) d Ch. No. SA2	850 1	1	1
1219	· · · · · · · · · · · · · · · · · · ·	low tone)		1	i	î
44/56			d Ch. No. SA2		i	î
44/57		" " N/S		1	î ·	ī
<b>27/39</b>	Rubber b	oush for horn leads (in	n splasher)	2	$\hat{f 2}$	2
•		•	- ,			
		ALTERAT	10N2			
		•••••			••••••	
		***************************************		••••••••••	••••••	
			·····	• • • • • • • • • • • • • • • • • • • •	••••••	
• • • • • • • • • • • • • • • • • • • •						
•••••				······	·····	
		REGULATOR AND	JUNCTION BO	x		
.881	Regulator box	REGULATOR AND	JUNCTION BO		1	1
	Regulator box Fuse cov	complete		n. 1		
.881 .881/101		complete	Ceased Cl	n. 1 02 1		1
881/101	Fuse cove	complete er complete	Ceased Cl No. SA09	n. 1 02 1 h. 1	1 1	1 1
881/101 1111 955/1	Fuse cove Regulator box Fuse cove	complete complete complete	Ceased Ch No. SA09 Comm. Cl	n. 1 02 1 h. 1	1 1 1	1 1 1
.881/101 .1111 .955/1 .881/102	Fuse cover Regulator box Fuse cover Regulator	c complete	Ceased Ch No. SA09 Comm. Cl	n. 1 02 1 h. 1 03 1	1 1 1 1	1 1 1 1
.881/101 .1111 .955/1 .881/102	Fuse cove Regulator box Fuse cove	c complete	Ceased Ch No. SA09 Comm. Cl	n. 1 02 1 h. 1 03 1 1	1 1 1 1	1 1 1 1
881/101 1111	Fuse cove Regulator box Fuse cove Regulator Regulator Resistanc	complete	Ceased Ch No. SA09 Comm. Cl No. SA09	n. 1 02 1 h. 1 03 1 1	1 1 1 1	1 1 1 1 1
.881/101 .1111 .955/1 .881/102	Fuse cove Regulator box Fuse cove Regulator Resistanc	c complete c complete c complete c cover e assembly (field	Ceased Ch No. SA09 Comm. Cl No. SA09	n. 1 02 1 h. 1 08 1 1	1 1 1 1 1	1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1	Fuse cove Regulator box Fuse cove Regulator Resistanc	c complete c complete	Ceased Ch No. SA09 Comm. Cl No. SA09	n. 1 02 1 h. 1 03 1 1 1 1.	1 1 1 1 1	1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100	Fuse covered Regulator box Fuse covered Regulator Regulator Resistance Covered Regulator Resistance Resistance Regulator Resistance Regulator (Covered Regulator Resistance Regulator (Covered Regulator Regulator (Covered Regulator Regulator (Covered Regulator (	complete	Ceased Ch No. SA09 Comm. Cl No. SA09	n. 1 02 1 h. 1 03 1 1 1 1. 86 1	1 1 1 1 1 1	1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101	Fuse covered Fuse	c complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24	n. 1 02 1 h. 1 03 1 1 1 1. 86 1 1 1 1	1 1 1 1 1 1 1 1	) ) ) ) ) ) )
881/101 1111 1955/1 881/102 881/100 881/1 .881/2 .1111/100 .1111/101 .1111/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25)	c complete cr cr cr cover e assembly (field ohms) swamping 38 ohms) r cr cover cr cover e assembly amp)	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24	n. 1 02 1 h. 1 03 1 1 1 1. 86 1 1 1 1	1 1 1 1 1 1 1 1	) ) ) ) ) ) )
881/101 1111 1955/1 881/102 881/100 881/1 .881/2 .1111/100 .1111/101 .1111/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25)	c complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5
881/101 1111 955/1 9881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73	Fuse covered Fuse (25 Bracket	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24	n. 1 02 1 h. 1 03 1 1 1. 86 1 1. 1 187 1 5	1 1 1 1 1 1 1 1 5	1 1 1 1 1 1 1 2 8
881/101 .1111 .955/1 .955/1 .981/102 .881/100 .881/1 .881/2 .1111/100 .1111/101 .1111/1 .139/101 44/73	Fuse cover Regulator Fuse cover Regulator Regulator Resistance Company of the Com	cemplete	Ceased Ch. No. SA09 Comm. Cl. No. SA09 Ceased Ch. No. SA24 Comm. Cl. No. SA24 Comm. Cl. No. SA24 cd. Ch. No. SA24 n. Ch. No. SA2	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5	1 1 1 1 1 1 1 1 5
881/101 .1111 .955/1 .955/1 .881/102 .881/100 .881/1 .881/2 .1111/100 .1111/101 .1111/1 .139/101 44/73 44/142 .863	Fuse cover Regulator Fuse cover Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket in Ditto Junction box	cremplete cr cr cr cr cr cr cover e assembly (field ohms) swamping 38 ohms) cr cover cr cover cr cover e assembly amp) for regulator box	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5	1 1 1 1 1 1 1 1 5 5
881/101 1111 955/1 955/1 9881/102 881/100 881/1 881/2 1111/100 1111/1 139/101 44/73 44/142 863	Fuse cover Regulator Fuse cover Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket in Ditto Junction box	cemplete	Ceased Ch. No. SA09 Comm. Cl. No. SA09 Ceased Ch. No. SA24 Comm. Cl. No. SA24 Comm. Cl. No. SA24 cd. Ch. No. SA24 n. Ch. No. SA2	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5	
881/101 1111 955/1 9881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 1139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistanc Ditto (Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket for Ditto Junction box Junction box	cemplete	Ceased Ch. No. SA09 Comm. Cl. No. SA09 Ceased Ch. No. SA24 Comm. Cl. No. SA24	n. 1 02 1 h. 1 03 1 1 n. 86 1 1 h. 1 87 1 5 2102 1 2103 1 1	1 1 1 1 1 1 1 1 5 1 1 1	
881/101 1111 955/1 9881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket for Ditto Junction box	cemplete	Ceased Ch. No. SA24  Comm. Cl. No. SA24	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5	1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73 44/142 863 863/1	Fuse cover Regulator Fuse cover Regulator Regulator Resistance Company of the Com	cemplete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 	1. 1 02 1 1 03 1 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 5	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 1111/1 139/101 44/173 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistanc Cover Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket for Ditto Junction box	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Gased Ch No. SA24 Comm. Cl No. SA24 d Ch. No. SA24 n. Ch. No. SA2	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 5	11 11 11 11 11 11 11 11 11 11 11 11 11
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistanc Ditto (Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket for Ditto Junction box	cemplete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1	11 11 11 11 11 11 11 11 11 11 11 11 11
881/101 .1111 .955/1 .955/1 .881/102 .881/100 .881/1 .881/2 .1111/100 .1111/101 .1111/1 .139/101 .44/73 .44/142 .863 .863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket find Ditto Junction box Junction box	complete	Ceased Ch. No. SA09 Comm. Cl. No. SA09 Ceased Ch. No. SA24 Comm. Cl. No. SA24 Cl. No. SA24 Cl. No. SA2	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5	11 11 11 11 11 11 11 11 11 11 11 11 11
.881/101 .1111 .955/1 .955/1 .881/102 .881/100 .881/1 .881/2 .1111/100 .1111/101 .1111/1 .139/101 .44/73 .44/142 .863 .863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket find Ditto Junction box Junction box	cemplete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 cd Ch. No. SA24 cd Ch. No. SA25 cd Ch. No. SA25 cd Ch. No. SA26 cd Ch. Sa26	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5	11 11 11 11 11 11 11 11 11 11 11 11 11
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 1139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Resistance Ditto (Regulator Regulator Regulator Regulator Regulator Resistance Fuse (25 Bracket find Ditto Junction box Junction box	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 cd Ch. No. SA24 cd Ch. No. SA25 cd Ch. No. SA25 cd Ch. No. SA26 cd Ch. Sa26	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1	11 11 11 11 11 11 11 11 11 11 11 11 11
881/101 .1111 .955/1 .881/102 .881/100 .881/1 .881/2 .1111/100 .1111/101 .1111/1 .139/101 .44/73 .44/142 .863 .863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Resistanc Ditto (Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket for Ditto Junction box Junction box	cemplete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 cd Ch. No. SA24 cd Ch. No. SA25 cd Ch. No. SA25 cd Ch. No. SA25 cd Ch. No. SA26 cd Ch. Sa26	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 1139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Resistance Ditto (Regulator Resistance Fuse (25 Bracket for Ditto Junction box Junction box Junction box	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Gased Ch No. SA24 Comm. Cl No. SA24 	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 11111/101 1111/1 1139/101 44/73 44/142 863 863/1 880/100 366/100 511/103	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Regulator Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket if Ditto Junction box Junction box Junction box Junction box Junction box Battery (less I Battery I Battery I Regulator)	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 955/1 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73 44/142 .863 .863/1 	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Regulator Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket if Ditto Junction box Junction box Junction box Junction box Junction box Battery (less I Battery I Battery I Regulator)	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Ceased Ch No. SA24 Comm. Cl No. SA24 	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1 1 2 2 2 4 4 4	1 1 1 1 2 2 2 4 4 2
881/101 1111 955/1 9881/102 881/100 881/1 881/2 1111/100 1111/101 1111/1 139/101 44/73 44/142 863 863/1 880/1 880/1 880/1 880/1 880/1 880/2	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Resistanc Puse cover Regulator Regulator Regulator Regulator Regulator Resistanc Fuse (25 Bracket for Ditto Junction box  Battery (less I Battery I Battery I Regulator Bracket for Ditto Junction box	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Gased Ch No. SA24 Comm. Cl No. SA24 cd Ch. No. SA24 cd Ch. No. SA24 cd Ch. No. SA24 cd Ch. No. SA24	1 02 1 h. 1 03 1 h. 1 103 1 11 1. 1 186 1 187 1 1. 1 187 1 1. 1 187 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
881/101 1111 955/1 881/102 881/100 881/1 881/2 1111/100 11111/101 1111/1 1139/101 44/73 44/142 863 863/1	Fuse cover Regulator box Fuse cover Regulator Regulator Regulator Regulator Resistanc Puse (25 Bracket for Ditto Junction box  Battery (less I Battery I Battery I Battery I Cap nut Terminal Vent plug	complete	Ceased Ch No. SA09 Comm. Cl No. SA09 Gased Ch No. SA24 Comm. Cl No. SA24 d Ch. No. SA2 n. Ch. No. SA2 	n. 1 02 1 h. 1 03 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1 1 1 1 1 1 1 1 1 5 1 1 1 1 1 1 1 1 2 2 2 4 4 4 2 6	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Part No.	MD	DESCRIPTION	(II)	1	No. Used	
rate INO.	(UD)	DESCRIPTION	עוט	Saloon	Tourer	Four- some
		ALTERATIO	ONS			
			•••••			
						· · · · · · · · · · · · · · · · · · ·
			.0.17			
A302	Ignition coil	IGNITION C		1	1	1
MG679/239	Support	bracket for ditto Ceased	l Ch. No. SA0854	1	1	1
		ALTERATIO	ONS			
						············
A complete		HARNESSED CABLES		_	4	
A871/1 A871/2		ables complete (main) es complete	Ceased Ch. No. SA0902	1 1	1	1 1
A956/1	Harnessed ca	bles complete (main)	Comm. Ch.	1	1	1
A956/2 S2/47		s complete gative starter cable to d	J No. SA0903	1 1	1 1	1 1
S2/48		(harnessed cables to rea		Т	1	1
		Ceased	Ch. No. SA2751	2	2	<b>2</b>
S2/49	Ditto	(harnessed cables to sidelamp wires to wing		6	6	6
S2/50	Ditto	(starter and battery ca		10	10	10
S2/65	Ditto	(harnessed cables to wing		0		
S2/49	Ditto	ance and Tecalemit brac (harnessed cables to d		2	<b>2</b>	2
.,		and steering)	SA2752	<b>2</b>	<b>2</b>	. 2
S2/66 S2/50		(harnessed cable to da		<b>2</b>	2	2
S2/50	17110	(main battery lead to s Comm.	Ch. No. SA2013	1	1	1
S2/53	Ditto	(trafficator cables to be		_		-
S2/69	Ditto	(headlamp cable to fro	Ch. No. SA2181	1	1	1
02,00		splasher)	Comm. Ch.	3	3	3
S2/42		(dynamo cable to frame		2	2	2
S27/18 S27/38		er bush (for battery and (tail-lamp cables to rea		10 1	10 1	10 1
,		ALTERATIO	•			
		ADIEKAII				
			· · · · · · · · · · · · · · · · · · ·			
			•••••			
		***************************************				<b></b>
		·······				· · · · · · · · · · · · · · · · · · ·
						· · · · · · · · · · · · · · · · · · ·
A877		OR AND HORN CONTR Imn control complete	OLS (illustration of	on page	50)	
$\Lambda927$		Ceased	Ch. No. SA0902 Ch. No. SA0903	1 1	1	1 1
	Ditto		Ch. No. SA0303 Ch. No. SA2751	1	1	1
A1133		(telescopic) Comm.	Ch. No. SA2752	1	1	1
$\frac{A877/1}{A877/2}$	Horn push o	complete witch complete		1 1	1 1	1 1
A877/101		or switch lever	Ceased Ch.	1	i	i
A877/100		column control ring	No. SA2751	1	1	1
A877/102	Cable fo	or steering column contr	ro1 <u>/</u>	1	1	1

art No.	(IM)	DESCRIPTION	(EIM)		No. Used	Fou
		*	<u> </u>	Saloon	Tourer	son
1123/1	Top cover ass	sembly	)	1	1	
1123/2	Horn push as			ī	ī	
1123/3	Horn push ki		Comm. Ch.	1	1	
1123/4		ritch lever assembly	No. SA275		i	:
1123/5		and plate assembly	110. 511210.	î	î	
1123/101		r return ring		î	i	
1120/101	Trameato	-		_	•	
		ALTERAT				
				· · · · · · · · · · · · · · · · · · ·		• • • • • • • • • • • • • • • • • • • •
			•••••			• • • • • • • •
		***************************************		******************		· · · · · · · · · · · · · · · · · · ·
				· · · · · · · · · · · · · · · · · · ·	******	
	Wil	NGS AND STAYS (illu	stration on page	<b>5</b> 9)		
80/3 80/4		ng O/S (primed)  N/S (primed)		. 1	1	
OU/#	Ditti		o. SA2773 (Coupe	9) 1	1	
80/22	Ditte	N/S (with wing wel		•		
82/1	Front wi		. SA2782 (Coupé)	0	$egin{smallmatrix} 1 \ 2 \end{smallmatrix}$	,
				43	2	
$55/12 \ 27/35$		tube for ditto (botto	•		2 4	
			/+an\			
55/13		tube for wing stay		. 2	2	
27/36 4/31		oush for ditto e for front wing rear	etore	. 4	4	
eat/or	End piec	Ceased Body No. 1		1) 2	2	
36/5	Stiffener	for front wing valance			$\bar{2}$	
<b>14</b> /39		to wing stay bracket		•	ĩ	
<b>14/4</b> 0	radiator		DT IC	. 1	î	
55/11	Mounting	tube for ditto			4	
27/34		4 6 3344	•••	()	8	
'			wing star bracks		2	
33/42 68/5		oolt for radiator to verrule for radiator to			4	
00,0		(through wing) Ceased			<b>2</b>	
68/22		through wing)	20dy 210. 110/01.	_	-	
•		Comm. E	Body No. <b>717</b> /372		<b>2</b>	
45/6		p bracket		2	<b>2</b>	
83/55		olt for ditto		<b>2</b>	<b>2</b>	
27/33		errule for radiator to	wing stay bracke		_	
00/3	_ `.	idiator end)		2	2	
80/1	Rear win	g O/S (primed)		1	1	
$80/2 \\ 44/82$	Stiffens-	N/S (primed) for rear wing valance		1	1	
** <sub> </sub> 04	Suitener		; ody No. <b>1256/424</b>	6 2	<b>2</b>	-
		ALTERAT	TIONS			
***************************************						
			•••••			
wa 14	15	RUNNING-B	OARDS	•	•	
71/1	Running-	board O/S (primed)		1	1	
71/2	C+"	N/S (primed)	1// 1	1	1	
37/6 37/7	Step cha	nnelling for ditto (53)	½" long)	2	$\frac{2}{4}$	
37/7	"		7 (long)	4	4	
37/8	." 		$\frac{1}{2}$ " long)	$\dots$ 2	2	
56/15		strip for running-boar		•	As requi	red
75/21		vasher for running-bo nick)	ard mounting		As requi	

Part No.	MD)	DESCRIPTION		Saloon	No. Used Tourer	Four
575/22	Rubber wa	asher for running-bo	ard mounting			
200/11		n) int (front wing to r	unning board) ()/S	1	As requir	
568/11 568/12	•		unning-board) N/S	1 1	1 1	1 1
		ALTERAT	CIONS			
						• • • • • • • • • • • • • • • • • • • •
•••••			• • • • • • • • • • • • • • • • • • • •			· · · · · · · · · · · · · · · ·
						· · · · · · · · · · · · · · · · · · ·
			***************************************			
		***************************************	***************************************	· · · · · · · · · · · · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·
MG <b>654</b>		AND FASTENERS te (primed) (hinged	louvres)	,		
MG <b>72</b> 6	Ditto	Ceased Body No. (primed) (fixed louv	<b>1423</b> /6276 (Saloon) res)	1	1	1
		Comin. Body No.	1424/6277 (Saloon)	1	1	1
MG <b>654/100</b> MG <b>654/101</b>	Bonnet to	p O/S (primed) N/S (primed)		1 1	1 1	1 1
MG654/102		p hinge rod		i	i	i
MG654/112		for ditto		1	1	1
MG654/1	O/S	position properties of the contract of the c	Ceased Body	1	1	1
MG654/2	Ditto N/S	(primed)	No. 1423/6276	1	1	1
MG654/103	Bonnet sid	le only O/S (primed " N/S (primed	(Saloon)	1 1	1 1	1
MG <b>654/104</b> MG <b>654/105</b>	Louvres f	or bonnet side O/S	Ceased Body	1	1	,
	(pri	med)	No. <b>922</b> /3903	1	1	1
MG <b>654/10</b> 6	Ditto N	/S (primed)	(Saloon)	1	1	1
MCeraline	T auxmag f	- bannat aida Oli	Comni. Body No. <b>923/3932</b>			
MG654/115	(prin	or bonnet side O/S ned)	(Saloon)	. 1	1	1
MG <b>654/116</b>		/S (primed)	No. <b>1423</b> /6276	1	1	1
			(Saloon)			
S104/2	Handle for	r bonnet louvres O/S	4	1	1	1
S104/3 MG <b>654/107</b>	Clevis pin	for louvres	Ceased Body	$\begin{array}{c} 1 \\ 16 \end{array}$	$\begin{array}{c} 1 \\ 16 \end{array}$	1 10
MG <b>654/108</b>	Fibre wasl	ner for ditto	No. 1423/6276	16	16	10
MG <b>654/1</b> 09	Coil spring		(Saloon)	16	16	19
MG654/110 MG654/114	-	ng for louvres O/S		4. 4.	4 4	4
MG726/100	Bonnet sid	le O/S	Commi. Body	1	1	1
MG <b>72</b> 6/101 MG6 <b>54</b> /111	Bonnet sid	N/S le hinge rod	J No. 1424/6277	$egin{array}{c} 1 \\ 2 \end{array}$	${ {1} \atop {2} }$	1 2
544/51		or bonnet hinge rod		1	î	í
575/20	Rubber fo		` •´   •	1	1	1
875/19 875/27		for bonnet corners bonnet (on wing)	··· · · · · · · · · · · · · · · · · ·	4	4	4
			Body No. <b>414</b> /46		4	4
MG <b>51</b> 6/1 MG <b>51</b> 6/2	Builder lastelle	, , , N/S			$egin{array}{c} 2 \\ 2 \end{array}$	2
A584/1	Bonnet fa	stener less handle O	<u>/S</u>	2	<b>2</b>	2
4584/2 MG516/100	Handle for	" " " " N r bonnet fastener O	[/S		${\color{red}2}\\{\color{red}2}$	2 2
MG <b>51</b> 6/101	,, ,,	., , N	ī/S	_	$\frac{2}{2}$	2
MG <b>693/10</b> 0	Bracket fo	or bonnet fastener (f	ront) O/S	1	1	1
MG693/101 S56/25	Mounting,	bracket for bonnet	ront) N/S fastener O/S	_	1 1	1
S56/26	27	,, ,, ,,	N/S		1	]
MG693/102		stener bracket (rear)	· ··· ··· ···	<b>2</b>	<b>2</b>	2
856/12 836/8	Stiftening Rubber pe	strip for bonnet fas acking for bonnet (r	tener bracket	$\frac{2}{2}$	$egin{smallmatrix} 2 \ 2 \end{matrix}$	2
S23/21	Kubber pa	icking strip for boni	net (on scuttle)		As requi	rea






1


1

Rear bumper bar

MG709/104

o cap and bolt for bumper ctom cap for bumper bar ein spring for rear bumper O/S poport for rear bumper "O/S " " " N/S bber ferrule for ditto (thro bber ferrule for rear bumper rear bumper)  ALTERA	ends O/S N/S S S upper cut-compared to the control of the cut-compared to the cut-	    	2 2 1 1 1 1 2 2 2	Toures	2 2 1 1 1 1 2 2 2 2
tom cap for bumper bar et in spring for rear bumper opport for rear bumper o/S  poport for rear bumper o/S  "" N/S  bber ferrule for ditto (thro bber ferrule for rear bumper rear bumper)	ends O/S N/S S S upper cut-compared to the control of the cut-compared to the cut-	   ody) out (without	2 1 1 1 1 2		2 1 1 1 1 2
tom cap for bumper bar et in spring for rear bumper opport for rear bumper o/S  poport for rear bumper o/S  "" N/S  bber ferrule for ditto (thro bber ferrule for rear bumper rear bumper)	ends O/S N/S S S upper cut-compared to the control of the cut-compared to the cut-	   ody) out (without	2 1 1 1 1 2		2 1 1 1 1 2
in spring for rear bumper opport for rear bumper O/S  "" N/S  bber ferrule for ditto (throbber ferrule for rear bumper rear bumper)	O/S N/S S S ough bother cut-o	   ody) out (without	1 1 1 1 2		1 1 1 1 2
pport for rear bumper O/S  " N/S  bber ferrule for ditto (thro bber ferrule for rear bumper rear bumper)	N/S S S ugh boor cut-o	  ody) out (without	1 1 1 2		1 1 1 2
port for rear bumper O/S  """ N/S  bber ferrule for ditto (thro  bber ferrule for rear bumpe  rear bumper)	S S ough bo er cut-o	ody) out (without	1 1 2		$\begin{matrix} 1 \\ 1 \\ 2 \end{matrix}$
bber ferrule for ditto (thro bber ferrule for rear bumpe rear bumper)	ough bo er cut-c	ody) out (without	$egin{smallmatrix} 1 \ 2 \end{smallmatrix}$		1 2
bber ferrule for ditto (thro bber ferrule for rear bumpe rear bumper)	ough bo er cut-c	ody) out (without	2		2
bber ferrule for rear bumper rear bumper)	er cut-c	out (without	_		
rear bumper)	•••		2		2
- ,	 TIONS	•••	4		
ALIERA					_
				***************************************	
					• • • • • • • • • • • • • • • • • • • •
					· · · · · · · · · · · · · · · · · · ·
					• • • • • • • • • •
PARE WHEEL CARRIER	(illustr	ation on page	60)		
heel lock nut and sleeve ass	embly		1	1	1
	1	Ceased Ch	1	1	1
					i
	1	1 10			i
	1	(Coupe)	_		i
		)	_		
	٠	Cassad Ch	1		_
		1	_		J
; <del>-</del> ,					1
	.)				
	( ' ' ' ' '	•••			_
tter for spare wheel cover	(sides)	•••		-	_
	(top)	•••	1		_
heel support tube assembly	<b>/</b> ··· }			1	1
mp for ditto				1	1
mp nut for ditto		1		1	1
sher for ditto	[			1	1
t for spare wheel support	tube				
(bottom)	.,,			1	1
				1	1
acket for ditto	]			1	1
	wheel	Wing fitting		,	_
	wheel			1	1
				1	1
bber ferrule for spare	wheel	` • ′			
trough	wheel		_	1	1
	1	<b> </b>		1	1
			_		í
		1	_		]
	1	ļ		_	_
	•••			_	1
u 101 uitto	ر ۰۰۰	1		1	1
	carrier	carrier  car	carrier	G. medallion for spare wheel carrier	Carrier   Carr





Pa <b>rt N</b> o.	MB	DESCRIPTION		MD		Saloon	No. Used Tourer	Four some
F	OTWELL AND	PROPELLER SHAF	T TUNK	VEL (il)	ustrati	on on p	page 63)	
5102/3	Rear foot	twell		•••		1	1	1
321/22	Felt strip	for ditto (rear)	•••	• • •	• • •	1	1	1
$\frac{521}{21} \\ \frac{5102}{2}$	" " Propeller	shaft tunnel		•••	• • • •	$\frac{2}{1}$	2 1	$\frac{2}{1}$
21/19		for ditto			• • • •	i	î	î
103/5	Carpet su	pport tunnel (on pre		Comm				
68/19	sha Sorbo sea	ift tunnel) il for ditto		No. Sa		1	1 1	1 1
,		ALTERA	TIONS					
		BODY MO	UNTING	G		1	••••••	
323/15	Dash to	body jointing (top)	• • •			1		
323/16 329/20	77 . 14 . 77 . 19	" " (sides)		• • • •	• • • •	$\frac{2}{6}$		-
33/59 33/57		ly to dash) ink screw for floorb		• • • •	• • • •	$\frac{8}{17}$	_	
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Counterst	ink serew for noorb	oarus	•••	•••	1,		
***************************************		ALTERA	TIONS					
		SALOON BOD	Y DET	AILS				
		RONT DOORS, LOC			DLES	•		Saloro
		ole (MS /with oteller						1
	Front door to	ck O/S (with strike			• • •	1		1
3267/24	,, ,, ,,	, N/S (with strike	r assem	bly)		Cease	ed Body	1
3267/24 3267/27	Striker assem	, N/S (with strike bly for front door le	r assem ock	bly)			ed Body 1935/ <b>8643</b>	1
3267/24 3267/27 517/21	Striker assem Rubber b	, N/S (with strike bly for front door lo oush for striker	r assem ock 	bly) 				1 2 2
3267/24 3267/27 517/21 3267/180	Striker assem Rubber b Cover-pla	, N/S (with strike bly for front door le	r assem ock 	bly) 	•••			1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6	Striker assem Rubber t Cover-pla Front door lo	, N/S (with strike bly for front door lo push for striker te for striker ck O/S (with strike , N/S (with strike	r assem ock  r assem r assem	bly) bly) bly)		No.	1935/8643	1 2 2 2 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43	Striker assem Rubber t Cover-pla Front door lo	, N/S (with strike bly for front door lo oush for striker te for striker ck O/S (with strike , N/S (with strike bly for front door lo	r assem ock r assem r assem ock O/S	bly) bly) bly)		No.	1935/ <b>8643</b> m. Body	1 2 2 2 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44	Striker assem Rubber t Cover-pla Front door lo Striker assem	, N/S (with strike bly for front door lo oush for striker te for striker ock O/S (with strike , N/S (with strike bly for front door lo	r assem ock r assem r assem ock O/S " N/S	bly) bly) bly) bly)		No.	1935/8643	1 2 2 2 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21	Striker assem Rubber t Cover-pla Front door lo Striker assem "Rubber t	, N/S (with strike bly for front door loosh for striker te for striker ock O/S (with strike , N/S (with strike bly for front door loosh for striker "	r assem ock r assem r assem ock O/S " N/S	bly) bly) bly) 5		No.	1935/ <b>8643</b> m. Body	1 2 2 1 1 1 1 2
3267/24 3267/27 617/21 3267/180 3276/5 3276/6 3271/43 3271/44 617/21 3276/111	Striker assem Rubber t Cover-pla Front door lo Striker assem "Rubber" t Cover-pla	, N/S (with strike bly for front door loush for striker ck O/S (with strike , N/S (with strike bly for front door loush for striker refer te for striker	r assem ock r assem r assem ock O/S " N/S	bly) bly) bly) bly)		No.	1935/ <b>8643</b> m. Body	1 2 2 2 1 1 1
3267/24 3267/27 317/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3267/103	Striker assem Rubber t Cover-pla Front door lo Striker assem "Rubber" t Cover-pla	, N/S (with strike bly for front door loosh for striker te for striker ock O/S (with strike , N/S (with strike bly for front door loosh for striker "	r assem ock r assem r assem ock O/S " N/S S	bly) bly) bly)		No.	1935/ <b>8643</b> m. Body 1845/ <b>9394</b>	1 2 2 1 1 1 2 2
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3276/103 3267/104 3267/104	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom co	N/S (with strike bly for front door loosh for striker te for striker ock O/S (with strike , N/S (with strike , N/S for front door loosh for striker regulator (front) O/S (front) N/S (channel for ditto	r assem ock r assem r assem ock O/S " N/S S	bly) bly) bly) bly)		Comp No.	m. Body 1845/ <b>9394</b> 	1 2 2 1 1 1 2 2 1
3267/24 3267/27 17/21 17/21 3267/180 3276/5 3271/43 3271/44 317/21 3276/111 3267/103 3267/104 3267/104	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for w	N/S (with strike bly for front door loush for striker ock O/S (with strike , N/S (with strike , N/S (with strike bly for front door loush for striker regulator (front) O/S (front) N/S channel for ditto indow regulator with	r assem ock r assem r assem ock O/S " N/S S h escute	bly) bly) bly) 5 5 cheon b		Common No.	m. Body 1845/ <b>9394</b> 	1 2 2 2 1 1 1 1 2 2 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3267/104 3267/104 3267/144 3267/43	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for w Door handle	N/S (with strike bly for front door loush for striker te for striker ck O/S (with strike, N/S (with strike) bly for front door loush for striker regulator (front) O/S (front) N/S (shannel for ditto indow regulator with (inside) with escutch	r assem ock r assem r assem r assem ock O/S N/S s h escute	bly) bly) bly)		Come No.	m. Body 1845/9394	1 2 2 2 1 1 1 2 2 1 1 2 2 2 2 2 2 2 2 2
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/104 3267/104 3267/111 3267/43 3267/44 3267/110	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for w Door handle	N/S (with strike bly for front door loush for striker te for striker ck O/S (with strike, N/S (with strike) bly for front door loush for striker regulator (front) O/S (front) N/S channel for ditto indow regulator with (inside) with escuted on for window regulator egulator regulator with channel for window regulator with escuted on for window regulator regulator regulator with escuted on for window regulator regulator regulator regulator with escuted on for window regulator regulator regulator regulator regulator with rescuted on for window regulator re	r assem ock r assem r assem ock O/S N/S s h escute lator ha	bly) bly) bly) cheon b sh and andle a		Come No.	m. Body 1845/9394	1 2 2 1 1 1 1 2 1 1
3267/24 3267/27 317/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/104 3267/104 3267/44 3267/43 3267/43 3267/43	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for d	N/S (with strike bly for front door le oush for striker ock O/S (with strike ock o/S (front) O/S	r assem cock r assem r assem r assem sock O/S N/S h escute eon bus lator he	bly) bly) bly) s s sheon b sh and andle a		Comi No.	m. Body 1845/9394	1 2 2 2 1 1 1 2 2 1 1 2 2 4
B267/24 B267/27 517/21 B267/180 B276/5 B276/6 B271/43 B271/44 S17/21 B276/111 B267/104 B267/104 B267/104 B267/44 B267/43 B267/43 B267/43 B267/43 B267/43 B267/398	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for we Door handle Escutcher Bush for Pin for do Ontside door	N/S (with strike bly for front door loush for striker te for striker ck O/S (with strike , N/S (with strike bly for front door loush for striker regulator (front) O/S (mindow regulator with (inside) with escutch on for window regulator thandle (front) O/S ditto thandle (front) O/S	r assem cock r assem r assem r assem sock O/S N/S h escute eon bus lator he	bly) bly) bly) s s sheon b sh and andle a		No. Comi No d pin ide doo	m. Body 1845/9394 or handle	1 2 2 1 1 1 1 1 2 2 1 1 1 2 2 2 4 4 4
B267/24 B267/27 B267/27 B267/180 B276/5 B276/6 B271/43 B271/44 B17/21 B276/111 B267/103 B267/104 B267/104 B267/111 B267/110 B267/110 B267/110 B267/398 B267/398	Striker assem Rubber t Cover-pla Front door lo Striker assem  "Rubber t Cover-pla Window  Bottom o Handle for w Door handle Escutched Bush for Pin for d Ontside door	, N/S (with strike bly for front door loush for striker ck O/S (with strike, N/S (with strike) bly for front door loush for striker regulator (front) O/S (front) N/S	r assem ock r assem r assem r assem ock O/S N/S h escute teeon but lator ha (with	bly) bly) bly) cheon b sh and andle a llocking	ush an pin nd ins barre	No. Common. No.  d pin de doo Ceass	m. Body 1845/9394	1 2 2 1 1 1 1 2 2 1 1 2 2 2 4 4 4 4 4 4
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3267/103 3267/104 3267/110 3267/398 3267/398 3267/3	Striker assem Rubber t Cover-pla Front door lo Striker assem  "Rubber t Cover-pla Window  Bottom o Handle for w Door handle Escutched Bush for Pin for d Ontside door	N/S (with strike bly for front door lovel for striker ck O/S (with strike, N/S (with strike, N/S (with strike) bly for front door lovel for striker regulator (front) O/S (front) N/S (front)	r assem ock r assem r assem r assem sock O/S N/S h escute teeon bullator ha (with	bly) bly) bly)		No.  Comi No.  Comi No.  di pin  dide doo  Cease No.	m. Body 1845/9394 or handle ed Body 1614/6350	1 2 2 1 1 1 1 1 2 2 1 1 1 2 2 2 4 4 4
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3267/103 3267/104 3267/110 3267/398 3267/398 3267/3	Striker assem Rubber to Cover-pla Front door lo  Striker assem Rubber to Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door Outside door Outside door	N/S (with strike bly for front door le oush for striker te for striker ok O/S (with strike N/S (with strike N/S (with strike bly for front door le oush for striker regulator (front) O/S (front) N/S (hannel for ditto indow regulator with (inside) with escuted on for window regulator (litto handle (front) O/S (d key) door handle (front) O/S (handle (front) O/S (d key)	r assem ock r assem r assem r assem sock O/S N/S h escute teeon bullator ha (with	bly) bly) bly)		Comi No.	m. Body 1845/9394 or handle ed Body 1614/6350 m. Body	1 2 2 1 1 1 1 2 2 1 1 1 2 2 2 4 4 4 4 1 1 1
3267/24 3267/27 3267/180 3276/5 3276/6 3271/43 3271/44 317/21 3276/111 3267/104 3267/104 3267/110 3267/43 3267/110 3267/43 3267/398 3267/398 3267/33	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for we Door handle Escutched Bush for Pin for do Ontside door and Outside door and	N/S (with strike bly for front door leads to striker to for striker ck O/S (with strike to N/S (with strike bly for front door leads to the for striker regulator (front) O/S (front) N/S (fro	r assem ock r assem r assem r assem cock O/S N/S h escute eon but lator ha (with N/S (with	bly) bly) bly)		Comi No.	m. Body 1845/9394 or handle ed Body 1614/6350	1 2 2 1 1 1 1 2 2 1 1 2 2 2 4 4 4 4 4 4
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/104 3267/104 3267/104 3267/110 3267/110 3267/398 3267/314 3267/398 3267/34 3267/34 3267/34 3267/34 3267/34 3267/34 3267/34 3267/34	Striker assem Rubber b Cover-pla Front door lo Striker assem Rubber b Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for do Outside door an Outside door an Outside door Coutside door an Outside door	N/S (with strike bly for front door leads to for striker te for striker ck O/S (with strike ke O/S (with strike ke N/S (with strike bly for front door leads to for striker regulator (front) O/S (front) N/S	r assem cock r assem r assem ock O/S N/S h escutcheon but lator ha (with N/S (with	bly) bly) bly) cheon besh and andle a locking	ush an pin nd ins barre	Comi No.	m. Body 1845/9394 or handle ed Body 1614/6350 m. Body	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/103 3267/104 3267/103 3267/104 3267/43 3267/43 3267/398 3267/398 3267/398 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340	Striker assem Rubber to Cover-pla Front door lo  Striker assem Rubber to Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for do Outside door and Outside door and Outside door And Counter to the counter to	N/S (with strike bly for front door le oush for striker te for striker ock O/S (with strike N/S (with strike N/S (with strike bly for front door le oush for striker regulator (front) O/S (front) N/S (front)	r assem cock r assem r assem r assem cock O/S N/S th escute lator ha (with N/S (with N/S	bly) bly) bly) bly) bly) bly) bly bly bly bly bly bly bly bly blocking blocking blocking blocking blocking		No.  Common No.  Common No.  Common No.  Cease No.  Common No.  Common No.  Common No.	m. Body 1845/9394 or handle ed Body 1614/6350 m. Body 1268/7341	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 1 1 1 1
3267/24 3267/27 117/21 3267/180 3276/5 3276/6 3271/43 3276/111 3267/104 3267/104 3267/104 3267/104 3267/43 3267/110 3267/398 3267/31 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/114	Striker assem Rubber th Cover-pla Front door lo Striker assem Rubber th Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door am Outside of Outside of Contside door And Coutside of Contside of C	N/S (with strike bly for front door le oush for striker te for striker ock O/S (with strike N/S (with strike N/S (with strike bly for front door le oush for striker regulator (front) O/S (front) N/S (front)	r assem ock r assem r assem r assem ck O/S N/S h escute eon bullator ha (with N/S (with N/S with key adde	bly) bly) bly) bly) cheon bsh and andle a locking locking	ush an pin nd ins barre barre	No.  Common No.  Common No.  Ceass No.  Common No.  Common No.  Common No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/103 3267/104 3267/104 3267/43 3267/44 3267/43 3267/397 3267/398 3267/33 3267/33 3267/340 31063 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340 3267/340	Striker assem Rubber b Cover-pla Front door lo Striker assem Rubber b Cover-pla Window Bottom c Handle for w Door handle Escutchec Bush for Pin for d Ontside door an Outside door an Outside door An Coutside doo	N/S (with strike bly for front door leads to for striker te for striker ck O/S (with strike ck O/S (with strike rough for front door leads for striker regulator (front) O/S (front) N/S (front) N	r assem cock r assem r assem r assem cock O/S N/S th escute lator ha (with N/S (with N/S	bly) bly) bly) bly) bly) bly) bly bly bly bly bly bly bly bly blocking blocking blocking blocking blocking		Comi No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/104 3267/104 3267/104 3267/110 3267/397 3267/398 3267/398 3267/398 3267/398 3267/398 3267/398 3267/398 3267/398 3267/398 3267/398 3267/114 3267/398 3267/114 3267/398 3267/114 3267/115 3267/115	Striker assem Rubber b Cover-pla Front door lo Striker assem Rubber b Cover-pla Window Bottom c Handle for w Door handle Escutchec Bush for Pin for d Ontside door an Outside door an Outside door An Coutside doo	N/S (with strike bly for front door le oush for striker te for striker ock O/S (with strike N/S (with strike N/S (with strike bly for front door le oush for striker regulator (front) O/S (front) N/S (front)	r assem ock r assem r assem r assem cock O/S N/S h escute eon but lator ha (with N/S (with N/S N/S n/S adde	bly) bly) bly) bly) cheon b sh and andle a llocking llocking	ush an pin nd ins barre barre	Comi No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 1 1 1 1
3267/24 3267/27 3267/27 3276/5 3276/5 3271/43 3271/44 317/21 3267/103 3267/104 3267/104 3267/103 3267/104 3267/103 3267/104 3267/398 3267/398 3267/398 3267/398 3267/314 3267/340 \$\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)\$\)	Striker assem Rubber th Cover-pla Front door lo Striker assem Rubber th Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door and Outside door Contaide door And Countied	N/S (with strike bly for front door le oush for striker te for striker ock O/S (with strike N/S (with strike N/S (with strike bly for front door le oush for striker regulator (front) O/S (front) N/S (front)	r assem ock r assem r assem r assem ck O/S N/S h escuteeon bulator ha (with N/S (with n/S adde	bly) bly) bly) cheon b sh and andle a llocking	ush an pin nd ins barre barre	No.  Common No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3267/103 3267/104 3267/104 3267/104 3267/44 3267/43 3267/43 3267/398 3267/398 3267/398 3267/398 3267/316 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/117 3267/117 3267/117 3267/118 3267/119 3267/119	Striker assem Rubber th Cover-pla Front door lo Striker assem Rubber th Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door and Outside door Contaide door And Countied	N/S (with strike bly for front door le oush for striker ck O/S (with strike, N/S (with strike, N/S (with strike) bly for front door le oush for striker regulator (front) O/S (mannel for ditto indow regulator with (inside) with escuted on for window regulator with (inside) with escuted on for window regulator with (inside) with escuted on for window regulator with (inside) handle (front) O/S (d key) (loor outside door handle (front) O/S (	r assem ock r assem r assem r assem ock O/S N/S h escute eon but lator ha (with N/S (with N/S in	bly) bly) bly) bly) s s cheon b sh and andle a llocking llocking	barre barre	No.  Comi No.  Comi No.  Ceasi No.  Com No.  Com No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 1 2 2 2 2 2 2 2 1 1
3267/24 3267/27 3267/180 3276/5 3276/6 3271/43 3271/44 317/21 3276/111 3267/103 3267/104 3267/104 3267/104 3267/104 3267/33 3267/398 3267/398 3267/398 3267/398 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31 3267/31	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for we Door handle Escutcher Bush for Pin for of Ontside door Annote to Contside door Annote to Coutside door Annote	N/S (with strike bly for front door leads to for striker te for striker ck O/S (with strike bly for front door leads ck of c	r assem ock r assem r assem r assem r assem h escute eon bus lator ha (with N/S (with N/S with key dle	bly) bly) bly) bly) cheon besh andle a llocking	barre	No.  Comi No.  Comi No.  Comi No.  Ceass No.  Com No.  Com No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/27 517/21 3267/180 3276/5 3276/6 3271/43 3271/44 517/21 3276/111 3267/103 3267/104 3267/104 3267/43 3267/43 3267/43 3267/43 3267/38 3267/398 3267/398 3267/31 3267/31 3267/116 3267/116 3267/117 3267/116 3267/117 3267/117 3267/119 3267/119 3267/119	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for we Door handle Escutcher Bush for Pin for of Ontside door Annote to Contside door Annote to Coutside door Annote	N/S (with strike bly for front door leads for striker to for ditto indow regulator with the strike to for ditto to for window regulator with the strike to for window regulator to for for window regulator to for handle (front) O/S down to for handle (front) O/S down to for handle (front) for ditto to for door handle (front) for ditto to for ditto (side) to for ditto (side) to for ditto (side) to for ditto O/S to for ditto O/S to for striker to for ditto O/S to for striker to for ditto O/S to for striker to for for ditto O/S to for striker to for for for ditto O/S to for striker to for for for ditto O/S to for striker to for for for for for ditto O/S to for striker to for striker to for for for for for for ditto O/S to for striker to for striker to for for for for for for for for for fo	r assem cock r assem r assem r assem cock O/S N/S h escutcheon but lator ha (with (with N/S with key addle //S //S	bly) bly) bly) cheon besh and andle a llocking	ush an pin nd ins barre	No.  Common No.  Common No.  Common No.  Common No.  Common No.  Common No.	nn. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 2 4 4 4 4 1 1 1 1
3267/24 3267/24 3267/27 317/21 3267/180 3276/5 3276/6 3276/6 3271/43 3271/44 317/21 3267/103 3267/104 3267/104 3267/103 3267/104 3267/110 3267/39 3267/39 3267/39 3267/39 3267/31 3267/340 \$1063 \$267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/116 3267/117 3267/118 3267/118 3267/119 3267/120 3267/120 3267/120	Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Front door lo Striker assem Rubber to Cover-pla Window Bottom of Handle for we Door handle Escutcher Bush for Pin for of Ontside door Annote to Contside door Annote to Coutside door Annote	N/S (with strike bly for front door leads to for striker to for ditto indow regulator with the for ditto to for window regulator with for for window regulator to for for window regulator to for handle (front) O/S down to for ditto to for door handle (front) for ditto to for ditto (side) to for ditto (side) to for ditto (side) to for ditto O/S to for ditto O/S to for ditto O/S to for ditto O/S to for striker to for striker to for ditto O/S to for striker to for striker to for striker to for ditto O/S to for striker	r assem cock r assem r assem r assem r assem cock O/S N/S h escute lator ha (with N/S (with N/S with key ddle //S	bly) bly) bly) bly) cheon besh andle a llocking	barre	No.  Common No.  Common No.  Cease No.  Common No.  Common No.  Common No.  Common No.  Common No.  Common No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 4 4 4 4 4 1 1 1 1
3267/24 3267/24 3267/27 317/21 3267/180 3276/5 3276/6 3271/43 3271/44 317/21 3267/103 3267/104 3267/104 3267/104 3267/110 3267/43 3267/110 3267/398 3267/398 3267/340 31063 3267/340 31063 3267/116 3267/116 3267/117 3267/117 3267/117 3267/118 3267/119 3267/119 3267/119 3267/120 3267/120 3267/120	Striker assem Rubber th Cover-pla Front door lo Striker assem Rubber th Cover-pla Window Bottom of Handle for w Door handle Escutched Bush for Pin for of Outside door an Outside door An Outside of Contside door An Outside of Contside for Front door Channel for Glazing r Front door vo "Frame fo "Glass for	N/S (with strike bly for front door leads to for striker to for old to for for striker to for for window regulator with findow regulator with findow regulator with findow regulator to for window regulator to for handle (front) O/S d key) to loor handle (front) O/S d key) to for door handle (front) for door handle (front) for ditto to for outside door handle (for outside door handle (for for ditto (side) to for ditto (side) to for ditto (side) to for ditto O/S not for ditto O/S not for ditto O/S not for striker to for ditto O/S not for striker to for for ditto O/S not for striker to for striker to for striker to for striker to for ditto O/S not for striker to for striker	r assem ock r assem r assem r assem r assem r assem sem ock O/S h escute eon bus lator ha (with N/S (with key adde //S /S	bly) bly) bly) bly) cheon bsh and andle a locking	barre	No.  Common No.  Common No.  Ceass No.  Common No.  Common No.  Common No.  Common No.  Common No.  Common No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 2 4 4 4 4 1 1 1 1
3267/23 8267/24 8267/24 8267/27 617/21 8267/180 3276/5 8276/6 8271/43 8271/44 617/21 8267/103 8267/104 3267/104 3267/104 3267/104 3267/110 8267/398 8267/398 8267/398 8267/398 8267/398 8267/114 8267/398 8267/116 8267/398 8267/117 8267/119 8267/119 8267/119 8267/119 8267/119 8267/120 8267/121 8267/121 8267/121 8267/122 8267/121	Striker assem Rubber th Cover-pla Front door lo  Striker assem  Rubber th Cover-pla Window  Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door an Outside door An Outside door An Coutside door An Coutsi	N/S (with strike bly for front door leads for striker to for ditto with escuted to for window regulator with findow regulator with findow regulator to for for window regulator to for handle (front) O/S down to for handle (front) O/S down to for door handle (front) for ditto for door handle (front) for ditto for ditto (side) to for ditto (side) to for ditto (side) to for ditto O/S to f	r assem ock r assem r assem r assem ock O/S , N/S h escuteleon bullator la (with N/S (with N/S , with s/S	bly) bly) bly) bly) cheon bsh andle andl	barre	No.  Comi No.  Comi No.  Cease No.  Com No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 2 2 1 7 2 2 2 2 4 4 4 4 4 4 1 1 1 1 1 1 1 2 2 2 2
B267/24 B267/27 B267/27 B267/180 B276/5 B276/6 B271/43 B276/1143 B276/1143 B276/111 B267/104 B267/104 B267/104 B267/44 B267/44 B267/44 B267/43 B267/44 B267/33 B267/340 A1063 A94/100 B267/116 B267/116 B267/117 B267/118 B267/119 B267/119 B267/119 B267/120 B267/120 B267/120 B267/120 B267/121 B267/122 B267/123	Striker assem Rubber th Cover-pla Front door lo  Striker assem  Rubber th Cover-pla Window  Bottom of Handle for w Door handle Escutched Bush for Pin for d Outside door an Outside door An Outside door An Coutside door An Coutsi	N/S (with strike bly for front door leads for striker to for striker ock O/S (with strike ock o/S (front) O/S (manufacture) ock of the striker ock of ock of the striker ock of the striker ock of the striker ock ock of the striker ock	r assem ock r assem r assem r assem ock O/S , N/S h escuteleon bullator la (with N/S (with N/S , with s/S	bly) bly) bly) bly) s cheon bsh and andle a locking		No.  Comi No.  Comi No.  Comi No.  Com No.	m. Body 1845/9394	1 2 2 2 1 1 1 1 1 2 2 2 2 2 1 1 1 1 1 2 2 2 2 2 1 1 1 1 1 1 2 2 2 2 1 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 1 1 1 1 2 2 2 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 2 1 1 1 1 2 2 2 2 3 1 1 1 1



DESCRIPTION


7	Control	lever O/S	S			• • •			
8		" N/S		•••		•••			
9	Glazing		r ventilator	r					
Ŏ			or ventilate		•••				
7		for centre		•••	•••		•••	•••	
8			entre chan			•••		•••	
	Slide bracke								•••
5		sert for d			ic insc	10,		•••	
3	Screw fo								
9			ket to vent						•••
ő		or ventila		matory					
1	J		N/S	•••	•••	•••	• • • •	•••	•••
1		" "		•••	•••		 	ased 1	Rodu
$\overset{1}{2}$		oor cappi	N/S	•••	•••	•••		o. 193	'-'
5		" "	O/S	•••	•••	•••		omm.	
	"	,, ,,	N/S	•••	•••	•••		o. 184	
	Doolring	"fillet for		•••	•••	•••	_		J/ 5354
	racking	met tor	ditto O/S	• • • •	• • •	• • • •	• • • •	• • •	• • •
	Tr===4 4	" " " " " "	" N/S	•••	• • • •	•••	• · •	•••	• • • •
	riont d	oor fillet	(top) O/S	•••	•••	•••	• • • •	•••	•••
<b>,</b>	**	""	(top) N/S	) OIC	•••	• • • •	• • •	• • • •	•••
,	,,	" "	(shut pillar		•••	• • • •	•••	• • •	•••
	,,	,, ,,	(shut pillar		• • •	• • •	•••	•••	• • •
)	,,	,, ,,	(hinge pilla		• • •			• • •	• • •
)	_ "	,, ,,	(hinge pilla	ar) N/S	• • •	•••	• • •	•••	• • •
l		oor rubbe		• • • •	• • •	•••	• • • •	• • •	• • •
2	Retaine	r for ditte	0	• • •		•••	•••		
	Ashtray	on fron	t door)		Ceas	ed Boo	ly No	. 1614	·/6350
	-	,	,						
									··········
	REAR DOO						on pag	re <b>64</b> )	
	Rear door lo	ock O/S	(with strike	r assem	bly)	•••	<u> </u>		
	Rear door lo	ock O/S " N/S	(with strike (with strike	r assem	bly) bly)		Ce	eased	
	Rear door lo	ock O/S ( " N/S nbly for a	(with strike (with strike rear door lo	r assem er assem oc <b>k</b>	bly) bly) 	···	Ce	eased ody N	
	Rear door lo "Striker asser Rubber	ock O/S " N/S nbly for a bush for	(with strike (with strike rear door lo striker	r assem er assem ock 	bly) bly) 		Ce	eased	
1	Rear door lo "Striker asser Rubber	ock O/S " N/S nbly for a bush for	(with strike (with strike rear door lo striker triker O/S	r assem er assem ock 	bly) bly)  	•••	Ce	eased ody N	
1	Rear door lo	ock O/S of N/S o	(with strike (with strike rear door lo striker triker O/S " N/S	r assemer assemed assemble ass	bly) bly)		Ce	eased ody N	
$1 \\ 2$	Rear door lo "Striker asser Rubber	ock O/S  " N/S  mbly for a  bush for  late for st  ock O/S	(with strike (with strike rear door lo striker triker O/S " N/S (with strike	r assemer assement assemble assemble assemble assemble as a sement assemble assemble assemble as a sement as	ably) ably) ably)		Ce	eased ody N	
1 2	Rear door le  Striker asser Rubber Cover-pl  Rear door le	ock O/S  " N/S  mbly for r  bush for st  ate for st  ock O/S  " N/S	(with strike (with strike rear door lo striker triker O/S ,, N/S (with strike (with strike	r assemer assement assem	ably) ably) ably) ably)			eased ody N 035/864	
1 2	Rear door lo	ock O/S  " N/S  mbly for r  bush for st  ate for st  ock O/S  " N/S	(with strike (with strike rear door lo striker triker O/S " N/S (with strike (with strike rear door lo	r assemer assemed assemble assement assemer assemed assemble as a second assemble as a second assemble	ably) ably) ably) ably)		Ce Be 19	eased ody N 035/864	13
$egin{smallmatrix} 1 \ 2 \end{smallmatrix}$	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser	ock O/S (  " N/S (  mbly for a constant of the	(with strike (with strike rear door lost striker O/S , N/S (with strike (with strike rear door log , " "	r assemer assement assement assement assement assement assement assement N/S	ably) ably) ably) ably) ably)		Co Bo 19	eased ody N 035/864 omm.	i <b>3</b>
1 2	Rear door ke Striker asser Rubber Cover-pl Rear door ke "Striker asser "Rubber"	ock O/S (  "N/S nbly for a bush for state for	(with strike (with strike rear door lost riker O/S , N/S (with strike (with strike rear door lost riker)	r assemer assemed assemble assement assemer assemed assemble as a second assemble as a second assemble	ably) ably) ably) ably) ably)		Co Bo 19	eased ody N 035/864	i <b>3</b>
1 2 2	Rear door ke Striker asser Rubber Cover-pl Rear door ke "Striker asser "Rubber"	bush for state f	(with strike (with strike rear door lost striker O/S N/S (with strike (with strike rear door low striker triker O/S	r assemer assement assement assement assement assement assement assement N/S	ably) ably) ably) ably) ably)		Co Bo 19	eased ody N 035/864 omm.	i <b>3</b>
1 2 2 3	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker "asser "Rubber Cover-pl	ock O/S ( " N/S ( " N/	(with strike (with strike rear door lost striker O/S , N/S (with strike tear door lost iker door lost iker o/S , N/S , N/S , N/S	r assemer assemed assemble assemble assemble assemble ock O/S "N/S"	bly) bly) bly) bly)		CG BG 19 CG BB 18	eased ody N 035/864 omm.	i3 :o. 94
2 2 3 7	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window	ock O/S ( " N/S ( " N/S ( ) bush for state for	(with strike (with striker car door lost iker o/S , N/S (with striker triker door lost iker o/S , N/S , N/S r (rear) O/S	r assemer assembly as a subject as a	bly) bly) bly) ably)		CG BG 18	eased ody N 935/864	o. <b>94</b>
2 3 7 3	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window "	ock O/S ( " N/S ( " N/	(with strike (with striker cear door lost iker O/S , N/S (with striker with striker o/S , " Striker triker O/S , N/S (rear) O/S (rear) N/S	r assem r assen ock O/S ,,, N/S	bly) bly) bly)  bly)  bly)  bly)  bly)  bly)  bly)  bly)		CG B 18	eased ody N 35/864	o. 94 
2 2 3 7 3	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window "Bottom	ock O/S ( " N/S ( " regulator ( " Channel :	(with strike (with strike rear door lost striker O/S "N/S (with strike (with strike rear door lost in "" " " " " " " " " " " " " " " " " "	r assemer assement assemble as	bbly) bbly) bbly) ably) bbly) ably)		CG BG 18	eased ody N 1935/864	 
1 2 2 3 7 8	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for	bush for stock O/S ("N/S") bush for stock O/S ("N/S") bush for stock O/S ("N/S") bush for stock or stock O/S ("N/S") channel stock or stock o/S ("N/S") bush for stock or stoc	(with strike (with strike rear door lost striker O/S "N/S (with strike tear door lost striker O/S "N/S (rear) O/S (rear)	r assemer assement assemble as	ably) ably) ably) ably) ably) tcheon	         bush	CAB 18	eased ody N 935/864	o. 94
1 2 2 3 7 8 1	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker " Striker asser "Rubber" Cover-pl Window Bottom Handle for Door handle	ock O/S ( " N/S ( " N/S ( bush for state for s	(with strike (with striker car door lost iker o/S , N/S (with striker triker O/S , N/S (rear) N/S (rear) N/S (rear) N/S (rear) N/S (with striker o/S , N/S (rear) N/S (rear) N/S (rear) N/S (rear) N/S (rear) N/S (with escutc	r assemer assemer assemer assemer assemer assemer assemer assemer assemer assement assemer assement assemer assement assemer assement assement assement assement assement assement assement assemble as a second assemble a	bly) bly) bly)  bly)  bly) bly)  bly)  bly)  current  cur	       bush	CG BG 18	eased ody N 935/864	o. 94
1 2 2 3 7 8 1	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber" Cover-pl Window Bottom Handle for Door handle Escutch	bush for state f	(with strike (with striker cear door lost iker o/S , N/S (with striker triker O/S , " " striker o/S , " N/S (rear) N/S (rear) N/S for ditto egulator with escutce gulator has	r assemer assemer assemer assemer assemer assemer assemer assement assemer assement assemble	bly) bly) bly) bly) bly) bly) bly) bly)		CC Bo	eased ody N 935/864	  
1 2 2 3 7 8 1	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber" Cover-pl Window Bottom Handle for Door handle Escutch Bush fo	ock O/S ( "N/S" "N/S (	(with strike (with striker terar door lost striker O/S , N/S (with strike (with striker triker O/S , N/S , N/S (rear) O/S (rear) N/S for ditto egulator wiwith escutce egulator ham of the control of the	r assemer assement assemble as	bly) bly) bly) bly) bly) bly) bly) bly)		CG BG 18	eased ody N 1935/864	  
1 2 3 7 8 1	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for to Door handle Escutch Bush fo Pin for	bush for stock O/S ("N/S") nbly for stock O/S ("	(with strike (with strike rear door lost striker O/S "N/S (with strike rear door lost iker O/S "N/S (rear) O/S (rear) O/S (rear) O/S (rear) O/S (rear) N/S (rear) O/S (rear) N/S	r assemer assemock r assemer assemer assemock O/S ,, N/S th escur heon bindle an	ably) ably) ably) ably) ably) tcheon ush an d insid		CC BB 18	eased ody N 1935/864	  
1 2 3 7 8 1 0 7 8 5	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for to Door handle Escutch Bush fo Pin for	bush for state f	(with strike (with strike rear door lost striker O/S "N/S (with strike rear door lost striker O/S "N/S (rear) O/S (rear)	r assemer assemock r assemer assemock O/S , N/S th escur heon bondle an D/S	bly) ably) ably) ably) bly) ably) tcheon ush an d insid		CC B 18	eased ody N 35/864	     Body
1 1 2 3 3 7 8 8 1 0 7 8 5 6	Rear door ke Striker "asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for to Door handle Escutch Bush fo Pin for	bush for stock O/S ("N/S") nbly for stock O/S ("	(with strike (with striker cear door lost iker triker O/S "N/S (with strike tear door lost iker triker O/S "N/S (rear) N/S (rear) N/S for ditto egulator with escutce egulator handle (rear) O/S (rear) N/S (rear	r assemer assembly as a second as a	ably) ably) ably) ably) ably) tcheon ush an d insid		CG Be 18	eased ody N 135/864	 94    Body 4/6350
1 1 2 3 7 8 1 0 7 8 5 6 6 1	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for Door handle Escutch Bush fo Pin for Outside	bush for state f	(with strike (with striker (with striker terar door lot striker O/S , N/S (with striker terar door lot striker O/S , N/S (rear) N/S	r assemer assemock r assemer assemock O/S th escurbed before the control of the contro	bly) ably) ably) ably) bly) ably) tcheon ush an d insid		CCB 18 18 18 18 18 18 18 18 18	ody N 935/864 omm. ody N 1445/933  in eased o. 161	     Body 4/ <b>635</b> (Body
11 22 23 78 11 07 85 61 12	Rear door ke Striker asser Rubber Cover-pl Rear door ke "" Striker asser "Rubber Cover-pl Window Bottom Handle for Door handle Escutch Bush fo Pin for Outside "" ""	bush for stock O/S ("N/S")  channel :  window resultator  channel :  window resultator  channel :  window resultator  ditto ditto  ditto  door han  """  """  """  """  ""  """  """  "	(with strike (with strike rear door lost striker O/S "N/S (with strike rear door lost striker O/S "N/S (rear) O/S (rear)	r assem r asser r asser r asser r assem r assem er assen	bly) bly) bly) bly) bly) bly) bly) bly)		CCB 18 18 18 18 18 18 18 18 18	eased ody N 135/864	     Body 4/ <b>635</b> (Body
1 1 2 2 3 7 8 1 0 7 8 5 6 6 1 1 2 7	Rear door ke Striker asser Rubber Cover-pl Rear door ke "" Rubber Cover-pl Window Bottom Handle for Door handle Escutch Bush fo Pin for Outside "" Packing	ock O/S (  " N/S (  " N/S (  bush for state fo	(with strike (with striker car door lost striker o/S "N/S (with strike tear door lost striker o/S "N/S (rear) N/S (rear)	r assem r asser r asser r asser r assem r assem er assen	bly) ably) ably) ably) they) tcheon ash an d insid		CCB 18 18 18 18 18 18 18 18 18	ody N 935/864 omm. ody N 1445/933  in eased o. 161	     Body 4/ <b>635</b> (Body
1 2 2 3 7 8 1 0 7 8 5 6 6 1 2 7 8	Rear door ke  Striker asser Rubber Cover-pl  Rear door ke  Striker asser  Rubber Cover-pl  Window  Bottom Handle for Door handle Escutch Bush fo Pin for Outside  "" Packing Rear do	ock O/S (  " N/S " N/S bush for state for stat	(with strike (with striker car door lost striker O/S "N/S (with strike triker O/S "N/S (rear) N/S (	r assem r asser r asser r asser r assem r assem er assen	bly) bly) bly)  bly)  bly)  bly)  bly)  bly)  cutcheon  sh an d insid		CCB 18 18 18 18 18 18 18 18 18	omm. ody N 035/864  omm. ody N 045/933  in le eased o. 161 omm. o. 1268	
1 1 2 2 3 7 8 1 0 7 8 5 6 6 1 2 7 8 7	Rear door ke  Striker asser Rubber Cover-pl  Rear door ke  Striker asser  Rubber Cover-pl  Window  Bottom Handle for Door handle Escutch Bush fo Pin for Outside  "" Packing Rear do	ock O/S  "N/S "N/S bush for stock O/S "N/S "N/S "N/S "N/S "N/S "Channel stock O/S "Channe	(with strike (with striker (with striker terar door lot striker O/S , N/S (with striker triker O/S , N/S (rear) N/S (rear	r assemer assemock r assemer assemock O/S , N/S th escur heon be ndle an D/S N/S N/S ndle	bly) ably) bly) ably) bly) ably) cheon ush an d insid		CC BB 18	onmm. ody N 35/864  omm. ody N 345/933  in eased o. 161 omm. o. 1268	0 04 04 04 05 06 07 08 08 08 09 00
$egin{array}{cccccccccccccccccccccccccccccccccccc$	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for Door handle Escutch Bush fo Pin for Outside "" Packing Rear do Channel	bush for state f	(with strike (with strike rear door lost striker O/S "N/S (with strike rear door lost striker O/S "N/S (rear) O/S (rear)	r assemer assemock r assemer assemock O/S th escurheon bondle an D/S V/S V/S V/S Indle	bly) bly) bly)  bly)  bly)  bly)  bly)  cubly)  cubly)	bush d pin le door	CC BB 18	omm. ody N 35/864  omm. ody N 345/938  in eased o. 161 omm. o. 1268	    Body 4/635(Body 5/7341
2 2 3 3 7 7 8 8 1 1 1 2 2 7 7 8 8 7 8 8 7 8 8 8 7 7 8 8 8 8 7 7 8 8 8 8 7 8 8 8 8 8 7 7 8 8 8 8 8 8 7 8 8 8 8 8 8 8 7 8 8 8 8 8 8 8 7 8 8 8 8 8 8 8 7 8 8 8 8 7 8 8 8 8 7 8	Rear door ke  Striker asser Rubber Cover-pl  Rear door ke "" Striker asser "Rubber Cover-pl Window "Bottom Handle for Door handle Escutch Bush fo Pin for Outside "" Packing Rear do Channel Glazing	ock O/S (  " N/S (  " N/S (  " N/S (  bush for state for	(with strike (with striker (with striker terar door lost striker triker O/S "N/S (with striker triker O/S "N/S (rear) O/S (rear) N/S	r assemer assemock r assemer assemock O/S r assemer assemock O/S th escur heon bindle an D/S N/S Indle	bly) ably) ably) ably) ably) tcheon ush an d insid		and pi	omm. ody N 35/864  omm. ody N 345/938  in eased o. 161 omm. o. 1268	    Body 4/6350 Body
2 2 3 3 7 8 5 5 6 6 1 1 2 7 7 8 8 7 7 8 8 7 7 7 8 8 7 7 7 8 7 7 7 8 7	Rear door ke Striker asser Rubber Cover-pl Rear door ke Striker asser "Rubber Cover-pl Window Bottom Handle for Door handle Escutch Bush fo Pin for Outside "" Packing Rear do Channel	ock O/S (  " N/S (  " N/S (  " N/S (  bush for state for	(with strike (with striker (with striker triker O/S , N/S (with striker triker O/S , N/S (rear) N/S	r assemer assemock r assemer assemock O/S r assemer assemock O/S th escur heon bindle an D/S N/S Indle	bly) ably) ably) ably) tcheon ash an d insid		CC B 18 18 18 18 18 18 18 18 18 18 18 18 18	omm. ody N 135/864  omm. ody N 145/938  in eased o. 161 omm. o. 1268	o     Body 4/6350 Body 4/7341 


B287/160	Part No.		DESCRIPT	ION		<b>(B)</b>				No. Us	sed
BB87 160	130,07 (3.50	T. C	7		0.10	•					Saloon
B267/161			NIC			•••	•••	• • •	•••		
B267/162   Centre channel for ditto O/S											
19267/168											
19267   125	B <b>267</b> /163	,,									1
BB871/12F	B267/125	Bracket	for centre cha		op)		• • •		•••	• • •	
19267 128	B267/126	, , , , , , , , , , , , , , , , , , ,		, (b	ottom)	• • •	•••	• • •	• • •		
B287 129		Control	NT/C								
B267/130		Glazing :	**								
B267/18   Slide bracket for control lever (with fibre insert)   2   2   2   2   2   2   2   2   2											
13267/315   Fibre insert for ditto	B267/18					re inser					
B267/299   Screw (slide bracket to ventilator)	B267/315	Fibre ins	sert for ditto						•••		2
B267/292						• • •		• • •	• • •	• • •	
B267/298					,	• • •	•••	• • •	• • •	•••	_
B267/164   Rear door capping O/S	- '	O						• • •			
B267/140								) Ce			
B267/400			NT /								
B267/401											1
B276/109	B267/401						•••	No	. 1268	/7341	1
B267/10								_ ∫ No	. 1935	/8643	
B287/166	B276/109	,, ,,			•••						
B267/167								,			
B267/168   Rear door fillet (top) O/S   1   1   1   1   1   1   1   1   1		Packing									
B267/169		Rear doo									
B267/170											
B267/172	B267/170										1
B267/173	B267/171	,, ,,					•••		·	• • •	
Rear door rubber		,, ,,				• • •	• • •	• • •	• • •	• • • •	
B267/142				. ,			•••				
A1046 Ashtray (on door capping) Comm. Body No. 1268/7341 2 B267/279 Retainer for rear door		and the same of th									
Buffer for rear door											
DOOR HINGES AND CHECKS   B267/39   Door hinge (top) complete   .				,							
DOOR HINGES AND CHECKS		Retainer	for ditto								2
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS											
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS											
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS											
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS											
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS					· · · · · · · · · · · · · · · · · · ·						
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS					· · · · · · · · · · · · · · · · · · ·						
B267/39       Door hinge (top) complete       2         B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto       4         B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       " " (front N/S, rear O/S)       2         B267/175       Special bolt for ditto       2         B267/175       Front door tread plate O/S       1         B267/276       " " " " N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS	****										
B267/40       " (bottom) complete       2         B267/323       Hinge pin       4         B267/324       Tab washer for ditto          B267/381       Nut for ditto          B267/379       Ball for hinge pin          B267/380       Spring for hinge pin          B267/143       Door check (front O/S, rear N/S)          B267/174       Base plate for door checks          B267/175       Special bolt for ditto          B267/275       Front door tread plate O/S          B267/276       " " " " N/S          B267/277       Rear door tread plate          ALTERATIONS				NGES.	AND C	HECK	8				
B267/323       Hinge pin       4         B267/324       Tab washer for ditto       4         B267/381       Nut for ditto          B267/379       Ball for hinge pin          B267/380       Spring for hinge pin          B267/143       Door check (front O/S, rear N/S)          B267/144       ,, (front N/S, rear O/S)          B267/175       Special bolt for ditto          B267/275       Front door tread plate O/S          B267/276       ,, N/S          B267/277       Rear door tread plate          ALTERATIONS											
B267/324       Tab washer for ditto       4         B267/381       Nut for ditto          B267/379       Ball for hinge pin          B267/380       Spring for hinge pin          B267/143       Door check (front O/S, rear N/S)          B267/144       ,       (front N/S, rear O/S)          B267/175       Special bolt for ditto          B267/275       Front door tread plate O/S          B267/276       ,       ,         B267/277       Rear door tread plate          ALTERATIONS											
B267/381       Nut for ditto </td <th></th> <td></td>											
B267/379       Ball for hinge pin       4         B267/380       Spring for hinge pin       4         B267/143       Door check (front O/S, rear N/S)       2         B267/144       ", " (front N/S, rear O/S)       2         B267/174       Base plate for door checks       2         B267/175       Special bolt for ditto       4         B267/275       Front door tread plate O/S       1         B267/276       ", ", ", ", N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS											
B267/380         Spring for hinge pin         4           B267/143         Door check (front O/S, rear N/S)         2           B267/144         " (front N/S, rear O/S)         2           B267/174         Base plate for door checks         2           B267/175         Special bolt for ditto            B267/275         Front door tread plate O/S            B267/276         " " " N/S            B267/277         Rear door tread plate            ALTERATIONS	B267/379				•••	•••					
B267/144	B267/380	Spring fo	or hinge pin			• • •					
B267/174       Base plate for door checks       2         B267/175       Special bolt for ditto       4         B267/275       Front door tread plate O/S       1         B267/276       ",",",N/S       1         B267/277       Rear door tread plate       2         ALTERATIONS	B267/143	Door che				• • •	• • •	•••		• • •	
B267/175       Special bolt for ditto        4         B267/275       Front door tread plate O/S        1         B267/276       " " " N/S        1         B267/277       Rear door tread plate         2         ALTERATIONS						• • •	• • • •		• • •		
B267/275 Front door tread plate O/S 1 B267/276 ", ", ", N/S 1 B267/277 Rear door tread plate 2  ALTERATIONS				ecks							
B267/276 ", ", ", N/S				0/8		•••					
B267/277 Rear door tread plate 2 ALTERATIONS				'							
	B <b>267/277</b>									• • •	2
			AL	TERA	TIONS	3					
Disco Ousta Obasia Fasina and Data Nanta in all Occasional								• • • • • • • • • • • • • • • • • • • •			
Disco Ousta Obasia Fasia and Data Nasha in all Ossansia											
Diseas Orate Obassis Fusion and Bud. North Street, J. J. Accounty						• • • • • • • • • • • • • • • • • • • •				,	
Diseas Ousts Obsessio Fusion and Party Number 12 - II Assessor									. <b></b>		
		Name Out C			d			n			





	SEATS AND CUSHIONS		•	Satoon
B267/12	Front bucket seat O/S complete (less cushion and airbag)	Coased	Body	1
B267/13	Ditto N/S complete (less cushion and airbag)	No. 136		i
B267/28		Comm.		î
	Ditto O/S complete (less cushion)	1		1
B267/29	Ditto N/S complete (less cushion)	J No. 135	•	$\frac{1}{2}$
B267/187	*		•••	$ ilde{f 2}$
B <b>267/188</b> B <b>267/34</b> 9			•••	2
			•••	2
B267/190			• • • •	2
B267/194	\tag{\psi} \ \tag{\psi} \tag{\psi} \ \tag{\psi} \tag{\psi} \ \tag{\psi} \tag{\psi} \ \tag{\psi} \tag{\psi} \ \tag{\psi} \ \tag{\psi} \tag{\psi} \tag{\psi} \ \tag{\psi} \tag{\psi} \ \tag{\psi} \ \tag{\psi} \tag{\psi} \tag{\psi}		• • • •	5
B267/195			• • •	
B267/192	_2		• • •	1
B267/193		N: 100	0/42EA	1
B267/191	Airbag for front seat back panel Ceased Body	NO. 130	3/ <b>4350</b>	2
B267/196			•••	1
B267/197		• • • • • • • • • • • • • • • • • • • •		1.
B267/198			•••	1
B267/199		• • • • • • • • • • • • • • • • • • • •	• • •	1
B267/200		• • • • • • • • • • • • • • • • • • • •	•••	2
B267/201		•••		2
B267/306		• • • • • • • • • • • • • • • • • • • •		2
B267/313		•• •••	• • • •	2
B267/257	j			]
B267/258	Adjusting fitting for ditto			1
	41 200 100 100 100 100			
	ALTERATIONS			
	· · · · · · · · · · · · · · · · · · ·			
• • • • • • • • • • • • • • • • • • • •				
	WINDSCREEN AND REAR LIGHT GLASS (illustration of	ou page 7	(0)	
B267/14	3377 3	Trage .	~ /	
				1
13967/909			• • •	1
B267/202 B267/203	Windscreen frame			1
B267/203	Windscreen frame			1
B267/203 S23/5	Windscreen frame		 	1 1 L lgth
B267/203 S23/5 B267/218	Windscreen frame		 1 1	1 1 1 lgth 1 lgth
B267/203 S23/5 B267/218 B267/16	Windscreen frame		 1 1	1 1 1 lgth 1 lgth 1
B267/203 S23/5 B267/218 B267/16 B267/17	Windscreen frame		 1 1	1 1 1 lgth 1 lgth 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205	Windscreen frame		 1 1	1 1 1 lgth 1 lgth 1 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206	Windscreen frame		1	1 1 1 lgth 1 lgth 1 1 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207	Windscreen frame		1	1 1 1 lgth 1 lgth 1 1 1 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/208	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S Windscreen adjusting bracket (on body) O/S (on body) N/S " " (on screen) O/S " " (on screen) N/S		1	1 1 1 lgth 1 lgth 1 1 1 1 1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/208 B267/209	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S " " " (on body) N/S " " " (on screen) O/S " " (on screen) O/S		1	1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S " " (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Windscreen adjusting link O/S		1	1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/208 B267/209	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S " " (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Windscreen adjusting link O/S Wing nut for ditto		1	1 1 1 1 1 1 1 1 1 1 1 1 1 2
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Wing nut for ditto Screw for wing nut		1	1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/209 B267/209 B267/210 B267/211	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S " " (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Wing nut for ditto Screw for wing nut		1	1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 1 1 2 2
B267/203 S23/5 B267/218 B267/16 B267/17 B267/206 B267/206 B267/206 B267/208 B267/209 B267/210 B267/211 B267/219	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Wing nut for ditto Screw for wing nut		1	1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210 B267/210 B267/210 B267/210	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S Windscreen adjusting bracket (on body) O/S " " (on body) N/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S " " N/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top)		1	1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 1 1 2 2
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/209 B267/210 B267/211 B267/299 B267/300 B267/300	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S  Windscreen adjusting bracket (on body) O/S  " " (on body) N/S  " " (on screen) O/S  " " (on screen) N/S  Windscreen adjusting link O/S " " N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link O/S  " " " " (on screen) N/S  Windscreen adjusting link (top)  " " " " (bottom) (R.H. thread		1	1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 2 2 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/206 B267/207 B267/208 B267/209 B267/210 B267/211 B267/299 B267/300 B267/301 B267/304	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S " " (on screen) O/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " " " (bottom) (R.H. thread) " " " " " (bottom) (L.H. thread) " " " " (bottom) (L.H. thread)		1	1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 1 2 2 2 1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/209 B267/210 B267/210 B267/211 B267/299 B267/300 B267/300 B267/301 B267/302 B267/302 B267/302	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S  " " (on body) N/S " (on screen) O/S " (on screen) N/S Windscreen adjusting link O/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top)  " " (bottom) (R.H. threat windscreen adjuster catch O/S Windscreen adjuster catch O/S		1	1 1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 1 2 2 2 1 1 2
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/206 B267/209 B267/209 B267/210 B267/211 B267/299 B267/300 B267/301 B267/304 B267/394 B267/394 B267/393	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S Windscreen adjusting bracket (on body) O/S " " (on body) N/S " (on screen) O/S " " (on screen) O/S Windscreen adjusting link O/S Windscreen adjusting link O/S Screw for wing nut Dome nut for adjusting link (top)  " " " " (bottom) (R.H. threat washer for ditto Windscreen adjuster catch O/S Windscreen adjuster catch O/S " " " " " (bottom) (L.H. threat washer for ditto Windscreen adjuster catch O/S " " " " " N/S		1	1 1 1 lgth 1 lgth 1 1 1 1 1 1 1 2 2 1 1 1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/209 B267/210 B267/211 B267/211 B267/300 B267/301 B267/304 B267/304 B267/304 B267/304 B267/302	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S  Windscreen adjusting bracket (on body) O/S  " " (on body) N/S  " (on screen) O/S  " " (on screen) O/S  Windscreen adjusting link O/S " " N/S  Windscreen adjusting link O/S  " " " " (bottom) (R.H. thread)  Washer for ditto  Windscreen adjuster catch O/S  " " " " " (bottom) (L.H. thread)  Washer for ditto  Windscreen adjuster catch O/S  " " " " " " (bottom) (L.H. thread)  Washer for ditto		1	1 1 lgth 1 lgth 1 l 1 l 1 l 1 l 1 l 1 l 1 l 2 2 2 l 1 l 2 2 l
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/206 B267/207 B267/209 B267/210 B267/211 B267/299 B267/300 B267/304 B267/304 B267/304 B267/304 B267/304 B267/302 B267/303 B267/303 B267/303 B267/303 B267/303 B267/304	Windscreen frame Windscreen glass		1	1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210 B267/211 B267/211 B267/299 B267/300 B267/301 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/41 B267/41 B267/42	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S  " " " (on body) O/S  " " (on body) N/S  " " (on screen) O/S  " " (on screen) O/S  " " (on screen) N/S  Windscreen adjusting link O/S  Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top)  " " " (bottom) (R.H. threat with the complete of the c		1	1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/205 B267/206 B267/207 B267/209 B267/210 B267/210 B267/211 B267/299 B267/300 B267/300 B267/301 B267/302 B267/302 B267/302 B267/402 B267/303 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402 B267/402	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S " " " (on body) O/S " (on body) N/S " (on screen) O/S " (on screen) O/S " (on screen) N/S  Windscreen adjusting link O/S " (on screen) N/S  Windscreen adjusting link O/S " (on screen) N/S  Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat) " " (bottom) (L.H. threat) " " (bottom) (L.H. threat) " " (bottom) (L.H. threat) " " " N/S  Cup washer for ditto  Windscreen adjuster catch O/S " N/S  Cup washer for ditto  Windscreen hinge complete O/S " " N/S  Windscreen hinge (body portion) O/S		1	1
B267/203 S23/5 B267/218 B267/216 B267/205 B267/205 B267/206 B267/207 B267/209 B267/209 B267/210 B267/211 B267/300 B267/301 B267/301 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S N/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S (on screen) O/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S " " N/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat washer for ditto Windscreen adjuster catch O/S Windscreen adjuster catch O/S Windscreen hinge complete O/S " " N/S Windscreen hinge (body portion) O/S Windscreen hinge (body portion) N/S		1	1
B267/203 S23/5 B267/218 B267/216 B267/16 B267/205 B267/206 B267/206 B267/200 B267/200 B267/210 B267/211 B267/299 B267/300 B267/304 B267/304 B267/304 B267/302 B267/302 B267/302 B267/383 B267/383 B267/382 B267/383 B267/383 B267/384	Windscreen frame Windscreen glass	d)	1	1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/205 B267/206 B267/207 B267/209 B267/210 B267/211 B267/211 B267/211 B267/300 B267/301 B267/301 B267/302 B267/302 B267/302 B267/393 B267/393 B267/393 B267/382 B267/382 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S  """ N/S  Windscreen adjusting bracket (on body) O/S  """ (on screen) O/S  """ (on screen) O/S  """ (on screen) N/S  Windscreen adjusting link O/S  """ (on screen) N/S  Windscreen adjusting link (O/S)  """ (on screen) N/S  Windscreen adjusting link (top)  """ (bottom) (R.H. thread)  """ (bottom) (R.H. thread)  Washer for ditto  Windscreen adjuster catch O/S  """ (bottom) (L.H. thread)  Washer for ditto  Windscreen hinge complete O/S  """ N/S  Windscreen hinge (body portion) O/S  "" (screen portion)  Hexagon bolt (screen portion to body portion)			1
B267/203 S23/5 B267/218 B267/216 B267/16 B267/205 B267/206 B267/206 B267/207 B267/209 B267/210 B267/210 B267/211 B267/300 B267/300 B267/301 B267/302 B267/302 B267/302 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/303 B267/383 B267/384 B267/385 B267/386	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S " " " (on body) O/S " (on body) N/S " (on screen) O/S " (on screen) O/S " (on screen) N/S  Windscreen adjusting link O/S Windscreen adjusting link O/S  Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat) " " (bottom) (L.H. threat) " " " (bottom) (L.H. threat) " " " N/S  Windscreen adjuster catch O/S Windscreen adjuster catch O/S " " N/S  Windscreen hinge (body portion) O/S Windscreen hinge (body portion) N/S " " (screen portion) Hexagon bolt (screen portion to body portion) Washer for ditto	d)		1
B267/203 S23/5 B267/218 B267/216 B267/16 B267/205 B267/206 B267/206 B267/209 B267/209 B267/210 B267/211 B267/300 B267/301 B267/301 B267/394 B267/394 B267/392 B267/393 B267/393 B267/42 B267/482 B267/4884 B267/384 B267/384 B267/384 B267/384 B267/385 B267/386 B267/386	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S " " N/S Windscreen adjusting bracket (on body) O/S " (on body) N/S " (on screen) O/S " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S " " N/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat where the complete O/S " " " (bottom) (L.H. threat where the complete O/S " " N/S Windscreen adjuster catch O/S " " N/S Windscreen hinge complete O/S " " N/S Windscreen hinge (body portion) O/S Windscreen hinge (body portion) N/S " (screen portion) N/S " " (screen portion) Hexagon bolt (screen portion to body portion) Set screw (screen portion to body portion)	d)		1
B267/203 S23/5 B267/218 B267/216 B267/205 B267/205 B267/206 B267/206 B267/209 B267/210 B267/211 B267/211 B267/300 B267/301 B267/302 B267/302 B267/302 B267/302 B267/302 B267/302 B267/384 B267/385 B267/385 B267/385 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/385	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S " " N/S Windscreen adjusting bracket (on body) O/S " (on body) N/S " (on screen) O/S " (on screen) O/S " " (on screen) N/S Windscreen adjusting link O/S " " N/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat was a complete o/S " " " (bottom) (L.H. threat was a complete o/S " " " " N/S Windscreen adjuster catch O/S " " N/S  Cup washer for ditto Windscreen hinge complete O/S " " N/S Windscreen hinge (body portion) O/S " (screen portion) N/S " (screen portion) Lexagon bolt (screen portion to body portion) washer for ditto Set screw (screen portion to body portion) Screw (screen hinge to screen) (female)	d)		1
B267/203 S23/5 B267/218 B267/16 B267/17 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210 B267/211 B267/211 B267/211 B267/390 B267/300 B267/301 B267/393 B267/394 B267/392 B267/392 B267/393 B267/393 B267/382 B267/384 B267/385 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/384 B267/385 B267/384 B267/385 B267/386 B267/387 B267/404 B267/404	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S  """ N/S  Windscreen adjusting bracket (on body) O/S  """ (on body) N/S  """ (on screen) O/S  """ (on screen) N/S  Windscreen adjusting link O/S  """ (on screen) N/S  Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top)  """ (bottom) (R.H. thread) Washer for ditto  Windscreen adjuster catch O/S  """ N/S  Cup washer for ditto  Windscreen hinge (body portion) O/S  """ (screen portion) O/S  "" (screen portion)  Hexagon bolt (screen portion to body portion) Washer for ditto  Set screw (screen portion to body portion) Screw (screen hinge to screen) (female) Washer for ditto  Washer for ditto  Screw (screen portion to body portion)	d)		1
B267/203 S23/5 B267/218 B267/216 B267/16 B267/205 B267/206 B267/206 B267/207 B267/209 B267/210 B267/210 B267/211 B267/300 B267/301 B267/301 B267/302 B267/302 B267/302 B267/302 B267/302 B267/303 B267/302 B267/303 B267/304 B267/388 B267/388 B267/388 B267/388 B267/386 B267/386 B267/386 B267/386 B267/386 B267/404 B267/404 B267/405 B267/405 B267/405	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S Windscreen adjusting bracket (on body) N/S  " " (on screen) O/S " (on screen) N/S Windscreen adjusting link O/S " " N/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threa " " (bottom) (L.H. threa Windscreen adjuster catch O/S Windscreen adjuster catch O/S Windscreen hinge complete O/S " " N/S Windscreen hinge (body portion) O/S Windscreen hinge (body portion) N/S (screen portion to body portion) Washer for ditto Screw (screen portion to body portion) Screw (screen hinge to screen) (female) Screw (screen hinge to screen) (male)			1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/207 B267/208 B267/209 B267/210 B267/210 B267/211 B267/300 B267/301 B267/301 B267/301 B267/302 B267/302 B267/303 B267/402 B267/392 B267/383 B267/42 B267/384 B267/385 B267/386 B267/386 B267/387 B267/388 B267/404 B267/404 B267/405 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388 B267/388	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S " " " (on body) O/S " " (on body) N/S " (on screen) O/S " (on screen) O/S " (on screen) N/S Windscreen adjusting link O/S " " (on screen) N/S Windscreen adjusting link O/S  Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threat) " " (bottom) (L.H. threat) " " (bottom) (D/S " " N/S Windscreen adjuster catch O/S " " N/S Windscreen hinge (body portion) O/S " (body portion) N/S " (screen portion) N/S " (screen portion) to body portion) Washer for ditto Screw (screen hinge to screen) (female) Washer for ditto Screw (screen aperture rubber (top)			1
B267/203 S23/5 B267/218 B267/16 B267/16 B267/205 B267/206 B267/206 B267/207 B267/209 B267/210 B267/210 B267/210 B267/300 B267/301 B267/301 B267/302 B267/302 B267/302 B267/302 B267/302 B267/303 B267/302 B267/383 B267/384 B267/384 B267/385 B267/386 B267/386 B267/386 B267/386 B267/386 B267/386 B267/386 B267/386 B267/386 B267/386 B267/404 B267/404 B267/405 B267/405 B267/405	Windscreen frame Windscreen glass Glazing rubber for ditto Windscreen draught excluder rubber Windscreen adjusting fittings complete O/S Windscreen adjusting bracket (on body) O/S Windscreen adjusting bracket (on body) N/S Windscreen adjusting bracket (on body) N/S Windscreen adjusting link O/S " " (on screen) O/S " " (on screen) N/S Windscreen adjusting link (O/S Wing nut for ditto Screw for wing nut Dome nut for adjusting link (top) " " (bottom) (R.H. threa Windscreen adjuster catch O/S Windscreen adjuster catch O/S Windscreen hinge complete O/S " " N/S Windscreen hinge (body portion) O/S Windscreen hinge (body portion) N/S (screen portion to body portion) Washer for ditto Set screw (screen portion to body portion) Screw (screen hinge to screen) (female) Washer for ditto Screw (screen hinge to screen) (male) Screw (screen aperture rubber (top)			1





Part No.		DESCRIPTION		(1)			•	No. Us	sed
B267/216 B267/217	Windscre	een aperture rubber	O/S N/S					• • •	Saloc 1 1
3267/219	Rear ligl	nt glass" "			• • • •	•••		• • •	i
3267/220		channel for ditto	•••					•••	1
3267/221	Clip for	ditto	•••		•••	•••	•••	•••	2
		ALTERA	TIONS						
			· · · · · · · · · · · · · · · · · · ·			· · · · · · · · · · · · · · · · · · ·			
••••									•••••
						. <b></b>			
						· · · · · · · · · · · · · · · · · · ·			
••••••					•••••			· · · · · · · · · · · · · · · · · · ·	• • • • • •
						· · · · · · · · · · · · · · · · · · ·			
						· · · · · · · · · · · · · · · · · · ·	·····		
						••••••		• • • • • • • • • • • • • • • • • • • •	
267/285	Hinge fo	r boot lid O/S	E BOOT			) Ce	ased I	Body	]
3267/286	",	, " " N/S	•••	•••		ĴΝο	. 1363	3/4350	]
3267/332	,, ,		•••	•••	•••		nım, l		]
3267/333 3267/225	Arm for	, " " N/S boot lid O/S	•••	•••			o. <b>135</b> 8 ased I		
3267/226 3267/226	Aim ioi	" " N/S	•••	• • • •		9 .	641		
3267/304	" "	" " o/s		• • •		ή Co	nım. İ	Body	
3267/305	" "	" "N/S	•••	• • •	• • •	J No	. 707/	3671	
3267/227 3267/228		ock for boot lid ock plate	***		•••	• • • •	• • •	•••	
3267/30		oot lid (with locking	barrel	and k	(ev)				
1066	Locking	barrel for ditto (wit	h key)						
894/100	Key for		•••			•••		• • •	
3267/230		for boot lid	•••	• • •	• • •		• • • •	• • • •	:
3267/232 3267/283		for boot lid flap aple for boot lid				•••	• • •		:
3267/284		mat for boot			•••				
3267/100		or boot lid (top)	• • •	•••					
3267/234	Plate for			•••	•••	• • • •	• • •	•••	
3267/310 3267/311		or boot lid (side) curing) for ditto		Comr	n Bo	ody No	759	/377B	
3267/312		ate for ditto (on boo	t lid)	Com	150	dy 110		31.10	
3267/273	Floor fix	ing bolt (in boot)	•••		•••				
3267/274	Special v	washer for ditto	•••	• • •	•••		•••	•••	
		ALTERA	TIONS						
					• • • • • • • • • • • • • • • • • • • •				
								<b></b>	
				•••••					
					•••••			• • • • • • • • • • • • • • • • • • • •	· · · · · •
					· · · · · · · · · · · · · · · · · · ·				
				· · · · · · · · · · · · · · · · · · ·	••••				
					••••				
			• • • • • • • • • • • • • • • • • • • •	<b></b>	•••••	• • • • • • • • • • • • • • • • • • • •	••••		
		SLIDING							
3267/236		device for sliding ro	of	• • •	• • •	•••	•••	• • • •	
3267/237 3267/303		for ditto r handle	•••	• • •	•••	•••	• • • •	•••	
3267/303 3267/238		for sliding roof			•••	•••			
3267/239		oof guide O/S							
3267/240	C1. 1.	" " N/S	• • •	•••	• • •	• • •	• • •	• • •	
3267/241 3267/242		oof runner cking for sliding roo	 of (long)	•••	•••	•••	•••		
3267/242 3267/243	ribie pa	erring for stitling LOC	of (long) short)	)	• • • •				
3267/244	Rubber :	for sliding roof		, <b>.</b>	•••			•••	
3267/280		sliding roof (front)	• • •		•••	• • • •		• • • •	
3267/281 3967/989	" "	" " (rear)	•••	•••	• • • •	•••	• • •	• • • •	
3267/282	,, ,,	" " (sides)							

Part No.	<b>(D)</b>	DESCRIPTI	ON					No. Us	sed
B267/321 B267/322 B267/347 B267/348	Drip way " " " "	N/S O/S N/S	   TERAT	   IONS	•••		Ceased Bo No. 1614/ Comm. B No. 1268/	<b>6350</b> ody	Saloo: 1 1 1 1
	••••	AL,							
	***************************************			· · · · · · · · · · · · · · · · · · ·					
								• • • • • • • • • • • • • • • • • • • •	
				•••••					
B <b>267/15</b>	Facia board (	ACIA BOARD			lids)		NT 2014/6		
B267/34	Ditto				Comm.	Body	No. 1614/6 No. 1268/7	341	1 1
B267/45 B267/251 B267/328 B267/344 B267/345 S25/6 B267/252 B267/253 B267/249 B267/246 B267/309 B267/346 B267/346	Hinge for Knob for Catch for Glove poo Capping f	" N/S for screen rail  " " " " " " " " " " " " " " " " " " "	 bid lid lid  		Ceased Comm. Ceased Comm. Ceased Comm.	Body	No. 1935/8 No. 1845/9 Ceased B No. 1614/ Comm. B No. 1268/	394 ody 6350 ody 7341   350 341 643 394	1 1 1 1 1 1 2 2 2 1 1 1 1 1 1 1 1 1 1 1
•••••								• • • • • • • • • • • • • • • • • • • •	· · · · · · · · · · · · · · · · · · ·
B267/265 B267/266 B267/267	Floorboard "Carpet (fi	N/S ront) O/S	•••	3 (illu: 	:		ge 70)  		1 1 1
B267/268 B267/269 B267/307 B267/270	Carpet on	ront) N/S remote contr propeller sha	ol (for (for	use v	ith one vith isol	piece rated r	emote cont	rol)	1 1 1
B267/308 B267/271 B267/272 B220/109	gea Ditto ( Carpet un Heel boar	rbox) for use with s ider front seat	synchror and in	nesh g rear	 gearbox) footwell 	·· · · ·			1 1 2 1 1
S68/10	Gearbox 1	rubber cover				•		•••	1
	***************************************		ΓERATΙ						
• • • • • • • • • • • • • • • • • • • •									





1888			DIAD	F177	TINA					Sato
	Roof-lamp complete	DY INTE		. FIII			) Cea	sed B	odv	1
888/100	Glass for roof-las							1935		1
1045	Roof-lamp complete							nm. B		1
1045/100	Glass for roof-las							1845		1
20/8	Bulb for roof-lar	np								1
889	Switch for roof-l	amp								1
890	Ashtray (on arm	ı-rest)			Ceasec	l Body	No.	1614/	6350	2
831	Sun visor (end :	fixing)								2
1039		e fixing)								2
1040		e fixing)			•••		• • •	• • •		2
1039/100	Sun visor shield					• • •	• • •		• • •	2
1040/100	" " " "	(centre f				• • •	• • •	• • •	• • • •	2
1039/101	Bracket for sun	,		(xing	• • • •	• • •	· · ·		• • • •	2
267/259	Rear blind	oord		• • •	• • •		• • •	• • • •	• • •	1 2
267/260 967/961	Pulley for blind				• • • •			• • •	• • • •	
$267/261 \\ 887$	Operating slide 1 Trafficators			•••	• • •		• • •	• • •	•••	1
	Bulb for ditto			• • •	• • •	• • • •	• • •	• • •		$\frac{2}{2}$
20/20	Daily for three	•••			•••		• • • •	• • • •	•••	_
		ALTE	RATI	IONS						
									• • • • • • • • • • • • • • • • • • • •	
					• • • • • • • • • •	•••••				
		CUTTIE	VENI		·					
267/38	Control assembly for	SCUTTLE					`			1
267/367	Clevis pin for di						Cor	nın.		ī
267/368								ly No		i
267/363	Bracket for cont							1/6230		ì
267/408	Sealing rubber f						1000	-/020	•	î
/		1		-		***	)			
		ALTE	RAT	IONS						
			• • • • • • • • • • • • • • • • • • • •							
										*
										*
										*
	FOI	URSOME	BODY	/ DEI	TAILS					· · · · · · · · · · · · · · · · · · ·
	FOI DOORS, I					INGES				fours
	Door lock O/S (with	LOGKS, H striker)	AND	LES A	ND H	INGES	•••			ionrs:
274/2	Door lock O/S (with	LOCKS, H striker) striker)	ANDI	-E\$ A		INGES		•••		1
274/2 274/104	Door lock O/S (with ,, ,, N/S (with Striker for door	LOGKS, H striker) striker)	ANDI	-ES A	ND H				•••	1 1 2
274/2 274/104 274/105	Door lock O/S (with ", ", N/S (with Striker for door Door handle (on	LOCKS, H striker) striker) lock	ANDI	-E\$ A	ND H	•••	 } wit	 h N/S	•••	1 1 2 1
274/2 274/104 274/105 274/3	Door lock O/S (with , , , N/S (with Striker for door Door handle (out Door handle (outside	striker) striker) lock tside) O/S	ANDI	ES A	ND H	   and key)	 wit lock	 h N/S king h	  landle	1 1 2 1 1
274/2 274/104 274/105 274/3 267/33	Door lock O/S (with " " N/S (with Striker for door Door handle (outside " " (outside	LOGKS, H striker) striker) lock tside) O/S N/S (wi	ANDI	LES A	IND H	  and key) .nd key)	 wit lock wit	 h N/S king h h O/S	andle	1 1 2 1 1
274/2 274/104 274/105 274/3 267/33 267/340	Door lock O/S (with ", ", N/S (with Striker for door Door handle (outside ", ", (outside Door handle (ou	LOGKS, H striker) striker) lock tside) O/S N/S (wi e) O/S (wi tside) N/S	ANDI	LES A	ND H	   and key) .nd key)	wit lock	h N/S king h h O/S king h	andle	1 2 1 1 1
274/2 274/104 274/105 274/3 267/33 267/340	Door lock O/S (with ", ", N/S (with Striker for door Door handle (outside ", (outside ", (outside Door handle (ou Locking barrel f	striker) striker) lock triside) O/S N/S (wi c) O/S (wi c) O/S (wi c) o/S (or door h	ANDI	LES A	which was a second control of the co	  and key) nd key) 	wit lock wit lock	h N/S king h h O/S king h	andle	1 1 2 1 1 1
274/2 274/104 274/105 274/3 267/33 267/340 .063 94/100	Door lock O/S (with ", N/S (with Striker for door Door handle (outside ", (outside Door handle (ou Locking barrel f Key for ditto	striker) striker) striker) lock .ttside) O/S O/S (wi c) O/S (wi ttside) N/S or door h	ANDI	LES A	which has been a control a	  and key) d key) 	wit lock wit lock	h N/S king h h O/S king h	andle	1 1 2 1 1 1 1
274/2 274/104 274/105 274/3 267/33 267/340 1063 894/100 274/8	Door lock O/S (with , "N/S (with Striker for door Door handle (outside " " (outside Door handle (ou Locking barrel f Key for ditto Door handle inside (	striker) lock striker) lock tside) O/S N/S (wi O/S (wi tside) N/S or door h plain)	ANDI	LES A	barrel a	  and key) d key)  	wit lock wit lock	h N/S king h h O/S king h	andle	1 2 1 1 1 1 1 1 2
274/2 274/104 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/43	Door lock O/S (with " N/S (with Striker for door Door handle (outside " (outside Door handle (ou Locking barrel f Key for ditto Door handle inside (	striker) lock striker) lock tside) O/S N/S (wi O/S (wi tside) N/S or door h plain) with M.G	ANDI  th lock the loc	LES A	barrel a  key)  in key)	  and key) nd key)  	wit lock wit lock	h N/S king h h O/S king h	andle	1 1 2 1 1 1 1 1 2 2
274/2 274/104 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/48 267/110	Door lock O/S (with N/S (with Striker for door Door handle (outside Door handle inside ("" "" "" "" "" "" "" "" "" "" "" "" ""	LOCKS, H striker) lock ttside) O/S ) N/S (wi ttside) N/S for door h  plain) with M.G	th locate	LES A	barrel a barrel a key)	  and key) nd key)  	wit lock	h N/S king h h Ö/S king h	andle	1 1 1 1 1 1 1 2 2
274/2 274/104 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/43 267/43 267/43	Door lock O/S (with N/S (with Striker for door Door handle (outside noor handle noor handle inside (noor handle noor han	LOCKS, H striker) striker) lock ttside) O/S (wi 0) O/S (wi ttside) N/S for door h  plain) plain) rubber)	ANDI	LES A	which has been depicted as the second	  and key) nd key)  	wit lock	h N/S king h h O/S king h	andle andle andle 	1 1 1 1 1 1 2 2 2
274/2 274/104 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/43 267/110 267/398	DOORS, I Door lock O/S (with , N/S (with Striker for door Door handle (outside , (outside ) Door handle (ou Locking barrel f Key for ditto Door handle inside ( "Escutheon for o Bush for ditto Pin for ditto	striker) lock striker) lock ttside) O/S (wi ttside) N/S (wi ttside) N/S or door h plain) with M.G litto rubber)	th locate	eking him (with	barrel a carrel a car	  und key) nd key)  	wit lock	h N/S king h h O/S king h	andle andle andle  	1 1 1 1 1 1 2 2 2 2
274/2 274/104 274/105 274/105 274/3 2667/33 267/340 1063 894/100 274/8 267/43 267/43 267/110 267/397 267/398 274/106	Door lock O/S (with , "N/S (with Striker for door Door handle (outside " (outside Door handle (outside Locking barrel f Key for ditto Door handle inside (" " " ( Escutcheon for of Bush for ditto Vindow winder	striker) lock striker) lock tside) O/S (wi tside) N/S or door h plain) with M.G litto rubber) handle	th locath	LES A	barrel a coarrel	  nd key) nd key)  	wit lock	h N/S king h h O/S king h	andle	1 1 1 1 1 1 2 2 2 2 2 2
274/2 274/104 274/105 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/43 267/110 267/397 267/398 274/106 274/107	Doors, I Door lock O/S (with ", ", N/S (with Striker for door Door handle (outside ", ", (outside Door handle (outside Locking barrel f Key for ditto Door handle inside (" " " " Escutcheon for G Bush for ditto Window winder Door glass	LOCKS, H. striker) striker) lock ttside) O/S (with tside) N/S (with ts	ANDI	LES A	barrel a barrel a barrel a  i key)   i	and key) nd key)	wit lock wit lock	h N/S king h h O/S king h	andle	1 1 1 1 1 1 2 2 2 2 2 2
274/2 274/104 274/105 274/3 267/33 267/340 1063 394/100 274/8 267/143 267/110 267/397 267/398 274/106 274/106	Doors, I Door lock O/S (with ", ", N/S (with Striker for door Door handle (outside ", ", (outside Door handle (outside Locking barrel f Key for ditto Door handle inside ", ", " Escutcheon for G Bush for ditto Window winder Door glass Channel for ditte	LOCKS, H striker) striker) lock ttside) O/S N/S (wi ttside) N/S for door h with M.G litto rubber) handle o (front)	th locate	LES A	barrel a coarrel a key)		wit lock wit lock	h N/S king h h O/S king h	andle	1 1 1 1 1 1 2 2 2 2 2 2 1
274/1 274/2 274/104 274/105 274/3 267/33 267/340 1063 894/18 247/48 267/110 267/397 267/398 274/106 274/107 274/108 274/108 274/108	Doors, I Door lock O/S (with ", ", N/S (with Striker for door Door handle (outside ", ", (outside Door handle (outside Locking barrel f Key for ditto Door handle inside (" " " " Escutcheon for G Bush for ditto Window winder Door glass	LOCKS, H. striker) striker) lock ttside) O/S (with tside) N/S (with ts	th locate	eking king king king king king king king	barrel abarrel		wit lock wit lock	h N/S king h h O/S king h	andle	1 1 1 1 1 1 2 2 2 2 2 2


Part No.		DESCRIP	TION		<b>(D)</b>				No. Us	sed
										ourson
B274/110		ige (top) O/S		• • •	•••	• • •	• • •	• • • •	• • •	1
B <b>274/111</b> B <b>274/112</b>	,, ,,	(annima) (		• • •	•••	• • •	• • •	• • •	• • •	1 1
B <b>274/113</b>	, ,, ,,	(00-4) 7								ì
B274/114	, ,,	(haddanis)	4							î
B <b>274/115</b>	,, ,,	(bottom)	N/S							1
B <b>274/161</b>	Door hin		•••		• • •		• • • •	•••	• • •	6
B274/116		ck strap	• • •	• • •	•••		• • •	• • •	•••	2
B274/117 B274/118	Door pul	r ditto ll		•••	•••	•••	• • •	•••	• • •	$\frac{4}{2}$
B <b>274/120</b>		(on door)	•••						• • •	$\frac{2}{2}$
B <b>274/121</b>		g fitting for								$ar{2}$
B <b>274</b> /160		nut for ditte	o							<b>2</b>
3274/122	Door buf	)_ *.'		• • •						2
3274/123	,, ,, Char fan			•••		•••	• • •	• • •	•••	2
3 <b>274/124</b> 3 <b>274/125</b>	Shoe for		•••	• • •	•••	• • •	•••	• • • •		$rac{2}{2}$
0414/120	Catch pla	ate for ditto	•••	• • •	•••		•••	•••	•••	4
			LTERA				, , , , , , , , , , , , , , , , , , , ,			
					**********					
		• • • • • • • • • • • • • • • • • • • •			• • • • • • • • • • • • • • • • • • • •					
		FACIA, WI	NDSCRE	EN A	ND HO	OD				
8274/6	Facia board	(with glove p	pocket lie							1
3274/135	Lid for g	glove pocket			• • •		• • •			1
3274/136	,, ,,	" "	N/S	• • •	• • • •	• • •	• • • •	• • •	• • • •	1
3274/126		en frame		0/8	• • •		• • •	• • •		1 1
3 <b>274</b> /4 3 <b>274</b> /5		en adjuster	=	N/S						1
3274/127	Windscre	en glass	,,,	•••			• • •			î
3274/128		le support O								í
3274/129		n N	Í/S		• • • •					1
	"									4
3274/157	Nut for	ditto	• • •	• • •			• • •			
3274/157 $3274/132$	Nut for Hood to	screen wing							• • •	2
$3274/132 \ 3274/133$	Nut for Hood to Pull for	screen wing hood	nut 		•••				•••	<b>2</b>
$3274/132 \ 3274/133$	Nut for Hood to	screen wing hood						•••	• • •	
$8274/132 \ 8274/133$	Nut for Hood to Pull for	screen wing hood at glass	nut 			• • •		 	•••	2
$8274/132 \ 8274/133$	Nut for Hood to Pull for	screen wing hood at glass	nut 			• • •		 	•••	2
$8274/132 \ 8274/133$	Nut for Hood to Pull for Rear ligh	screen wing hood nt glass A	nutLTERA	rions	··· ···		•••			2
$8274/132 \ 8274/133$	Nut for Hood to Pull for Rear ligh	screen wing hood it glass A	nut	rions	 S		•••			2
$8274/132 \ 8274/133$	Nut for Hood to Pull for Rear ligh	screen wing hood it glass A	nut	rions	 S		•••			<b>2</b>
$8274/132 \ 8274/133$	Nut for Hood to Pull for Rear ligh	screen wing hood it glass A	nut	rions	 S		•••			<b>2</b>
3274/132 3274/133 3274/156	Nut for Hood to Pull for Rear ligh	screen wing hood nt glass A	nut	LIONS	··· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ··		•••			2
3274/132 3274/133 3274/156 3274/137	Nut for Hood to Pull for Rear ligh	screen wing hood at glass A	LTERA	TINGS	··· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ·· ··		•••			1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138	Nut for Hood to Pull for Rear ligh	screen wing hood at glass A	nut	TINGS	  		•••			1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/138	Nut for Hood to Pull for Rear ligh	screen wing hood at glass A  See (on seat) (on floor)	nut	TINGS	3 					1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood at glass A	nut	TINGS	 S		•••			1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood It glass  A  see (on seat) (on seat) (on floor) (on floor)	nut	TINGS	3					1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood It glass  A  see (on seat) (on seat) (on floor) (on floor)	EAT FIT (plain) (locking) (locking)	TINGS	3 	•••	•••			1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood A	EAT FIT (plain) (locking) (plain) (locking)	TINGS	3	•••				1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood at glass  A  see (on seat) (on floor) (on floor) A	EAT FIT (locking) (plain) (locking)	TINGS	3 		•••			1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood A	EAT FIT (locking) (plain) (locking)	TINGS	3 		•••			1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139	Nut for Hood to Pull for Rear ligh	screen wing hood It glass  A  see (on seat) (on floor) (on floor)	EAT FIT (plain) (locking) (plain) (locking)	TINGS	3 		•••			1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139 3274/140	Nut for Hood to Pull for Rear ligh	screen wing hood A  A  See (on seat) (on floor) (on floor)	EAT FIT (plain) (locking) (locking) (LTERA)	TINGS	3   					1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139 3274/140	Nut for Hood to Pull for Rear ligh	screen wing hood at glass  A  see (on seat) (on floor) (on floor) A  dele stay for h	EAT FIT (plain) (locking) (plain) (locking) (LTERA)	TINGS	3  		•••			1 1 1 1 1 1 1
3274/132 3274/133 3274/156 3274/156 3274/137 3274/138 3274/139 3274/140 3274/141 3274/141	Nut for Hood to Pull for Rear ligh	screen wing hood  It glass  A  See (on seat) (on floor) (on floor)  A  Cole stay for h	EAT FIT (plain) (locking) (plain) (locking) UGGAGE	TINGS FIONS FIONS O)S	3   					1 1 1 1 1
3274/132	Nut for Hood to Hood to Pull for Rear ligh	screen wing hood at glass  A  see (on seat) (on floor) (on floor) A  dele stay for h	EAT FIT (plain) (locking) (plain) (locking) WALTERA	TINGS	3  		•••			1 1 1 1 1 1 1

## DESCRIPTION



No. Used

B274/7 Handle for boot lid (with locking barrel and key) Ccased B267/30 ", ", " (with locking barrel and key) Comm A1066 Locking barrel for ditto (with key) A894/100 Key for ditto	• •••	Foursom 1 1 1 1
B267/30 " " " (with locking barrel and key) Comm A1066 Locking barrel for ditto (with key)	• •••	1 1 1
A1066 Locking barrel for ditto (with key)		1
A1066 Locking barrel for ditto (with key)		_
A894/100 Key for ditto	• •••	1
		1
ALTERATIONS		
TOOL KIT (illustration on page 76) Saloon	Tourer	Foursom
\$78/16 Tool roll 1	1	1
\$78/2 Tappet spanner 1	1	1
S78/3 Tappet feeler gauge (.015") 1	1	1
S78/4 Spanner for cylinder head nuts 1	1	1
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	1	1
$P330/140$ , , $(\frac{5}{16}" \times \frac{3}{8}")$ 1	1	1
$S78/5$ , $\left(\frac{7}{16}'' \times \frac{1}{2}''\right)$ 1	1	1
P330/110 Tommy bar for ditto 1	1	1
S78/6 Double-ended spanner $(\frac{3}{16}'' \times \frac{1}{4}'')$ 1	1	1
$S78/6$ Double-ended spanner $(\frac{3}{16}'' \times \frac{1}{4}'')$ 1 $S78/7$ , , , $(\frac{5}{16}'' \times \frac{3}{8}'')$ 1	1	1
$S78/8$ , , $(\frac{7}{16}'' \times \frac{1}{2}'')$ 1	1	1
P330/104 Pliers 1	1	1
S78/9 Screwdriver 1	1	1
S78/10 Oilcan 1	1	1
P330/130 Hammer 1	ī	ī
P330/117 , (copper headed) 1	î	î
S78/11 Tyre valve tool 1	1	î
Omorbina and the second of the	i	ī
A1074 Distributor screwdriver (with feeler gauge) 1 Grease gun Ceased Ch. No. SA2751 1	ì	i
9	i	1
A1135 ", (hydraulic) Comm. Ch. No. SA2752 1		
S78/13 Wrench for Lockheed bleeder screw 1	1	1
S78/15 Drain and tube for Lockheed system 1	1	1
S78/22 Tyre pump 1	1	1
MG679/36 Starting handle Ceased Ch. No. SA1500 1	1	1
MG679/508 , , Comm. Ch. No. SA1501 1	1	1
S78/17 Tool for rear axle oil filler 1	1	1
P330/126 Tyre levers 2	<b>2</b>	2
ALTERATIONS		
	· · · · · · · · · · · · · · · · · · ·	
		•••••••



Telephone:
25! Abingdon

Telegrams: "Emgee," Abingdon



Chairman • • • VISCOUNT NUFFIELD, G.B.E.
Vice-Chairman • • SIR MILES THOMAS, D.F.C.
Managing Director • • • • • • H. A. RYDER